ACME

ACME BEAMONE (BEAM 1)



Manufacturer	**ACME**
Type	**Moving head**
DMX modes	**1**
DMX footprint	**16 channels**
Beam angle	**2°**
Pan range	**540°**
Tilt range	**270°**
Size (W × H × D)	**216 × 307 × 200 mm**
GDTF fixture type	**D33E9E2F-E455-4770-B4AE-A6…**

Controls

Focus · Frost · Prism · Prism rotation · Colour wheel · Strobe · Dimmer · Pan and tilt · Gobos

Safety-relevant functions

Lamp on and off · Fixture reset · Strobe

DMX modes

Mode1 16DMX — 16 ch

Mode1 16DMX

16 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Pan Fine	0	Fine byte of Pan
3	Tilt	128	
4	Tilt Fine	0	Fine byte of Tilt
5	P TSpeed	0	
6	Color Wheel	0	0–7 Open (wheel slot 1) 8–11 Color 1 (wheel slot 2) 12–15 Color 2 (wheel slot 3) 16–19 Color 3 (wheel slot 4) 20–23 Color 4 (wheel slot 5) 24–27 Color 5 (wheel slot 6) 28–31 Color 6 (wheel slot 7) 32–35 Color 7 (wheel slot 8) 36–39 Color 8 (wheel slot 9) 40–43 Color 9 (wheel slot 10) 44–47 Color 10 (wheel slot 11) 48–51 Color 11 (wheel slot 12) 52–55 Color 12 (wheel slot 13) 56–59 Color 13 (wheel slot 14) 60–63 Color 14 (wheel slot 15) 64–64 Open (wheel slot 1) 65–127 Index 128–158 << 159–188 << 189–189 < 190–193 Stop 194–224 > 225–254 >> 255–255 >>>
7	Gobo	0	0–7 Open (wheel slot 1) 8–11 Gobo 1 (wheel slot 2) 12–14 Gobo 2 (wheel slot 3) 15–18 Color 3 (wheel slot 4) 19–21 Color 4 (wheel slot 5) 22–25 Color 5 (wheel slot 6) 26–28 Color 6 (wheel slot 7) 29–32 Color 7 (wheel slot 8) 33–35 Color 8 (wheel slot 9) 36–39 Color 9 (wheel slot 10) 40–42 Color 10 (wheel slot 11) 43–49 Color 11 (wheel slot 12) 50–56 Color 12 (wheel slot 13) 57–63 Color 13 (wheel slot 14) 64–127 Shake 128–158 <<< 159–188 << 189–189 < 190–193 Stop 194–224 >>> 225–254 >> 255–255 >
8	Prism	0	0–7 Close 8–255 Open (wheel slot 1)

Mode1 16DMX (continued)

Ch	Function	Default	DMX values
9	Prism Rotation	0	0–127 Prism1PosRotate 1 128–158 << 159–188 < 189–189 < 190–193 Open 194–224 >>> 225–254 >> 255–255 >
10	Frost1	0	
11	Focus	128	
12	Focus Fine	0	Fine byte of Focus
13	Shutter / Strobe	0	0–7 Close 8–15 Open 16–131 Strobe 132–139 Open 1 140–181 Strobe 1 182–189 Open 2 190–231 Strobe 2 232–239 Open 3 240–247 Strobe 3 248–255 Open 4
14	Dimmer	0	
15	Dimmer Fine	0	Fine byte of Dimmer
16	Function	0	0–129 No Function 1 130–139 lamp On 140–149 p/t reset 3 150–159 eff Reset 4 160–199 No Function 5 200–209 all reset 6 210–213 GoboWheelShortcutMode 7 214–217 ColorWheelShortcutMode 8 218–229 No Function 9 230–239 Lamp Off 10 240–255 No Function 11