ACME

ACME CINDERELLA (WASH 100)



Manufacturer	**ACME**
Type	**Moving head**
DMX modes	**2**
DMX footprint	**15, 25 channels**
Beam angle	**6°**
Pan range	**540°**
Tilt range	**175°**
Heads / cells	**4**
Size (W × H × D)	**159 × 134 × 160 mm**
GDTF fixture type	**222524A6-11B4-4041-B234-B1…**

Controls

Colour temperature · Colour wheel · Strobe · Dimmer · Pixel control · Pan and tilt

Safety-relevant functions

Fixture reset

DMX modes

Mode 2 15CH	15 ch
Mode 1 25CH	25 ch

Mode 2 15CH

15 channels

Ch	Function	Default	DMX values
1	Pan	127	
2	Pan Fine	255	Fine byte of Pan
3	Tilt	127	
4	Tilt Fine	255	Fine byte of Tilt
5	P TSpeed	0	
6	Red	255	
7	Green	255	
8	Blue	255	
9	White	0	
10	Color Wheel	0	0–9 Open (wheel slot 1) 10–14 Color 1 (wheel slot 2) 15–19 Color 2 (wheel slot 3) 20–24 Color 3 (wheel slot 4) 25–29 Color 4 (wheel slot 5) 30–34 Color 5 (wheel slot 6) 35–39 Color 6 (wheel slot 7) 40–44 Color 7 (wheel slot 8) 45–49 Color 8 (wheel slot 9) 50–54 Color 9 (wheel slot 10) 55–59 Color 10 (wheel slot 11) 60–64 Color 11 (wheel slot 12) 65–69 Color 12 (wheel slot 13) 70–74 Color 13 (wheel slot 14) 75–79 Color 14 (wheel slot 15) 80–84 Color 15 (wheel slot 16) 85–89 Color 16 (wheel slot 17) 90–94 Color 17 (wheel slot 18) 95–99 Color 18 (wheel slot 19) 100–104 Color 19 (wheel slot 20) 105–109 Color 20 (wheel slot 21) 110–114 Color 21 (wheel slot 22) 115–119 Color 22 (wheel slot 23) 120–124 Color 23 (wheel slot 24) 125–129 Color 24 (wheel slot 25) 130–134 Color 25 (wheel slot 26) 135–139 Color 26 (wheel slot 27) 140–144 Color 27 (wheel slot 28) 145–149 Color 28 (wheel slot 29) 150–154 Color 29 (wheel slot 30) 155–159 Color 30 (wheel slot 31) 160–164 Color 31 (wheel slot 32) 165–169 Color 32 (wheel slot 33) 170–174 Color 33 (wheel slot 34) 175–179 Open 180–190 >>> 191–200 >> 201–201 > 202–207 Stop 208–217 < 218–228 < 229–229 <<< 230–234 Open 235–239 Random Fast 240–244 Random Medium 245–249 Random Slow 250–255 Open
11	C TO	0	

Mode 2 15CH (continued)

Ch	Function	Default	DMX values
12	Shutter / Strobe	12	0–7 Closed 8–15 Open 16–130 min Strobe 131–131 max Strobe 132–139 Open 2 140–180 min Pulse Open 181–181 max Pulse Open 189–189 Open 3 190–230 min Pulse Close 231–231 max Pulse Close 232–239 Sound Strobe 240–246 min Strobe Ran 247–247 max Strobe Ran 248–255 Open 5
13	Dimmer	0	
14	Dimmer Fine	0	Fine byte of Dimmer
15	Function	0	0–29 NoFunction 30–39 Dim Curve Line 40–49 Dim Square Law 50–59 Dim Inv Square Law 60–69 Dim Curve S 70–139 NoFunction 140–149 PT Reset 150–159 Eff Reset 160–199 NoFunction 200–209 All Reset 210–219 Fast 220–229 Slow 230–255 NoFunction

Mode 1 25CH

25 channels

Ch	Function	Default	DMX values
1	Pan	127	
2	Pan Fine	255	Fine byte of Pan
3	Tilt	127	
4	Tilt Fine	255	Fine byte of Tilt
5	P TSpeed	0	
6	Shutter / Strobe	12	0–7 Closed 8–15 Open 16–130 min Strobe 131–131 max Strobe 132–139 Open 2 140–180 min Pulse Open 181–181 max Pulse Open 189–189 Open 3 190–230 min Pulse Close 231–231 max Pulse Close 232–239 Sound Strobe 240–246 min Strobe Ran 247–247 max Strobe Ran 248–255 Open 5
7	Dimmer	0	
8	Dimmer Fine	0	Fine byte of Dimmer

Mode 1 25CH (continued)

Ch	Function	Default	DMX values
9	Function	0	0–29 NoFunction 30–39 Dim Curve Line 40–49 Dim Square Law 50–59 Dim Inv Square Law 60–69 Dim Curve S 70–139 NoFunction 140–149 PT Reset 150–159 Eff Reset 160–199 NoFunction 200–209 All Reset 210–219 Fast 220–229 Slow 230–255 NoFunction
10	Red	255	
11	Green	255	
12	Blue	255	
13	White	0	
14	Red	255	
15	Green	255	
16	Blue	255	
17	White	0	
18	Red	255	
19	Green	255	
20	Blue	255	
21	White	0	
22	Red	255	
23	Green	255	
24	Blue	255	
25	White	0	