ADJ

Inno Pocket Spot



Manufacturer	**ADJ**
Type	**Moving head**
DMX modes	**2**
DMX footprint	**9, 11 channels**
Beam angle	**13°**
Pan range	**525°**
Tilt range	**180°**
Size (W × H × D)	**90 × 146 × 90 mm**
GDTF fixture type	**8F9439A6-A789-4F7A-A049-17…**

Controls

Colour wheel · Strobe · Dimmer · Pan and tilt · Movement speed · Gobos

Safety-relevant functions

Strobe

DMX modes

9CH	9 ch
11CH	11 ch

9CH

9 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Tilt	128	
3	Color Wheel	0	0–7 WHITE (wheel slot 1) 8–14 RED (wheel slot 2) 15–21 ORANGE (wheel slot 3) 22–28 YELLOW (wheel slot 4) 29–35 GREEN (wheel slot 5) 36–42 BLUE (wheel slot 6) 43–49 LIGHT BLUE (wheel slot 7) 50–56 PINK (wheel slot 8) 57–127 Split (wheel slot 8) 128–189 Scroll Fast to Slow 190–193 Stop 194–255 Scroll Slow to Fast
4	Gobo	0	0–7 Open (wheel slot 1) 8–15 Gobo 1 (wheel slot 2) 16–23 Gobo 2 (wheel slot 3) 24–31 Gobo 3 (wheel slot 4) 32–39 Gobo 4 (wheel slot 5) 40–47 Gobo 5 (wheel slot 6) 48–55 Gobo 6 (wheel slot 7) 56–63 Gobo 7 (wheel slot 8) 64–71 Open (wheel slot 1) 72–79 Gobo 1 (wheel slot 2) 80–87 Gobo 2 (wheel slot 3) 88–95 Gobo 3 (wheel slot 4) 96–103 Gobo 4 (wheel slot 5) 104–111 Gobo 5 (wheel slot 6) 112–119 Gobo 6 (wheel slot 7) 120–127 Gobo 7 (wheel slot 8) 128–189 SCROLL FAST - SLOW 190–193 STOP 194–255 SCROLL SLOW - FAST
5	Shutter / Strobe	15	0–7 LED OFF 8–15 LED ON 16–131 STROBING SLOW - FAST 132–139 LED ON 140–181 SHUTTER SLOW OPEN - FAST CLOSE 182–189 LED ON 190–231 SHUTTER FAST OPEN - SLOW CLOSE 232–239 LED ON 240–247 RANDOM STROBE 248–255 LED ON
6	Dimmer	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
7	Position MSpeed	0	
8	Function	0	0–69 NO FUNCTION 70–79 BLACKOUT WITH PAN/TILT 80–89 NO BLACKOUT WITH PAN/TILT 90–99 BLACKOUT WITH COLOR CHANGE 100–109 NO BLACKOUT WITH COLOR CHANGE 110–119 BLACKOUT WITH GOBO CHANGE 120–129 NO BLACKOUT WITH GOBO CHANGE 130–199 NO FUNCTION 200–209 RESET ALL 210–249 NO FUNCTION 250–255 SOUND ACTIVE MODE

9CH (continued)

Ch	Function	Default	DMX values
9	Dimmer Mode	0	0–20 STANDARD 21–40 STAGE 41–60 TV 61–80 ARCHITECTURAL 81–100 THEATER 101–255 DEFAULT TO UNIT CURVE SETTING

11CH

11 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Pan Fine	128	Fine byte of Pan
3	Tilt	128	
4	Tilt Fine	0	Fine byte of Tilt
5	Color Wheel	0	0–7 WHITE (wheel slot 1) 8–14 RED (wheel slot 2) 15–21 ORANGE (wheel slot 3) 22–28 YELLOW (wheel slot 4) 29–35 GREEN (wheel slot 5) 36–42 BLUE (wheel slot 6) 43–49 LIGHT BLUE (wheel slot 7) 50–56 PINK (wheel slot 8) 57–127 Split (wheel slot 8) 128–189 Scroll Fast to Slow 190–193 Stop 194–255 Scroll Slow to Fast
6	Gobo	0	0–7 Open (wheel slot 1) 8–15 Gobo 1 (wheel slot 2) 16–23 Gobo 2 (wheel slot 3) 24–31 Gobo 3 (wheel slot 4) 32–39 Gobo 4 (wheel slot 5) 40–47 Gobo 5 (wheel slot 6) 48–55 Gobo 6 (wheel slot 7) 56–63 Gobo 7 (wheel slot 8) 64–71 Open (wheel slot 1) 72–79 Gobo 1 (wheel slot 2) 80–87 Gobo 2 (wheel slot 3) 88–95 Gobo 3 (wheel slot 4) 96–103 Gobo 4 (wheel slot 5) 104–111 Gobo 5 (wheel slot 6) 112–119 Gobo 6 (wheel slot 7) 120–127 Gobo 7 (wheel slot 8) 128–189 SCROLL FAST - SLOW 190–193 STOP 194–255 SCROLL SLOW - FAST
7	Shutter / Strobe	15	0–7 LED OFF 8–15 LED ON 16–131 STROBING SLOW - FAST 132–139 LED ON 140–181 SHUTTER SLOW OPEN - FAST CLOSE 182–189 LED ON 190–231 SHUTTER FAST OPEN - SLOW CLOSE 232–239 LED ON 240–247 RANDOM STROBE 248–255 LED ON

11CH (continued)

Ch	Function	Default	DMX values
8	Dimmer	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
9	Position MSpeed	0	
10	Function	0	0–69 NO FUNCTION 70–79 BLACKOUT WITH PAN/TILT 80–89 NO BLACKOUT WITH PAN/TILT 90–99 BLACKOUT WITH COLOR CHANGE 100–109 NO BLACKOUT WITH COLOR CHANGE 110–119 BLACKOUT WITH GOBO CHANGE 120–129 NO BLACKOUT WITH GOBO CHANGE 130–199 NO FUNCTION 200–209 RESET ALL 210–249 NO FUNCTION 250–255 SOUND ACTIVE MODE
11	Dimmer Mode	0	0–20 STANDARD 21–40 STAGE 41–60 TV 61–80 ARCHITECTURAL 81–100 THEATER 101–255 DEFAULT TO UNIT CURVE SETTING