ADJ

Inno Pocket Z4



Manufacturer	**ADJ**
Type	**Moving head**
DMX modes	**3**
DMX footprint	**16, 19, 22 channels**
Beam angle	**10-16°**
Pan range	**525°**
Tilt range	**180°**
Heads / cells	**2**
Size (W × H × D)	**96 × 120 × 96 mm**
GDTF fixture type	**96F4C466-F996-4F11-B622-AD…**

Controls

Zoom · Colour wheel · Strobe · Dimmer · Pixel control · Pan and tilt · Movement speed

Safety-relevant functions

Fixture reset · Strobe

DMX modes

16CH	16 ch
19CH	19 ch
22CH	22 ch

16CH

16 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Pan Fine	128	Fine byte of Pan
3	Tilt	128	
4	Tilt Fine	0	Fine byte of Tilt
5	Red	0	0–62 0 % LED 1 63–126 25 % LED 1 127–190 50 % LED 1 191–254 75 % LED 1 255–255 100 % LED 1
6	Green	0	0–62 0 % LED 1 63–126 25 % LED 1 127–190 50 % LED 1 191–254 75 % LED 1 255–255 100 % LED 1
7	Blue	0	0–62 0 % LED 1 63–126 25 % LED 1 127–190 50 % LED 1 191–254 75 % LED 1 255–255 100 % LED 1
8	White	0	0–62 0 % LED 1 63–126 25 % LED 1 127–190 50 % LED 1 191–254 75 % LED 1 255–255 100 % LED 1
9	Red	0	0–62 0 % LED 2 63–126 25 % LED 2 127–190 50 % LED 2 191–254 75 % LED 2 255–255 100 % LED 2
10	Green	0	0–62 0 % LED 2 63–126 25 % LED 2 127–190 50 % LED 2 191–254 75 % LED 2 255–255 100 % LED 2
11	Blue	0	0–62 0 % LED 2 63–126 25 % LED 2 127–190 50 % LED 2 191–254 75 % LED 2 255–255 100 % LED 2
12	White	0	0–62 0 % LED 2 63–126 25 % LED 2 127–190 50 % LED 2 191–254 75 % LED 2 255–255 100 % LED 2
13	Zoom	0	
14	Shutter / Strobe	15	0–7 LED OFF 8–15 LED ON 16–131 Strobing Slow-Fast 132–139 LED ON 140–181 Slow Open-Fast Close 182–189 LED ON 190–231 Fast Open-Slow Close 232–239 LED ON 240–247 Random Strobing Slow-Fast 248–255 LED ON

16CH (continued)

Ch	Function	Default	DMX values
15	Dimmer	0	0–62 0 percent 63–126 25 percent 127–190 50 percent 191–254 75 percent 255–255 100 percent
16	Function	0	0–69 No Function 70–79 Blackout w/ Pan/Tilt Movement 80–89 Disable Blackout with Pan/Tilt Movement 90–199 No Function 200–209 Reset All 210–255 No Function

19CH

19 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Pan Fine	128	Fine byte of Pan
3	Tilt	128	
4	Tilt Fine	0	Fine byte of Tilt
5	Red	0	0–62 0 % LED 1 63–126 25 % LED 1 127–190 50 % LED 1 191–254 75 % LED 1 255–255 100 % LED 1
6	Green	0	0–62 0 % LED 1 63–126 25 % LED 1 127–190 50 % LED 1 191–254 75 % LED 1 255–255 100 % LED 1
7	Blue	0	0–62 0 % LED 1 63–126 25 % LED 1 127–190 50 % LED 1 191–254 75 % LED 1 255–255 100 % LED 1
8	White	0	0–62 0 % LED 1 63–126 25 % LED 1 127–190 50 % LED 1 191–254 75 % LED 1 255–255 100 % LED 1
9	Red	0	0–62 0 % LED 2 63–126 25 % LED 2 127–190 50 % LED 2 191–254 75 % LED 2 255–255 100 % LED 2
10	Green	0	0–62 0 % LED 2 63–126 25 % LED 2 127–190 50 % LED 2 191–254 75 % LED 2 255–255 100 % LED 2
11	Blue	0	0–62 0 % LED 2 63–126 25 % LED 2 127–190 50 % LED 2 191–254 75 % LED 2 255–255 100 % LED 2

19CH (continued)

Ch	Function	Default	DMX values
12	White	0	0–62 0 % LED 2 63–126 25 % LED 2 127–190 50 % LED 2 191–254 75 % LED 2 255–255 100 % LED 2
13	Color Macro1	0	0–7 No Function 8–11 Color Macro 1 12–15 Color Macro 2 16–19 Color Macro 3 20–22 Color Macro 4 23–26 Color Macro 5 27–30 Color Macro 6 31–34 Color Macro 7 35–37 Color Macro 8 38–41 Color Macro 9 42–45 Color Macro 10 46–48 Color Macro 11 49–52 Color Macro 12 53–56 Color Macro 13 57–60 Color Macro 14 61–63 Color Macro 15 64–67 Color Macro 16 68–71 Color Macro 17 72–75 Color Macro 18 76–79 Color Macro 19 80–82 Color Macro 20 83–85 Color Macro 21 86–89 Color Macro 22 90–93 Color Macro 23 94–97 Color Macro 24 98–101 Color Macro 25 102–104 Color Macro 26 105–108 Color Macro 27 109–112 Color Macro 28 113–115 Color Macro 29 116–119 Color Macro 30 120–123 Color Macro 31 124–127 Color Macro 32 128–191 Color Changing 192–255 Color Fading
14	Color Macro1Rate	0	
15	Zoom	0	
16	Shutter / Strobe	15	0–7 LED OFF 8–15 LED ON 16–131 Strobing Slow-Fast 132–139 LED ON 140–181 Slow Open-Fast Close 182–189 LED ON 190–231 Fast Open-Slow Close 232–239 LED ON 240–247 Random Strobing Slow-Fast 248–255 LED ON
17	Dimmer	0	0–62 0 percent 63–126 25 percent 127–190 50 percent 191–254 75 percent 255–255 100 percent

19CH (continued)

Ch	Function	Default	DMX values
18	Function	0	0–69 No Function 70–79 Blackout w/ Pan/Tilt Movement 80–89 Disable Blackout with Pan/Tilt Movement 90–199 No Function 200–209 Reset All 210–255 No Function
19	Dimmer Mode	0	0–20 Standard 21–40 Stage 41–60 TV 61–80 Architectural 81–100 Theatre 101–255 Default to unit setting

22CH

22 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Pan Fine	128	Fine byte of Pan
3	Tilt	128	
4	Tilt Fine	0	Fine byte of Tilt
5	Red	0	0–62 0 % LED 1 63–126 25 % LED 1 127–190 50 % LED 1 191–254 75 % LED 1 255–255 100 % LED 1
6	Green	0	0–62 0 % LED 1 63–126 25 % LED 1 127–190 50 % LED 1 191–254 75 % LED 1 255–255 100 % LED 1
7	Blue	0	0–62 0 % LED 1 63–126 25 % LED 1 127–190 50 % LED 1 191–254 75 % LED 1 255–255 100 % LED 1
8	White	0	0–62 0 % LED 1 63–126 25 % LED 1 127–190 50 % LED 1 191–254 75 % LED 1 255–255 100 % LED 1
9	Red	0	0–62 0 % LED 2 63–126 25 % LED 2 127–190 50 % LED 2 191–254 75 % LED 2 255–255 100 % LED 2
10	Green	0	0–62 0 % LED 2 63–126 25 % LED 2 127–190 50 % LED 2 191–254 75 % LED 2 255–255 100 % LED 2
11	Blue	0	0–62 0 % LED 2 63–126 25 % LED 2 127–190 50 % LED 2 191–254 75 % LED 2 255–255 100 % LED 2

22CH (continued)

Ch	Function	Default	DMX values
12	White	0	0–62 0 % LED 2 63–126 25 % LED 2 127–190 50 % LED 2 191–254 75 % LED 2 255–255 100 % LED 2
13	Color Macro1	0	0–7 No Function 8–11 Color Macro 1 12–15 Color Macro 2 16–19 Color Macro 3 20–22 Color Macro 4 23–26 Color Macro 5 27–30 Color Macro 6 31–34 Color Macro 7 35–37 Color Macro 8 38–41 Color Macro 9 42–45 Color Macro 10 46–48 Color Macro 11 49–52 Color Macro 12 53–56 Color Macro 13 57–60 Color Macro 14 61–63 Color Macro 15 64–67 Color Macro 16 68–71 Color Macro 17 72–75 Color Macro 18 76–79 Color Macro 19 80–82 Color Macro 20 83–85 Color Macro 21 86–89 Color Macro 22 90–93 Color Macro 23 94–97 Color Macro 24 98–101 Color Macro 25 102–104 Color Macro 26 105–108 Color Macro 27 109–112 Color Macro 28 113–115 Color Macro 29 116–119 Color Macro 30 120–123 Color Macro 31 124–127 Color Macro 32 128–191 Color Changing 192–255 Color Fading
14	Color Macro1Rate	0	
15	Position Effect	0	0–15 No Function 16–35 Macro 1 36–55 Macro 2 56–75 Macro 3 76–95 Macro 4 96–115 Macro 5 116–135 Macro 6 136–155 Macro 7 156–175 Macro 8 176–195 Macro 9 196–215 Macro 10 216–235 Macro 11 236–255 Macro 12
16	Position Effect Rate	0	
17	Zoom	0	

22CH (continued)

Ch	Function	Default	DMX values
18	Shutter / Strobe	15	0–7 LED OFF 8–15 LED ON 16–131 Strobing Slow-Fast 132–139 LED ON 140–181 Slow Open-Fast Close 182–189 LED ON 190–231 Fast Open-Slow Close 232–239 LED ON 240–247 Random Strobing Slow-Fast 248–255 LED ON
19	Dimmer	0	0–62 0 percent 63–126 25 percent 127–190 50 percent 191–254 75 percent 255–255 100 percent
20	Position MSpeed	0	
21	Function	0	0–69 No Function 70–79 Blackout w/ Pan/Tilt Movement 80–89 Disable Blackout with Pan/Tilt Movement 90–199 No Function 200–209 Reset All 210–255 No Function
22	Dimmer Mode	0	0–20 Standard 21–40 Stage 41–60 TV 61–80 Architectural 81–100 Theatre 101–255 Default to unit setting