ATON

Que Par



Manufacturer	**ATON**
Type	**Effect light**
DMX modes	**4**
DMX footprint	**5, 7, 10, 15 channels**
Beam angle	**25°**
Size (W × H × D)	**258 × 173 × 40 mm**
GDTF fixture type	**E6E4A166-C707-4548-BEC9-C1…**

Controls

Extra LED colours · RGB colour mixing · Colour temperature · Effect speed · Strobe · Dimmer

Safety-relevant functions

Strobe · Built-in effect programmes

DMX modes

5 Channel	5 ch
7 Channel	7 ch
10 Channel	10 ch
15 Channel	15 ch

5 Channel

5 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	White	255	
5	Control1	0	0–49 Dimmer Speed 0 50–99 Dimmer Speed 1 100–149 Dimmer Speed 2 150–199 Dimmer Speed 3 200–255 Dimmer Speed 4

7 Channel

7 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open
2	Red	255	
3	Green	255	
4	Blue	255	
5	White	255	
6	Shutter / Strobe	0	0–9 Open 10–122 Strobe Slow 123–254 Strobe Med 255–255 Strobe Fast
7	Control1	0	0–49 Dimmer Speed 0 50–99 Dimmer Speed 1 100–149 Dimmer Speed 2 150–199 Dimmer Speed 3 200–255 Dimmer Speed 4

10 Channel

10 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open
2	Red	255	
3	Green	255	
4	Blue	255	
5	White	255	
6	Shutter / Strobe	0	0–9 Open 10–122 Strobe Slow 123–254 Strobe Med 255–255 Strobe Fast
7	C TO	0	

10 Channel (continued)

Ch	Function	Default	DMX values
8	Effect	0	0–20 Open 21–30 Auto 1 31–40 Auto 2 41–50 Auto 3 51–60 Auto 4 61–70 Auto 5 71–80 Auto 6 81–90 Auto 7 91–100 Auto 8 101–110 Auto 9 111–120 Auto 10 121–255 NoFeature 1
9	Effect Speed	0	0–127 Slow 128–254 Medium 255–255 Fast
10	Control1	0	0–49 Dimmer Speed 0 50–99 Dimmer Speed 1 100–149 Dimmer Speed 2 150–199 Dimmer Speed 3 200–255 Dimmer Speed 4

15 Channel

15 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open
2	Dimmer Fine	0	Fine byte of Dimmer
3	Red	255	
4	Red Fine	255	Fine byte of Red
5	Green	255	
6	Green Fine	255	Fine byte of Green
7	Blue	255	
8	Blue Fine	255	Fine byte of Blue
9	White	255	
10	White Fine	255	Fine byte of White
11	Shutter / Strobe	0	0–9 Open 10–122 Strobe Slow 123–254 Strobe Med 255–255 Strobe Fast
12	C TO	0	
13	Effect	0	0–20 Open 21–30 Auto 1 31–40 Auto 2 41–50 Auto 3 51–60 Auto 4 61–70 Auto 5 71–80 Auto 6 81–90 Auto 7 91–100 Auto 8 101–110 Auto 9 111–120 Auto 10 121–255 NoFeature 1
14	Effect Speed	0	0–127 Slow 128–254 Medium 255–255 Fast

15 Channel (continued)

Ch	Function	Default	DMX values
15	Control1	0	0–49 Dimmer Speed 0 50–99 Dimmer Speed 1 100–149 Dimmer Speed 2 150–199 Dimmer Speed 3 200–255 Dimmer Speed 4