Chauvet Professional

COLORado PXL Bar 16



Manufacturer	**Chauvet Professional**
Type	**Moving head**
DMX modes	**13**
DMX footprint	**7, 8, 19, 20, 26, 48, 64, 84, 128, 154, 182, 186 channels**
Beam angle	**8.9-42.2°**
Tilt range	**200°**
Heads / cells	**16**
Size (W × H × D)	**993 × 184 × 105 mm**
GDTF fixture type	**10909037-4ADB-4EE5-9B6C-B7…**

Controls

Zoom · Extra LED colours · RGB colour mixing · Colour temperature · Colour wheel · Effect speed · Strobe · Dimmer · Pixel control · Pan and tilt · Movement speed

Safety-relevant functions

Fixture reset · Built-in effect programmes

DMX modes

Dual Control Movement: Basic2 7ch	7 ch
Dual Control Movement: Basic 8ch	8 ch
Single Control: Basic2 Mode 19ch	19 ch
Dual Control Movement: Standard 20ch	20 ch
Single Control: Basic Mode 20ch	20 ch
Dual Control Movement: Advanced 26ch	26 ch
Dual Control Pixels:Basic 48ch	48 ch
Dual Control Pixels:Standard 64ch	64 ch
Single Control: Standard Mode 84ch	84 ch
Dual Control Pixels : Advanced Mode 128ch	128 ch
Single Control: Advanced Mode 154ch	154 ch
Single Control: Full PXL Mode 182ch	182 ch
Single Control: Tour Mode 186ch	186 ch

Dual Control Movement: Basic2 7ch

7 channels

Ch	Function	Default	DMX values
1	Tilt	127	0–126 Min 127–254 Home 255–255 Max
2	Tilt Fine	255	Fine byte of Tilt
3	Position MSpeed	0	0–0 Min 1–254 Min > Max 255–255 Max
4	Dimmer	0	0–0 Min 1–254 Min > Max 255–255 Max
5	Shutter / Strobe	22	0–19 Shutter Closed 20–24 Shutter Open 25–25 STROBE · Fast 20 Hz 26–63 STROBE · Fast > Slow 19.5–0.61 Hz 64–64 STROBE · Slow 0.1 Hz 65–69 Shutter Open 70–70 STROBE 100-0% · Fast 20 Hz 71–83 STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 84–84 STROBE 100-0% · Slow 0.1 Hz 85–89 Shutter Open 90–90 STROBE 0-100% · Fast 20 Hz 91–103 STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 104–104 STROBE 0-100% · Slow 0.1 Hz 105–109 Shutter Open 110–110 RANDOM STROBE · Fast 20 Hz 111–123 RANDOM STROBE · Fast > Slow 18.6–1.52 Hz 124–124 RANDOM STROBE · Slow 0.1 Hz 125–129 Shutter Open 130–130 RANDOM STROBE 100-0% · Fast 20 Hz 131–143 RANDOM STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 144–144 RANDOM STROBE 100-0% · Slow 0.1 Hz 145–149 Shutter Open 150–150 RANDOM STROBE 0-100% · Fast 20 Hz 151–163 RANDOM STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 164–164 RANDOM STROBE 0-100% · Slow 0.1 Hz 165–169 Shutter Open 170–170 PULSE STROBE · Fast 20 Hz 171–183 PULSE STROBE · Fast > Slow 18.6–1.52 Hz 184–184 PULSE STROBE · Slow 0.1 Hz 185–189 Shutter Open 190–190 RANDOM PULSE STROBE · Fast 20 Hz 191–203 RANDOM PULSE STROBE · Fast > Slow 18.6–1.52 Hz 204–204 RANDOM PULSE STROBE · Slow 0.1 Hz 205–209 Shutter Open 210–210 STROBE 0-100-0% · Fast 20 Hz 211–223 STROBE 0-100-0% · Fast > Slow 18.6–1.52 Hz 224–224 STROBE 0-100-0% · Slow 0.1 Hz 225–229 Shutter Open 230–230 RANDOM PULSE STROBE 1 · Fast 20 Hz 231–243 RANDOM PULSE STROBE 1 · Fast > Slow 18.6–1.52 … 244–244 RANDOM PULSE STROBE 1 · Slow 0.1 Hz 245–255 Shutter Open
6	Zoom	127	0–0 Wide 1–254 Wide > Narrow 255–255 Narrow

Dual Control Movement: Basic2 7ch (continued)

Ch	Function	Default	DMX values
7	Control1	0	0–9 No Function 10–14 Blackout On Tilt 15–19 Reserved 20–24 RGBW Color Mixing Mode 25–29 CMY Color Mixing Mode 30–39 Reserved 40–44 Defrost Fan On 45–49 Defrost Fan Off 50–54 Reserved 55–59 Tilt Reset 60–64 Zoom Reset 65–69 Reserved 70–74 Reset All 75–75 PWM 600Hz 76–76 PWM 1200Hz 77–77 PWM 2000Hz 78–78 PWM 4000Hz 79–79 PWM 6000Hz 80–80 PWM 15000Hz 81–81 Reserved 82–84 Cell Order 1-16 85–89 Cell Order 16-1 90–94 Tilt Reverse 95–99 Reserved 100–104 Tilt Reverse Disable 105–119 Reserved 120–124 Fan ECO 125–129 Fan Full 130–134 Fan Auto 135–139 Dimmer Fast 140–144 Dimmer Smooth 145–149 Linear 150–154 Square 155–159 Inverse Square 160–164 S Square 165–169 White Mode 170–174 Full Mode 175–239 Color Macros HTP On 240–247 Color Macros HTP Off 248–255 Reserved

Dual Control Movement: Basic 8ch

8 channels

Ch	Function	Default	DMX values
1	Tilt	127	0–126 Min 127–254 Home 255–255 Max
2	Tilt Fine	255	Fine byte of Tilt
3	Position MSpeed	0	0–0 Min 1–254 Min > Max 255–255 Max
4	Dimmer	0	0–0 Min 1–254 Min > Max 255–255 Max

Dual Control Movement: Basic 8ch (continued)

Ch	Function	Default	DMX values
5	Shutter / Strobe	22	0–19 Shutter Closed 20–24 Shutter Open 25–25 STROBE · Fast 20 Hz 26–63 STROBE · Fast > Slow 19.5–0.61 Hz 64–64 STROBE · Slow 0.1 Hz 65–69 Shutter Open 70–70 STROBE 100-0% · Fast 20 Hz 71–83 STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 84–84 STROBE 100-0% · Slow 0.1 Hz 85–89 Shutter Open 90–90 STROBE 0-100% · Fast 20 Hz 91–103 STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 104–104 STROBE 0-100% · Slow 0.1 Hz 105–109 Shutter Open 110–110 RANDOM STROBE · Fast 20 Hz 111–123 RANDOM STROBE · Fast > Slow 18.6–1.52 Hz 124–124 RANDOM STROBE · Slow 0.1 Hz 125–129 Shutter Open 130–130 RANDOM STROBE 100-0% · Fast 20 Hz 131–143 RANDOM STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 144–144 RANDOM STROBE 100-0% · Slow 0.1 Hz 145–149 Shutter Open 150–150 RANDOM STROBE 0-100% · Fast 20 Hz 151–163 RANDOM STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 164–164 RANDOM STROBE 0-100% · Slow 0.1 Hz 165–169 Shutter Open 170–170 PULSE STROBE · Fast 20 Hz 171–183 PULSE STROBE · Fast > Slow 18.6–1.52 Hz 184–184 PULSE STROBE · Slow 0.1 Hz 185–189 Shutter Open 190–190 RANDOM PULSE STROBE · Fast 20 Hz 191–203 RANDOM PULSE STROBE · Fast > Slow 18.6–1.52 Hz 204–204 RANDOM PULSE STROBE · Slow 0.1 Hz 205–209 Shutter Open 210–210 STROBE 0-100-0% · Fast 20 Hz 211–223 STROBE 0-100-0% · Fast > Slow 18.6–1.52 Hz 224–224 STROBE 0-100-0% · Slow 0.1 Hz 225–229 Shutter Open 230–230 RANDOM PULSE STROBE 1 · Fast 20 Hz 231–243 RANDOM PULSE STROBE 1 · Fast > Slow 18.6–1.52 … 244–244 RANDOM PULSE STROBE 1 · Slow 0.1 Hz 245–255 Shutter Open
6	Zoom	127	0–0 Wide 1–254 Wide > Narrow 255–255 Narrow
7	Zoom	127	0–0 Narrow 1–254 Narrow > Wide 255–255 Wide

Dual Control Movement: Basic 8ch (continued)

Ch	Function	Default	DMX values
8	Control1	0	0–9 No Function 10–14 Blackout On Tilt 15–19 Reserved 20–24 RGBW Color Mixing Mode 25–29 CMY Color Mixing Mode 30–39 Reserved 40–44 Defrost Fan On 45–49 Defrost Fan Off 50–54 Reserved 55–59 Tilt Reset 60–64 Zoom Reset 65–69 Reserved 70–74 Reset All 75–75 PWM 600Hz 76–76 PWM 1200Hz 77–77 PWM 2000Hz 78–78 PWM 4000Hz 79–79 PWM 6000Hz 80–80 PWM 15000Hz 81–81 Reserved 82–84 Cell Order 1-16 85–89 Cell Order 16-1 90–94 Tilt Reverse 95–99 Reserved 100–104 Tilt Reverse Disable 105–119 Reserved 120–124 Fan ECO 125–129 Fan Full 130–134 Fan Auto 135–139 Dimmer Fast 140–144 Dimmer Smooth 145–149 Linear 150–154 Square 155–159 Inverse Square 160–164 S Square 165–169 White Mode 170–174 Full Mode 175–239 Color Macros HTP On 240–247 Color Macros HTP Off 248–255 Reserved

Single Control: Basic2 Mode 19ch

19 channels

Ch	Function	Default	DMX values
1	Tilt	127	0–126 Min 127–254 Home 255–255 Max
2	Tilt Fine	255	Fine byte of Tilt
3	Position MSpeed	0	0–0 Min 1–254 Min > Max 255–255 Max
4	C TC	0	

Single Control: Basic2 Mode 19ch (continued)

Ch	Function	Default	DMX values
5	Color Macro1	0	0–0 Open (wheel slot 1) 1–2 White 2700K - CTC (wheel slot 1) 3–4 White 3200K - CTC (wheel slot 2) 5–6 White 4200K - CTC (wheel slot 3) 7–8 White 5600K - CTC (wheel slot 4) 9–10 White 8000K - CTC (wheel slot 5) 11–11 Blue (wheel slot 6) 12–48 +Green (wheel slot 7) 49–49 Cyan (wheel slot 8) 50–86 -Blue (wheel slot 9) 87–87 Green (wheel slot 10) 88–124 +Red (wheel slot 11) 125–125 Yellow (wheel slot 12) 126–162 -Green (wheel slot 13) 163–163 Red (wheel slot 14) 164–200 +Blue (wheel slot 15) 201–201 Magenta (wheel slot 16) 202–238 -Red (wheel slot 17) 239–239 Blue (wheel slot 7) 240–240 Fast 241–246 Fast > Slow 247–247 Slow 248–248 Fast 249–254 Fast > Slow 255–255 Slow

Single Control: Basic2 Mode 19ch (continued)

Ch	Function	Default	DMX values
6	Effect	0	0–0 Open 1–1 Pattern 1 - Macro 2–2 Pattern 2 - Macro 3–3 Pattern 3 - Macro 4–4 Pattern 4 - Macro 5–5 Pattern 5 - Macro 6–6 Pattern 6 - Macro 7–7 Pattern 7 - Macro 8–8 Pattern 8 - Macro 9–9 Pattern 9 - Macro 10–10 Pattern 10 - Macro 11–11 Pattern 11 - Macro 12–12 Pattern 12 - Macro 13–13 Pattern 13 - Macro 14–14 Pattern 14 - Macro 15–15 Pattern 15 - Macro 16–16 Pattern 16 - Macro 17–17 Pattern 17 - Macro 18–18 Pattern 18 - Macro 19–19 Pattern 19 - Macro 20–20 Pattern 20 - Macro 21–21 Pattern 21 - Macro 22–22 Pattern 22 - Macro 23–23 Pattern 23 - Macro 24–24 Pattern 24 - Macro 25–25 Pattern 25 - Macro 26–26 Pattern 26 - Macro 27–27 Pattern 27 - Macro 28–28 Pattern 28 - Macro 29–29 Pattern 29 - Macro 30–30 Pattern 30 - Macro 31–31 Pattern 31 - Macro 32–32 Pattern 32 - Macro 33–33 Pattern 33 - Macro 34–34 Pattern 34 - Macro 35–35 Pattern 35 - Macro 36–36 Pattern 36 - Macro 37–37 Pattern 37 - Macro 38–38 Pattern 38 - Macro 39–39 Pattern 39 - Macro 40–40 Pattern 40 - Macro 41–41 Pattern 41 - Macro 42–42 Pattern 42 - Macro 43–43 Pattern 43 - Macro 44–44 Pattern 44 - Macro 45–45 Pattern 45 - Macro 46–46 Pattern 46 - Macro 47–47 Pattern 47 - Macro 48–48 Pattern 48 - Macro 49–49 Pattern 49 - Macro 50–50 Pattern 50 - Macro 51–51 Pattern 51 - Macro 52–52 Pattern 52 - Macro 53–53 Pattern 53 - Macro 54–54 Pattern 54 - Macro 55–55 Pattern 55 - Macro 56–56 Pattern 56 - Macro 57–57 Pattern 57 - Macro 58–58 Pattern 58 - Macro 59–59 Pattern 59 - Macro 60–60 Pattern 60 - Macro 61–61 Pattern 61 - Macro 62–62 Pattern 62 - Macro 63–63 Pattern 63 - Macro

Single Control: Basic2 Mode 19ch (continued)

Ch	Function	Default	DMX values
7	Effect 2	0	0–15 LED Built-In Open 16–17 LED Built-In 1 - Macro 18–19 LED Built-In 2 - Macro 20–21 LED Built-In 3 - Macro 22–23 LED Built-In 4 - Macro 24–25 LED Built-In 5 - Macro 26–27 LED Built-In 6 - Macro 28–29 LED Built-In 7 - Macro 30–31 LED Built-In 8 - Macro 32–33 LED Built-In 9 - Macro 34–35 LED Built-In 10 - Macro 36–37 LED Built-In 11 - Macro 38–39 LED Built-In 12 - Macro 40–41 LED Built-In 13 - Macro 42–43 LED Built-In 14 - Macro 44–45 LED Built-In 15 - Macro 46–47 LED Built-In 16 - Macro 48–49 LED Built-In 17 - Macro 50–51 LED Built-In 18 - Macro 52–53 LED Built-In 19 - Macro 54–55 LED Built-In 20 - Macro 56–57 LED Built-In 21 - Macro 58–59 LED Built-In 22 - Macro 60–61 LED Built-In 23 - Macro 62–63 LED Built-In 24 - Macro 64–65 LED Built-In 25 - Macro 66–67 LED Built-In 26 - Macro 68–69 LED Built-In 27 - Macro 70–71 LED Built-In 28 - Macro 72–73 LED Built-In 29 - Macro 74–75 LED Built-In 30 - Macro 76–77 LED Built-In 31 - Macro 78–79 LED Built-In 32 - Macro 80–81 LED Built-In 33 - Macro 82–83 LED Built-In 34 - Macro 84–85 LED Built-In 35 - Macro 86–87 LED Built-In 36 - Macro 88–89 LED Built-In 37 - Macro 90–91 LED Built-In 38 - Macro 92–93 LED Built-In 39 - Macro 94–95 LED Built-In 40 - Macro 96–97 LED Built-In 41 - Macro 98–99 LED Built-In 42 - Macro 100–101 LED Built-In 43 - Macro 102–103 LED Built-In 44 - Macro 104–105 LED Built-In 45 - Macro 106–107 LED Built-In 46 - Macro 108–109 LED Built-In 47 - Macro 110–111 LED Built-In 48 - Macro 112–113 LED Built-In 49 - Macro 114–115 LED Built-In 50 - Macro 116–117 LED Built-In 51 - Macro 118–119 LED Built-In 52 - Macro 120–121 LED Built-In 53 - Macro 122–123 LED Built-In 54 - Macro 124–125 LED Built-In 55 - Macro 126–127 LED Built-In 56 - Macro 128–129 LED Built-In 57 - Macro 130–131 LED Built-In 58 - Macro 132–133 LED Built-In 59 - Macro 134–135 LED Built-In 60 - Macro 136–137 LED Built-In 61 - Macro 138–139 LED Built-In 62 - Macro 140–141 LED Built-In 63 - Macro

Single Control: Basic2 Mode 19ch (continued)

Ch	Function	Default	DMX values
8	Effect Speed 2	128	0–127 Fast > Slow 128–128 Stop 129–255 Slow > Fast
9	Effects2Adjust1	0	0–0 Min 1–254 Min > Max 255–255 Max
10	Color Macro2	0	0–0 Open 1–2 White 2700K - CTC (wheel slot 1) 3–4 White 3200K - CTC (wheel slot 2) 5–6 White 4200K - CTC (wheel slot 3) 7–8 White 5600K - CTC (wheel slot 4) 9–10 White 8000K - CTC (wheel slot 5) 11–11 Blue (wheel slot 6) 12–48 +Green (wheel slot 7) 49–49 Cyan (wheel slot 8) 50–86 -Blue (wheel slot 9) 87–87 Green (wheel slot 10) 88–124 +Red (wheel slot 11) 125–125 Yellow (wheel slot 12) 126–162 -Green (wheel slot 13) 163–163 Red (wheel slot 14) 164–200 +Blue (wheel slot 15) 201–201 Magenta (wheel slot 16) 202–238 -Red (wheel slot 17) 239–239 Blue (wheel slot 7) 240–240 Fast 241–246 Fast > Slow 247–247 Slow 248–248 Fast 249–254 Fast > Slow 255–255 Slow
11	Background Dimmer	0	0–0 Min 1–254 Min > Max 255–255 Max
12	Dimmer	0	0–0 Min 1–254 Min > Max 255–255 Max

Single Control: Basic2 Mode 19ch (continued)

Ch	Function	Default	DMX values
13	Shutter / Strobe	22	0–19 Shutter Closed 20–24 Shutter Open 25–25 STROBE · Fast 20 Hz 26–63 STROBE · Fast > Slow 19.5–0.61 Hz 64–64 STROBE · Slow 0.1 Hz 65–69 Shutter Open 70–70 STROBE 100-0% · Fast 20 Hz 71–83 STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 84–84 STROBE 100-0% · Slow 0.1 Hz 85–89 Shutter Open 90–90 STROBE 0-100% · Fast 20 Hz 91–103 STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 104–104 STROBE 0-100% · Slow 0.1 Hz 105–109 Shutter Open 110–110 RANDOM STROBE · Fast 20 Hz 111–123 RANDOM STROBE · Fast > Slow 18.6–1.52 Hz 124–124 RANDOM STROBE · Slow 0.1 Hz 125–129 Shutter Open 130–130 RANDOM STROBE 100-0% · Fast 20 Hz 131–143 RANDOM STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 144–144 RANDOM STROBE 100-0% · Slow 0.1 Hz 145–149 Shutter Open 150–150 RANDOM STROBE 0-100% · Fast 20 Hz 151–163 RANDOM STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 164–164 RANDOM STROBE 0-100% · Slow 0.1 Hz 165–169 Shutter Open 170–170 PULSE STROBE · Fast 20 Hz 171–183 PULSE STROBE · Fast > Slow 18.6–1.52 Hz 184–184 PULSE STROBE · Slow 0.1 Hz 185–189 Shutter Open 190–190 RANDOM PULSE STROBE · Fast 20 Hz 191–203 RANDOM PULSE STROBE · Fast > Slow 18.6–1.52 Hz 204–204 RANDOM PULSE STROBE · Slow 0.1 Hz 205–209 Shutter Open 210–210 STROBE 0-100-0% · Fast 20 Hz 211–223 STROBE 0-100-0% · Fast > Slow 18.6–1.52 Hz 224–224 STROBE 0-100-0% · Slow 0.1 Hz 225–229 Shutter Open 230–230 RANDOM PULSE STROBE 1 · Fast 20 Hz 231–243 RANDOM PULSE STROBE 1 · Fast > Slow 18.6–1.52 … 244–244 RANDOM PULSE STROBE 1 · Slow 0.1 Hz 245–255 Shutter Open
14	Zoom	127	0–0 Wide 1–254 Wide > Narrow 255–255 Narrow

Single Control: Basic2 Mode 19ch (continued)

Ch	Function	Default	DMX values
15	Control1	0	0–9 No Function 10–14 Blackout On Tilt 15–19 Reserved 20–24 RGBW Color Mixing Mode 25–29 CMY Color Mixing Mode 30–39 Reserved 40–44 Defrost Fan On 45–49 Defrost Fan Off 50–54 Reserved 55–59 Tilt Reset 60–64 Zoom Reset 65–69 Reserved 70–74 Reset All 75–75 PWM 600Hz 76–76 PWM 1200Hz 77–77 PWM 2000Hz 78–78 PWM 4000Hz 79–79 PWM 6000Hz 80–80 PWM 15000Hz 81–81 Reserved 82–84 Cell Order 1-16 85–89 Cell Order 16-1 90–94 Tilt Reverse 95–99 Reserved 100–104 Tilt Reverse Disable 105–119 Reserved 120–124 Fan ECO 125–129 Fan Full 130–134 Fan Auto 135–139 Dimmer Fast 140–144 Dimmer Smooth 145–149 Linear 150–154 Square 155–159 Inverse Square 160–164 S Square 165–169 White Mode 170–174 Full Mode 175–239 Color Macros HTP On 240–247 Color Macros HTP Off 248–255 Reserved
16	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
17	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
18	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
19	White	255	0–0 Min 1–254 Min > Max 255–255 Max

Dual Control Movement: Standard 20ch

20 channels

Ch	Function	Default	DMX values
1	Tilt	127	0–126 Min 127–254 Home 255–255 Max

Dual Control Movement: Standard 20ch (continued)

Ch	Function	Default	DMX values
2	Tilt Fine	255	Fine byte of Tilt
3	Position MSpeed	0	0–0 Min 1–254 Min > Max 255–255 Max
4	C TC	0	
5	Color Macro1	0	0–0 Open (wheel slot 1) 1–2 White 2700K - CTC (wheel slot 1) 3–4 White 3200K - CTC (wheel slot 2) 5–6 White 4200K - CTC (wheel slot 3) 7–8 White 5600K - CTC (wheel slot 4) 9–10 White 8000K - CTC (wheel slot 5) 11–11 Blue (wheel slot 6) 12–48 +Green (wheel slot 7) 49–49 Cyan (wheel slot 8) 50–86 -Blue (wheel slot 9) 87–87 Green (wheel slot 10) 88–124 +Red (wheel slot 11) 125–125 Yellow (wheel slot 12) 126–162 -Green (wheel slot 13) 163–163 Red (wheel slot 14) 164–200 +Blue (wheel slot 15) 201–201 Magenta (wheel slot 16) 202–238 -Red (wheel slot 17) 239–239 Blue (wheel slot 7) 240–240 Fast 241–246 Fast > Slow 247–247 Slow 248–248 Fast 249–254 Fast > Slow 255–255 Slow

Dual Control Movement: Standard 20ch (continued)

Ch	Function	Default	DMX values
6	Effect	0	0–0 Open 1–1 Pattern 1 - Macro 2–2 Pattern 2 - Macro 3–3 Pattern 3 - Macro 4–4 Pattern 4 - Macro 5–5 Pattern 5 - Macro 6–6 Pattern 6 - Macro 7–7 Pattern 7 - Macro 8–8 Pattern 8 - Macro 9–9 Pattern 9 - Macro 10–10 Pattern 10 - Macro 11–11 Pattern 11 - Macro 12–12 Pattern 12 - Macro 13–13 Pattern 13 - Macro 14–14 Pattern 14 - Macro 15–15 Pattern 15 - Macro 16–16 Pattern 16 - Macro 17–17 Pattern 17 - Macro 18–18 Pattern 18 - Macro 19–19 Pattern 19 - Macro 20–20 Pattern 20 - Macro 21–21 Pattern 21 - Macro 22–22 Pattern 22 - Macro 23–23 Pattern 23 - Macro 24–24 Pattern 24 - Macro 25–25 Pattern 25 - Macro 26–26 Pattern 26 - Macro 27–27 Pattern 27 - Macro 28–28 Pattern 28 - Macro 29–29 Pattern 29 - Macro 30–30 Pattern 30 - Macro 31–31 Pattern 31 - Macro 32–32 Pattern 32 - Macro 33–33 Pattern 33 - Macro 34–34 Pattern 34 - Macro 35–35 Pattern 35 - Macro 36–36 Pattern 36 - Macro 37–37 Pattern 37 - Macro 38–38 Pattern 38 - Macro 39–39 Pattern 39 - Macro 40–40 Pattern 40 - Macro 41–41 Pattern 41 - Macro 42–42 Pattern 42 - Macro 43–43 Pattern 43 - Macro 44–44 Pattern 44 - Macro 45–45 Pattern 45 - Macro 46–46 Pattern 46 - Macro 47–47 Pattern 47 - Macro 48–48 Pattern 48 - Macro 49–49 Pattern 49 - Macro 50–50 Pattern 50 - Macro 51–51 Pattern 51 - Macro 52–52 Pattern 52 - Macro 53–53 Pattern 53 - Macro 54–54 Pattern 54 - Macro 55–55 Pattern 55 - Macro 56–56 Pattern 56 - Macro 57–57 Pattern 57 - Macro 58–58 Pattern 58 - Macro 59–59 Pattern 59 - Macro 60–60 Pattern 60 - Macro 61–61 Pattern 61 - Macro 62–62 Pattern 62 - Macro 63–63 Pattern 63 - Macro

Dual Control Movement: Standard 20ch (continued)

Ch	Function	Default	DMX values
7	Effect 2	0	0–15 LED Built-In Open 16–17 LED Built-In 1 - Macro 18–19 LED Built-In 2 - Macro 20–21 LED Built-In 3 - Macro 22–23 LED Built-In 4 - Macro 24–25 LED Built-In 5 - Macro 26–27 LED Built-In 6 - Macro 28–29 LED Built-In 7 - Macro 30–31 LED Built-In 8 - Macro 32–33 LED Built-In 9 - Macro 34–35 LED Built-In 10 - Macro 36–37 LED Built-In 11 - Macro 38–39 LED Built-In 12 - Macro 40–41 LED Built-In 13 - Macro 42–43 LED Built-In 14 - Macro 44–45 LED Built-In 15 - Macro 46–47 LED Built-In 16 - Macro 48–49 LED Built-In 17 - Macro 50–51 LED Built-In 18 - Macro 52–53 LED Built-In 19 - Macro 54–55 LED Built-In 20 - Macro 56–57 LED Built-In 21 - Macro 58–59 LED Built-In 22 - Macro 60–61 LED Built-In 23 - Macro 62–63 LED Built-In 24 - Macro 64–65 LED Built-In 25 - Macro 66–67 LED Built-In 26 - Macro 68–69 LED Built-In 27 - Macro 70–71 LED Built-In 28 - Macro 72–73 LED Built-In 29 - Macro 74–75 LED Built-In 30 - Macro 76–77 LED Built-In 31 - Macro 78–79 LED Built-In 32 - Macro 80–81 LED Built-In 33 - Macro 82–83 LED Built-In 34 - Macro 84–85 LED Built-In 35 - Macro 86–87 LED Built-In 36 - Macro 88–89 LED Built-In 37 - Macro 90–91 LED Built-In 38 - Macro 92–93 LED Built-In 39 - Macro 94–95 LED Built-In 40 - Macro 96–97 LED Built-In 41 - Macro 98–99 LED Built-In 42 - Macro 100–101 LED Built-In 43 - Macro 102–103 LED Built-In 44 - Macro 104–105 LED Built-In 45 - Macro 106–107 LED Built-In 46 - Macro 108–109 LED Built-In 47 - Macro 110–111 LED Built-In 48 - Macro 112–113 LED Built-In 49 - Macro 114–115 LED Built-In 50 - Macro 116–117 LED Built-In 51 - Macro 118–119 LED Built-In 52 - Macro 120–121 LED Built-In 53 - Macro 122–123 LED Built-In 54 - Macro 124–125 LED Built-In 55 - Macro 126–127 LED Built-In 56 - Macro 128–129 LED Built-In 57 - Macro 130–131 LED Built-In 58 - Macro 132–133 LED Built-In 59 - Macro 134–135 LED Built-In 60 - Macro 136–137 LED Built-In 61 - Macro 138–139 LED Built-In 62 - Macro 140–141 LED Built-In 63 - Macro

Dual Control Movement: Standard 20ch (continued)

Ch	Function	Default	DMX values
8	Effect Speed 2	128	0–127 Fast > Slow 128–128 Stop 129–255 Slow > Fast
9	Effects2Adjust1	0	0–0 Min 1–254 Min > Max 255–255 Max
10	Color Macro2	0	0–0 Open 1–2 White 2700K - CTC (wheel slot 1) 3–4 White 3200K - CTC (wheel slot 2) 5–6 White 4200K - CTC (wheel slot 3) 7–8 White 5600K - CTC (wheel slot 4) 9–10 White 8000K - CTC (wheel slot 5) 11–11 Blue (wheel slot 6) 12–48 +Green (wheel slot 7) 49–49 Cyan (wheel slot 8) 50–86 -Blue (wheel slot 9) 87–87 Green (wheel slot 10) 88–124 +Red (wheel slot 11) 125–125 Yellow (wheel slot 12) 126–162 -Green (wheel slot 13) 163–163 Red (wheel slot 14) 164–200 +Blue (wheel slot 15) 201–201 Magenta (wheel slot 16) 202–238 -Red (wheel slot 17) 239–239 Blue (wheel slot 7) 240–240 Fast 241–246 Fast > Slow 247–247 Slow 248–248 Fast 249–254 Fast > Slow 255–255 Slow
11	Background Dimmer	0	0–0 Min 1–254 Min > Max 255–255 Max
12	Dimmer	0	0–0 Min 1–254 Min > Max 255–255 Max

Dual Control Movement: Standard 20ch (continued)

Ch	Function	Default	DMX values
13	Shutter / Strobe	22	0–19 Shutter Closed 20–24 Shutter Open 25–25 STROBE · Fast 20 Hz 26–63 STROBE · Fast > Slow 19.5–0.61 Hz 64–64 STROBE · Slow 0.1 Hz 65–69 Shutter Open 70–70 STROBE 100-0% · Fast 20 Hz 71–83 STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 84–84 STROBE 100-0% · Slow 0.1 Hz 85–89 Shutter Open 90–90 STROBE 0-100% · Fast 20 Hz 91–103 STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 104–104 STROBE 0-100% · Slow 0.1 Hz 105–109 Shutter Open 110–110 RANDOM STROBE · Fast 20 Hz 111–123 RANDOM STROBE · Fast > Slow 18.6–1.52 Hz 124–124 RANDOM STROBE · Slow 0.1 Hz 125–129 Shutter Open 130–130 RANDOM STROBE 100-0% · Fast 20 Hz 131–143 RANDOM STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 144–144 RANDOM STROBE 100-0% · Slow 0.1 Hz 145–149 Shutter Open 150–150 RANDOM STROBE 0-100% · Fast 20 Hz 151–163 RANDOM STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 164–164 RANDOM STROBE 0-100% · Slow 0.1 Hz 165–169 Shutter Open 170–170 PULSE STROBE · Fast 20 Hz 171–183 PULSE STROBE · Fast > Slow 18.6–1.52 Hz 184–184 PULSE STROBE · Slow 0.1 Hz 185–189 Shutter Open 190–190 RANDOM PULSE STROBE · Fast 20 Hz 191–203 RANDOM PULSE STROBE · Fast > Slow 18.6–1.52 Hz 204–204 RANDOM PULSE STROBE · Slow 0.1 Hz 205–209 Shutter Open 210–210 STROBE 0-100-0% · Fast 20 Hz 211–223 STROBE 0-100-0% · Fast > Slow 18.6–1.52 Hz 224–224 STROBE 0-100-0% · Slow 0.1 Hz 225–229 Shutter Open 230–230 RANDOM PULSE STROBE 1 · Fast 20 Hz 231–243 RANDOM PULSE STROBE 1 · Fast > Slow 18.6–1.52 … 244–244 RANDOM PULSE STROBE 1 · Slow 0.1 Hz 245–255 Shutter Open
14	Zoom	127	0–0 Wide 1–254 Wide > Narrow 255–255 Narrow
15	Zoom	127	0–0 Wide 1–254 Wide > Narrow 255–255 Narrow

Dual Control Movement: Standard 20ch (continued)

Ch	Function	Default	DMX values
16	Control1	0	0–9 No Function 10–14 Blackout On Tilt 15–19 Reserved 20–24 RGBW Color Mixing Mode 25–29 CMY Color Mixing Mode 30–39 Reserved 40–44 Defrost Fan On 45–49 Defrost Fan Off 50–54 Reserved 55–59 Tilt Reset 60–64 Zoom Reset 65–69 Reserved 70–74 Reset All 75–75 PWM 600Hz 76–76 PWM 1200Hz 77–77 PWM 2000Hz 78–78 PWM 4000Hz 79–79 PWM 6000Hz 80–80 PWM 15000Hz 81–81 Reserved 82–84 Cell Order 1-16 85–89 Cell Order 16-1 90–94 Tilt Reverse 95–99 Reserved 100–104 Tilt Reverse Disable 105–119 Reserved 120–124 Fan ECO 125–129 Fan Full 130–134 Fan Auto 135–139 Dimmer Fast 140–144 Dimmer Smooth 145–149 Linear 150–154 Square 155–159 Inverse Square 160–164 S Square 165–169 White Mode 170–174 Full Mode 175–239 Color Macros HTP On 240–247 Color Macros HTP Off 248–255 Reserved
17	R Overwrite	0	0–0 Min 1–254 Min > Max 255–255 Max
18	G Overwrite	0	0–0 Min 1–254 Min > Max 255–255 Max
19	B Overwrite	0	0–0 Min 1–254 Min > Max 255–255 Max
20	W Overwrite	0	0–0 Min 1–254 Min > Max 255–255 Max

Single Control: Basic Mode 20ch

20 channels

Ch	Function	Default	DMX values
1	Tilt	127	0–126 Min 127–254 Home 255–255 Max

Single Control: Basic Mode 20ch (continued)

Ch	Function	Default	DMX values
2	Tilt Fine	255	Fine byte of Tilt
3	Position MSpeed	0	0–0 Min 1–254 Min > Max 255–255 Max
4	C TC	0	
5	Color Macro1	0	0–0 Open (wheel slot 1) 1–2 White 2700K - CTC (wheel slot 1) 3–4 White 3200K - CTC (wheel slot 2) 5–6 White 4200K - CTC (wheel slot 3) 7–8 White 5600K - CTC (wheel slot 4) 9–10 White 8000K - CTC (wheel slot 5) 11–11 Blue (wheel slot 6) 12–48 +Green (wheel slot 7) 49–49 Cyan (wheel slot 8) 50–86 -Blue (wheel slot 9) 87–87 Green (wheel slot 10) 88–124 +Red (wheel slot 11) 125–125 Yellow (wheel slot 12) 126–162 -Green (wheel slot 13) 163–163 Red (wheel slot 14) 164–200 +Blue (wheel slot 15) 201–201 Magenta (wheel slot 16) 202–238 -Red (wheel slot 17) 239–239 Blue (wheel slot 7) 240–240 Fast 241–246 Fast > Slow 247–247 Slow 248–248 Fast 249–254 Fast > Slow 255–255 Slow

Single Control: Basic Mode 20ch (continued)

Ch	Function	Default	DMX values
6	Effect	0	0–0 Open 1–1 Pattern 1 - Macro 2–2 Pattern 2 - Macro 3–3 Pattern 3 - Macro 4–4 Pattern 4 - Macro 5–5 Pattern 5 - Macro 6–6 Pattern 6 - Macro 7–7 Pattern 7 - Macro 8–8 Pattern 8 - Macro 9–9 Pattern 9 - Macro 10–10 Pattern 10 - Macro 11–11 Pattern 11 - Macro 12–12 Pattern 12 - Macro 13–13 Pattern 13 - Macro 14–14 Pattern 14 - Macro 15–15 Pattern 15 - Macro 16–16 Pattern 16 - Macro 17–17 Pattern 17 - Macro 18–18 Pattern 18 - Macro 19–19 Pattern 19 - Macro 20–20 Pattern 20 - Macro 21–21 Pattern 21 - Macro 22–22 Pattern 22 - Macro 23–23 Pattern 23 - Macro 24–24 Pattern 24 - Macro 25–25 Pattern 25 - Macro 26–26 Pattern 26 - Macro 27–27 Pattern 27 - Macro 28–28 Pattern 28 - Macro 29–29 Pattern 29 - Macro 30–30 Pattern 30 - Macro 31–31 Pattern 31 - Macro 32–32 Pattern 32 - Macro 33–33 Pattern 33 - Macro 34–34 Pattern 34 - Macro 35–35 Pattern 35 - Macro 36–36 Pattern 36 - Macro 37–37 Pattern 37 - Macro 38–38 Pattern 38 - Macro 39–39 Pattern 39 - Macro 40–40 Pattern 40 - Macro 41–41 Pattern 41 - Macro 42–42 Pattern 42 - Macro 43–43 Pattern 43 - Macro 44–44 Pattern 44 - Macro 45–45 Pattern 45 - Macro 46–46 Pattern 46 - Macro 47–47 Pattern 47 - Macro 48–48 Pattern 48 - Macro 49–49 Pattern 49 - Macro 50–50 Pattern 50 - Macro 51–51 Pattern 51 - Macro 52–52 Pattern 52 - Macro 53–53 Pattern 53 - Macro 54–54 Pattern 54 - Macro 55–55 Pattern 55 - Macro 56–56 Pattern 56 - Macro 57–57 Pattern 57 - Macro 58–58 Pattern 58 - Macro 59–59 Pattern 59 - Macro 60–60 Pattern 60 - Macro 61–61 Pattern 61 - Macro 62–62 Pattern 62 - Macro 63–63 Pattern 63 - Macro

Single Control: Basic Mode 20ch (continued)

Ch	Function	Default	DMX values
7	Effect 2	0	0–15 LED Built-In Open 16–17 LED Built-In 1 - Macro 18–19 LED Built-In 2 - Macro 20–21 LED Built-In 3 - Macro 22–23 LED Built-In 4 - Macro 24–25 LED Built-In 5 - Macro 26–27 LED Built-In 6 - Macro 28–29 LED Built-In 7 - Macro 30–31 LED Built-In 8 - Macro 32–33 LED Built-In 9 - Macro 34–35 LED Built-In 10 - Macro 36–37 LED Built-In 11 - Macro 38–39 LED Built-In 12 - Macro 40–41 LED Built-In 13 - Macro 42–43 LED Built-In 14 - Macro 44–45 LED Built-In 15 - Macro 46–47 LED Built-In 16 - Macro 48–49 LED Built-In 17 - Macro 50–51 LED Built-In 18 - Macro 52–53 LED Built-In 19 - Macro 54–55 LED Built-In 20 - Macro 56–57 LED Built-In 21 - Macro 58–59 LED Built-In 22 - Macro 60–61 LED Built-In 23 - Macro 62–63 LED Built-In 24 - Macro 64–65 LED Built-In 25 - Macro 66–67 LED Built-In 26 - Macro 68–69 LED Built-In 27 - Macro 70–71 LED Built-In 28 - Macro 72–73 LED Built-In 29 - Macro 74–75 LED Built-In 30 - Macro 76–77 LED Built-In 31 - Macro 78–79 LED Built-In 32 - Macro 80–81 LED Built-In 33 - Macro 82–83 LED Built-In 34 - Macro 84–85 LED Built-In 35 - Macro 86–87 LED Built-In 36 - Macro 88–89 LED Built-In 37 - Macro 90–91 LED Built-In 38 - Macro 92–93 LED Built-In 39 - Macro 94–95 LED Built-In 40 - Macro 96–97 LED Built-In 41 - Macro 98–99 LED Built-In 42 - Macro 100–101 LED Built-In 43 - Macro 102–103 LED Built-In 44 - Macro 104–105 LED Built-In 45 - Macro 106–107 LED Built-In 46 - Macro 108–109 LED Built-In 47 - Macro 110–111 LED Built-In 48 - Macro 112–113 LED Built-In 49 - Macro 114–115 LED Built-In 50 - Macro 116–117 LED Built-In 51 - Macro 118–119 LED Built-In 52 - Macro 120–121 LED Built-In 53 - Macro 122–123 LED Built-In 54 - Macro 124–125 LED Built-In 55 - Macro 126–127 LED Built-In 56 - Macro 128–129 LED Built-In 57 - Macro 130–131 LED Built-In 58 - Macro 132–133 LED Built-In 59 - Macro 134–135 LED Built-In 60 - Macro 136–137 LED Built-In 61 - Macro 138–139 LED Built-In 62 - Macro 140–141 LED Built-In 63 - Macro

Single Control: Basic Mode 20ch (continued)

Ch	Function	Default	DMX values
8	Effect Speed 2	128	0–127 Fast > Slow 128–128 Stop 129–255 Slow > Fast
9	Effects2Adjust1	0	0–0 Min 1–254 Min > Max 255–255 Max
10	Color Macro2	0	0–0 Open 1–2 White 2700K - CTC (wheel slot 1) 3–4 White 3200K - CTC (wheel slot 2) 5–6 White 4200K - CTC (wheel slot 3) 7–8 White 5600K - CTC (wheel slot 4) 9–10 White 8000K - CTC (wheel slot 5) 11–11 Blue (wheel slot 6) 12–48 +Green (wheel slot 7) 49–49 Cyan (wheel slot 8) 50–86 -Blue (wheel slot 9) 87–87 Green (wheel slot 10) 88–124 +Red (wheel slot 11) 125–125 Yellow (wheel slot 12) 126–162 -Green (wheel slot 13) 163–163 Red (wheel slot 14) 164–200 +Blue (wheel slot 15) 201–201 Magenta (wheel slot 16) 202–238 -Red (wheel slot 17) 239–239 Blue (wheel slot 7) 240–240 Fast 241–246 Fast > Slow 247–247 Slow 248–248 Fast 249–254 Fast > Slow 255–255 Slow
11	Background Dimmer	0	0–0 Min 1–254 Min > Max 255–255 Max
12	Dimmer	0	0–0 Min 1–254 Min > Max 255–255 Max

Single Control: Basic Mode 20ch (continued)

Ch	Function	Default	DMX values
13	Shutter / Strobe	22	0–19 Shutter Closed 20–24 Shutter Open 25–25 STROBE · Fast 20 Hz 26–63 STROBE · Fast > Slow 19.5–0.61 Hz 64–64 STROBE · Slow 0.1 Hz 65–69 Shutter Open 70–70 STROBE 100-0% · Fast 20 Hz 71–83 STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 84–84 STROBE 100-0% · Slow 0.1 Hz 85–89 Shutter Open 90–90 STROBE 0-100% · Fast 20 Hz 91–103 STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 104–104 STROBE 0-100% · Slow 0.1 Hz 105–109 Shutter Open 110–110 RANDOM STROBE · Fast 20 Hz 111–123 RANDOM STROBE · Fast > Slow 18.6–1.52 Hz 124–124 RANDOM STROBE · Slow 0.1 Hz 125–129 Shutter Open 130–130 RANDOM STROBE 100-0% · Fast 20 Hz 131–143 RANDOM STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 144–144 RANDOM STROBE 100-0% · Slow 0.1 Hz 145–149 Shutter Open 150–150 RANDOM STROBE 0-100% · Fast 20 Hz 151–163 RANDOM STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 164–164 RANDOM STROBE 0-100% · Slow 0.1 Hz 165–169 Shutter Open 170–170 PULSE STROBE · Fast 20 Hz 171–183 PULSE STROBE · Fast > Slow 18.6–1.52 Hz 184–184 PULSE STROBE · Slow 0.1 Hz 185–189 Shutter Open 190–190 RANDOM PULSE STROBE · Fast 20 Hz 191–203 RANDOM PULSE STROBE · Fast > Slow 18.6–1.52 Hz 204–204 RANDOM PULSE STROBE · Slow 0.1 Hz 205–209 Shutter Open 210–210 STROBE 0-100-0% · Fast 20 Hz 211–223 STROBE 0-100-0% · Fast > Slow 18.6–1.52 Hz 224–224 STROBE 0-100-0% · Slow 0.1 Hz 225–229 Shutter Open 230–230 RANDOM PULSE STROBE 1 · Fast 20 Hz 231–243 RANDOM PULSE STROBE 1 · Fast > Slow 18.6–1.52 … 244–244 RANDOM PULSE STROBE 1 · Slow 0.1 Hz 245–255 Shutter Open
14	Zoom	127	0–0 Wide 1–254 Wide > Narrow 255–255 Narrow
15	Zoom	127	0–0 Wide 1–254 Wide > Narrow 255–255 Narrow

Single Control: Basic Mode 20ch (continued)

Ch	Function	Default	DMX values
16	Control1	0	0–9 No Function 10–14 Blackout On Tilt 15–19 Reserved 20–24 RGBW Color Mixing Mode 25–29 CMY Color Mixing Mode 30–39 Reserved 40–44 Defrost Fan On 45–49 Defrost Fan Off 50–54 Reserved 55–59 Tilt Reset 60–64 Zoom Reset 65–69 Reserved 70–74 Reset All 75–75 PWM 600Hz 76–76 PWM 1200Hz 77–77 PWM 2000Hz 78–78 PWM 4000Hz 79–79 PWM 6000Hz 80–80 PWM 15000Hz 81–81 Reserved 82–84 Cell Order 1-16 85–89 Cell Order 16-1 90–94 Tilt Reverse 95–99 Reserved 100–104 Tilt Reverse Disable 105–119 Reserved 120–124 Fan ECO 125–129 Fan Full 130–134 Fan Auto 135–139 Dimmer Fast 140–144 Dimmer Smooth 145–149 Linear 150–154 Square 155–159 Inverse Square 160–164 S Square 165–169 White Mode 170–174 Full Mode 175–239 Color Macros HTP On 240–247 Color Macros HTP Off 248–255 Reserved
17	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
18	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
19	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
20	White	255	0–0 Min 1–254 Min > Max 255–255 Max

Dual Control Movement: Advanced 26ch

26 channels

Ch	Function	Default	DMX values
1	Tilt	127	0–126 Min 127–254 Home 255–255 Max

Dual Control Movement: Advanced 26ch (continued)

Ch	Function	Default	DMX values
2	Tilt Fine	255	Fine byte of Tilt
3	Position MSpeed	0	0–0 Min 1–254 Min > Max 255–255 Max
4	C TC	0	
5	Color Macro1	0	0–0 Open (wheel slot 1) 1–2 White 2700K - CTC (wheel slot 1) 3–4 White 3200K - CTC (wheel slot 2) 5–6 White 4200K - CTC (wheel slot 3) 7–8 White 5600K - CTC (wheel slot 4) 9–10 White 8000K - CTC (wheel slot 5) 11–11 Blue (wheel slot 6) 12–48 +Green (wheel slot 7) 49–49 Cyan (wheel slot 8) 50–86 -Blue (wheel slot 9) 87–87 Green (wheel slot 10) 88–124 +Red (wheel slot 11) 125–125 Yellow (wheel slot 12) 126–162 -Green (wheel slot 13) 163–163 Red (wheel slot 14) 164–200 +Blue (wheel slot 15) 201–201 Magenta (wheel slot 16) 202–238 -Red (wheel slot 17) 239–239 Blue (wheel slot 7) 240–240 Fast 241–246 Fast > Slow 247–247 Slow 248–248 Fast 249–254 Fast > Slow 255–255 Slow

Dual Control Movement: Advanced 26ch (continued)

Ch	Function	Default	DMX values
6	Effect	0	0–0 Open 1–1 Pattern 1 - Macro 2–2 Pattern 2 - Macro 3–3 Pattern 3 - Macro 4–4 Pattern 4 - Macro 5–5 Pattern 5 - Macro 6–6 Pattern 6 - Macro 7–7 Pattern 7 - Macro 8–8 Pattern 8 - Macro 9–9 Pattern 9 - Macro 10–10 Pattern 10 - Macro 11–11 Pattern 11 - Macro 12–12 Pattern 12 - Macro 13–13 Pattern 13 - Macro 14–14 Pattern 14 - Macro 15–15 Pattern 15 - Macro 16–16 Pattern 16 - Macro 17–17 Pattern 17 - Macro 18–18 Pattern 18 - Macro 19–19 Pattern 19 - Macro 20–20 Pattern 20 - Macro 21–21 Pattern 21 - Macro 22–22 Pattern 22 - Macro 23–23 Pattern 23 - Macro 24–24 Pattern 24 - Macro 25–25 Pattern 25 - Macro 26–26 Pattern 26 - Macro 27–27 Pattern 27 - Macro 28–28 Pattern 28 - Macro 29–29 Pattern 29 - Macro 30–30 Pattern 30 - Macro 31–31 Pattern 31 - Macro 32–32 Pattern 32 - Macro 33–33 Pattern 33 - Macro 34–34 Pattern 34 - Macro 35–35 Pattern 35 - Macro 36–36 Pattern 36 - Macro 37–37 Pattern 37 - Macro 38–38 Pattern 38 - Macro 39–39 Pattern 39 - Macro 40–40 Pattern 40 - Macro 41–41 Pattern 41 - Macro 42–42 Pattern 42 - Macro 43–43 Pattern 43 - Macro 44–44 Pattern 44 - Macro 45–45 Pattern 45 - Macro 46–46 Pattern 46 - Macro 47–47 Pattern 47 - Macro 48–48 Pattern 48 - Macro 49–49 Pattern 49 - Macro 50–50 Pattern 50 - Macro 51–51 Pattern 51 - Macro 52–52 Pattern 52 - Macro 53–53 Pattern 53 - Macro 54–54 Pattern 54 - Macro 55–55 Pattern 55 - Macro 56–56 Pattern 56 - Macro 57–57 Pattern 57 - Macro 58–58 Pattern 58 - Macro 59–59 Pattern 59 - Macro 60–60 Pattern 60 - Macro 61–61 Pattern 61 - Macro 62–62 Pattern 62 - Macro 63–63 Pattern 63 - Macro

Dual Control Movement: Advanced 26ch (continued)

Ch	Function	Default	DMX values
7	Effect 2	0	0–15 LED Built-In Open 16–17 LED Built-In 1 - Macro 18–19 LED Built-In 2 - Macro 20–21 LED Built-In 3 - Macro 22–23 LED Built-In 4 - Macro 24–25 LED Built-In 5 - Macro 26–27 LED Built-In 6 - Macro 28–29 LED Built-In 7 - Macro 30–31 LED Built-In 8 - Macro 32–33 LED Built-In 9 - Macro 34–35 LED Built-In 10 - Macro 36–37 LED Built-In 11 - Macro 38–39 LED Built-In 12 - Macro 40–41 LED Built-In 13 - Macro 42–43 LED Built-In 14 - Macro 44–45 LED Built-In 15 - Macro 46–47 LED Built-In 16 - Macro 48–49 LED Built-In 17 - Macro 50–51 LED Built-In 18 - Macro 52–53 LED Built-In 19 - Macro 54–55 LED Built-In 20 - Macro 56–57 LED Built-In 21 - Macro 58–59 LED Built-In 22 - Macro 60–61 LED Built-In 23 - Macro 62–63 LED Built-In 24 - Macro 64–65 LED Built-In 25 - Macro 66–67 LED Built-In 26 - Macro 68–69 LED Built-In 27 - Macro 70–71 LED Built-In 28 - Macro 72–73 LED Built-In 29 - Macro 74–75 LED Built-In 30 - Macro 76–77 LED Built-In 31 - Macro 78–79 LED Built-In 32 - Macro 80–81 LED Built-In 33 - Macro 82–83 LED Built-In 34 - Macro 84–85 LED Built-In 35 - Macro 86–87 LED Built-In 36 - Macro 88–89 LED Built-In 37 - Macro 90–91 LED Built-In 38 - Macro 92–93 LED Built-In 39 - Macro 94–95 LED Built-In 40 - Macro 96–97 LED Built-In 41 - Macro 98–99 LED Built-In 42 - Macro 100–101 LED Built-In 43 - Macro 102–103 LED Built-In 44 - Macro 104–105 LED Built-In 45 - Macro 106–107 LED Built-In 46 - Macro 108–109 LED Built-In 47 - Macro 110–111 LED Built-In 48 - Macro 112–113 LED Built-In 49 - Macro 114–115 LED Built-In 50 - Macro 116–117 LED Built-In 51 - Macro 118–119 LED Built-In 52 - Macro 120–121 LED Built-In 53 - Macro 122–123 LED Built-In 54 - Macro 124–125 LED Built-In 55 - Macro 126–127 LED Built-In 56 - Macro 128–129 LED Built-In 57 - Macro 130–131 LED Built-In 58 - Macro 132–133 LED Built-In 59 - Macro 134–135 LED Built-In 60 - Macro 136–137 LED Built-In 61 - Macro 138–139 LED Built-In 62 - Macro 140–141 LED Built-In 63 - Macro

Dual Control Movement: Advanced 26ch (continued)

Ch	Function	Default	DMX values
8	Effect Speed 2	128	0–127 Fast > Slow 128–128 Stop 129–255 Slow > Fast
9	Effects2Adjust1	0	0–0 Min 1–254 Min > Max 255–255 Max
10	Color Macro2	0	0–0 Open 1–2 White 2700K - CTC (wheel slot 1) 3–4 White 3200K - CTC (wheel slot 2) 5–6 White 4200K - CTC (wheel slot 3) 7–8 White 5600K - CTC (wheel slot 4) 9–10 White 8000K - CTC (wheel slot 5) 11–11 Blue (wheel slot 6) 12–48 +Green (wheel slot 7) 49–49 Cyan (wheel slot 8) 50–86 -Blue (wheel slot 9) 87–87 Green (wheel slot 10) 88–124 +Red (wheel slot 11) 125–125 Yellow (wheel slot 12) 126–162 -Green (wheel slot 13) 163–163 Red (wheel slot 14) 164–200 +Blue (wheel slot 15) 201–201 Magenta (wheel slot 16) 202–238 -Red (wheel slot 17) 239–239 Blue (wheel slot 7) 240–240 Fast 241–246 Fast > Slow 247–247 Slow 248–248 Fast 249–254 Fast > Slow 255–255 Slow
11	Background Dimmer	0	
12	Background Dimmer Fine	0	Fine byte of Background Dimmer
13	Dimmer	0	
14	Dimmer Fine	0	Fine byte of Dimmer

Dual Control Movement: Advanced 26ch (continued)

Ch	Function	Default	DMX values
15	Shutter / Strobe	22	0–19 Shutter Closed 20–24 Shutter Open 25–25 STROBE · Fast 20 Hz 26–63 STROBE · Fast > Slow 19.5–0.61 Hz 64–64 STROBE · Slow 0.1 Hz 65–69 Shutter Open 70–70 STROBE 100-0% · Fast 20 Hz 71–83 STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 84–84 STROBE 100-0% · Slow 0.1 Hz 85–89 Shutter Open 90–90 STROBE 0-100% · Fast 20 Hz 91–103 STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 104–104 STROBE 0-100% · Slow 0.1 Hz 105–109 Shutter Open 110–110 RANDOM STROBE · Fast 20 Hz 111–123 RANDOM STROBE · Fast > Slow 18.6–1.52 Hz 124–124 RANDOM STROBE · Slow 0.1 Hz 125–129 Shutter Open 130–130 RANDOM STROBE 100-0% · Fast 20 Hz 131–143 RANDOM STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 144–144 RANDOM STROBE 100-0% · Slow 0.1 Hz 145–149 Shutter Open 150–150 RANDOM STROBE 0-100% · Fast 20 Hz 151–163 RANDOM STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 164–164 RANDOM STROBE 0-100% · Slow 0.1 Hz 165–169 Shutter Open 170–170 PULSE STROBE · Fast 20 Hz 171–183 PULSE STROBE · Fast > Slow 18.6–1.52 Hz 184–184 PULSE STROBE · Slow 0.1 Hz 185–189 Shutter Open 190–190 RANDOM PULSE STROBE · Fast 20 Hz 191–203 RANDOM PULSE STROBE · Fast > Slow 18.6–1.52 Hz 204–204 RANDOM PULSE STROBE · Slow 0.1 Hz 205–209 Shutter Open 210–210 STROBE 0-100-0% · Fast 20 Hz 211–223 STROBE 0-100-0% · Fast > Slow 18.6–1.52 Hz 224–224 STROBE 0-100-0% · Slow 0.1 Hz 225–229 Shutter Open 230–230 RANDOM PULSE STROBE 1 · Fast 20 Hz 231–243 RANDOM PULSE STROBE 1 · Fast > Slow 18.6–1.52 … 244–244 RANDOM PULSE STROBE 1 · Slow 0.1 Hz 245–255 Shutter Open
16	Zoom	127	0–0 Wide 1–254 Wide > Narrow 255–255 Narrow
17	Zoom	127	0–0 Wide 1–254 Wide > Narrow 255–255 Narrow

Dual Control Movement: Advanced 26ch (continued)

Ch	Function	Default	DMX values
18	Control1	0	0–9 No Function 10–14 Blackout On Tilt 15–19 Reserved 20–24 RGBW Color Mixing Mode 25–29 CMY Color Mixing Mode 30–39 Reserved 40–44 Defrost Fan On 45–49 Defrost Fan Off 50–54 Reserved 55–59 Tilt Reset 60–64 Zoom Reset 65–69 Reserved 70–74 Reset All 75–75 PWM 600Hz 76–76 PWM 1200Hz 77–77 PWM 2000Hz 78–78 PWM 4000Hz 79–79 PWM 6000Hz 80–80 PWM 15000Hz 81–81 Reserved 82–84 Cell Order 1-16 85–89 Cell Order 16-1 90–94 Tilt Reverse 95–99 Reserved 100–104 Tilt Reverse Disable 105–119 Reserved 120–124 Fan ECO 125–129 Fan Full 130–134 Fan Auto 135–139 Dimmer Fast 140–144 Dimmer Smooth 145–149 Linear 150–154 Square 155–159 Inverse Square 160–164 S Square 165–169 White Mode 170–174 Full Mode 175–239 Color Macros HTP On 240–247 Color Macros HTP Off 248–255 Reserved
19	R Overwrite	0	
20	R Overwrite Fine	0	Fine byte of R Overwrite
21	G Overwrite	0	
22	G Overwrite Fine	0	Fine byte of G Overwrite
23	B Overwrite	0	
24	B Overwrite Fine	0	Fine byte of B Overwrite
25	W Overwrite	0	
26	W Overwrite Fine	0	Fine byte of W Overwrite

Dual Control Pixels:Basic 48ch

48 channels

Ch	Function	Default	DMX values
1	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
2	Green	255	0–0 Min 1–254 Min > Max 255–255 Max

Dual Control Pixels:Basic 48ch (continued)

Ch	Function	Default	DMX values
3	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
4	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
5	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
6	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
7	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
8	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
9	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
10	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
11	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
12	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
13	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
14	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
15	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
16	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
17	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
18	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
19	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
20	Green	255	0–0 Min 1–254 Min > Max 255–255 Max

Dual Control Pixels:Basic 48ch (continued)

Ch	Function	Default	DMX values
21	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
22	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
23	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
24	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
25	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
26	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
27	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
28	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
29	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
30	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
31	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
32	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
33	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
34	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
35	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
36	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
37	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
38	Green	255	0–0 Min 1–254 Min > Max 255–255 Max

Dual Control Pixels:Basic 48ch (continued)

Ch	Function	Default	DMX values
39	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
40	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
41	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
42	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
43	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
44	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
45	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
46	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
47	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
48	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max

Dual Control Pixels:Standard 64ch

64 channels

Ch	Function	Default	DMX values
1	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
2	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
3	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
4	White	255	0–0 Min 1–254 Min > Max 255–255 Max
5	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
6	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
7	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max

Dual Control Pixels:Standard 64ch (continued)

Ch	Function	Default	DMX values
8	White	255	0–0 Min 1–254 Min > Max 255–255 Max
9	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
10	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
11	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
12	White	255	0–0 Min 1–254 Min > Max 255–255 Max
13	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
14	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
15	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
16	White	255	0–0 Min 1–254 Min > Max 255–255 Max
17	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
18	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
19	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
20	White	255	0–0 Min 1–254 Min > Max 255–255 Max
21	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
22	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
23	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
24	White	255	0–0 Min 1–254 Min > Max 255–255 Max
25	Red	255	0–0 Min 1–254 Min > Max 255–255 Max

Dual Control Pixels:Standard 64ch (continued)

Ch	Function	Default	DMX values
26	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
27	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
28	White	255	0–0 Min 1–254 Min > Max 255–255 Max
29	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
30	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
31	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
32	White	255	0–0 Min 1–254 Min > Max 255–255 Max
33	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
34	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
35	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
36	White	255	0–0 Min 1–254 Min > Max 255–255 Max
37	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
38	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
39	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
40	White	255	0–0 Min 1–254 Min > Max 255–255 Max
41	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
42	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
43	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max

Dual Control Pixels:Standard 64ch (continued)

Ch	Function	Default	DMX values
44	White	255	0–0 Min 1–254 Min > Max 255–255 Max
45	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
46	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
47	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
48	White	255	0–0 Min 1–254 Min > Max 255–255 Max
49	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
50	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
51	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
52	White	255	0–0 Min 1–254 Min > Max 255–255 Max
53	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
54	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
55	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
56	White	255	0–0 Min 1–254 Min > Max 255–255 Max
57	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
58	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
59	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
60	White	255	0–0 Min 1–254 Min > Max 255–255 Max
61	Red	255	0–0 Min 1–254 Min > Max 255–255 Max

Dual Control Pixels:Standard 64ch (continued)

Ch	Function	Default	DMX values
62	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
63	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
64	White	255	0–0 Min 1–254 Min > Max 255–255 Max

Single Control: Standard Mode 84ch

84 channels

Ch	Function	Default	DMX values
1	Tilt	127	
2	Tilt Fine	255	Fine byte of Tilt
3	Position MSpeed	0	
4	C TC	0	
5	Color Macro1	0	

Single Control: Standard Mode 84ch (continued)

Ch	Function	Default	DMX values
6	Effect	0	0–0 Open 1–1 Pattern 1 - Macro 2–2 Pattern 2 - Macro 3–3 Pattern 3 - Macro 4–4 Pattern 4 - Macro 5–5 Pattern 5 - Macro 6–6 Pattern 6 - Macro 7–7 Pattern 7 - Macro 8–8 Pattern 8 - Macro 9–9 Pattern 9 - Macro 10–10 Pattern 10 - Macro 11–11 Pattern 11 - Macro 12–12 Pattern 12 - Macro 13–13 Pattern 13 - Macro 14–14 Pattern 14 - Macro 15–15 Pattern 15 - Macro 16–16 Pattern 16 - Macro 17–17 Pattern 17 - Macro 18–18 Pattern 18 - Macro 19–19 Pattern 19 - Macro 20–20 Pattern 20 - Macro 21–21 Pattern 21 - Macro 22–22 Pattern 22 - Macro 23–23 Pattern 23 - Macro 24–24 Pattern 24 - Macro 25–25 Pattern 25 - Macro 26–26 Pattern 26 - Macro 27–27 Pattern 27 - Macro 28–28 Pattern 28 - Macro 29–29 Pattern 29 - Macro 30–30 Pattern 30 - Macro 31–31 Pattern 31 - Macro 32–32 Pattern 32 - Macro 33–33 Pattern 33 - Macro 34–34 Pattern 34 - Macro 35–35 Pattern 35 - Macro 36–36 Pattern 36 - Macro 37–37 Pattern 37 - Macro 38–38 Pattern 38 - Macro 39–39 Pattern 39 - Macro 40–40 Pattern 40 - Macro 41–41 Pattern 41 - Macro 42–42 Pattern 42 - Macro 43–43 Pattern 43 - Macro 44–44 Pattern 44 - Macro 45–45 Pattern 45 - Macro 46–46 Pattern 46 - Macro 47–47 Pattern 47 - Macro 48–48 Pattern 48 - Macro 49–49 Pattern 49 - Macro 50–50 Pattern 50 - Macro 51–51 Pattern 51 - Macro 52–52 Pattern 52 - Macro 53–53 Pattern 53 - Macro 54–54 Pattern 54 - Macro 55–55 Pattern 55 - Macro 56–56 Pattern 56 - Macro 57–57 Pattern 57 - Macro 58–58 Pattern 58 - Macro 59–59 Pattern 59 - Macro 60–60 Pattern 60 - Macro 61–61 Pattern 61 - Macro 62–62 Pattern 62 - Macro 63–63 Pattern 63 - Macro

Single Control: Standard Mode 84ch (continued)

Ch	Function	Default	DMX values
7	Effect 2	0	0–15 LED Built-In Open 16–17 LED Built-In 1 - Macro 18–19 LED Built-In 2 - Macro 20–21 LED Built-In 3 - Macro 22–23 LED Built-In 4 - Macro 24–25 LED Built-In 5 - Macro 26–27 LED Built-In 6 - Macro 28–29 LED Built-In 7 - Macro 30–31 LED Built-In 8 - Macro 32–33 LED Built-In 9 - Macro 34–35 LED Built-In 10 - Macro 36–37 LED Built-In 11 - Macro 38–39 LED Built-In 12 - Macro 40–41 LED Built-In 13 - Macro 42–43 LED Built-In 14 - Macro 44–45 LED Built-In 15 - Macro 46–47 LED Built-In 16 - Macro 48–49 LED Built-In 17 - Macro 50–51 LED Built-In 18 - Macro 52–53 LED Built-In 19 - Macro 54–55 LED Built-In 20 - Macro 56–57 LED Built-In 21 - Macro 58–59 LED Built-In 22 - Macro 60–61 LED Built-In 23 - Macro 62–63 LED Built-In 24 - Macro 64–65 LED Built-In 25 - Macro 66–67 LED Built-In 26 - Macro 68–69 LED Built-In 27 - Macro 70–71 LED Built-In 28 - Macro 72–73 LED Built-In 29 - Macro 74–75 LED Built-In 30 - Macro 76–77 LED Built-In 31 - Macro 78–79 LED Built-In 32 - Macro 80–81 LED Built-In 33 - Macro 82–83 LED Built-In 34 - Macro 84–85 LED Built-In 35 - Macro 86–87 LED Built-In 36 - Macro 88–89 LED Built-In 37 - Macro 90–91 LED Built-In 38 - Macro 92–93 LED Built-In 39 - Macro 94–95 LED Built-In 40 - Macro 96–97 LED Built-In 41 - Macro 98–99 LED Built-In 42 - Macro 100–101 LED Built-In 43 - Macro 102–103 LED Built-In 44 - Macro 104–105 LED Built-In 45 - Macro 106–107 LED Built-In 46 - Macro 108–109 LED Built-In 47 - Macro 110–111 LED Built-In 48 - Macro 112–113 LED Built-In 49 - Macro 114–115 LED Built-In 50 - Macro 116–117 LED Built-In 51 - Macro 118–119 LED Built-In 52 - Macro 120–121 LED Built-In 53 - Macro 122–123 LED Built-In 54 - Macro 124–125 LED Built-In 55 - Macro 126–127 LED Built-In 56 - Macro 128–129 LED Built-In 57 - Macro 130–131 LED Built-In 58 - Macro 132–133 LED Built-In 59 - Macro 134–135 LED Built-In 60 - Macro 136–137 LED Built-In 61 - Macro 138–139 LED Built-In 62 - Macro 140–141 LED Built-In 63 - Macro

Single Control: Standard Mode 84ch (continued)

Ch	Function	Default	DMX values
8	Effect Speed 2	128	
9	Effects2Adjust1	0	
10	Color Macro2	0	
11	Background Dimmer	0	
12	Dimmer	0	
13	Shutter / Strobe	22	0–19 Shutter Closed 20–24 Shutter Open 25–25 STROBE · Fast 20 Hz 26–63 STROBE · Fast > Slow 19.5–0.61 Hz 64–64 STROBE · Slow 0.1 Hz 65–69 Shutter Open 70–70 STROBE 100-0% · Fast 20 Hz 71–83 STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 84–84 STROBE 100-0% · Slow 0.1 Hz 85–89 Shutter Open 90–90 STROBE 0-100% · Fast 20 Hz 91–103 STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 104–104 STROBE 0-100% · Slow 0.1 Hz 105–109 Shutter Open 110–110 RANDOM STROBE · Fast 20 Hz 111–123 RANDOM STROBE · Fast > Slow 18.6–1.52 Hz 124–124 RANDOM STROBE · Slow 0.1 Hz 125–129 Shutter Open 130–130 RANDOM STROBE 100-0% · Fast 20 Hz 131–143 RANDOM STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 144–144 RANDOM STROBE 100-0% · Slow 0.1 Hz 145–149 Shutter Open 150–150 RANDOM STROBE 0-100% · Fast 20 Hz 151–163 RANDOM STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 164–164 RANDOM STROBE 0-100% · Slow 0.1 Hz 165–169 Shutter Open 170–170 PULSE STROBE · Fast 20 Hz 171–183 PULSE STROBE · Fast > Slow 18.6–1.52 Hz 184–184 PULSE STROBE · Slow 0.1 Hz 185–189 Shutter Open 190–190 RANDOM PULSE STROBE · Fast 20 Hz 191–203 RANDOM PULSE STROBE · Fast > Slow 18.6–1.52 Hz 204–204 RANDOM PULSE STROBE · Slow 0.1 Hz 205–209 Shutter Open 210–210 STROBE 0-100-0% · Fast 20 Hz 211–223 STROBE 0-100-0% · Fast > Slow 18.6–1.52 Hz 224–224 STROBE 0-100-0% · Slow 0.1 Hz 225–229 Shutter Open 230–230 RANDOM PULSE STROBE 1 · Fast 20 Hz 231–243 RANDOM PULSE STROBE 1 · Fast > Slow 18.6–1.52 … 244–244 RANDOM PULSE STROBE 1 · Slow 0.1 Hz 245–255 Shutter Open
14	Zoom	127	
15	Zoom	127	
16	Control1	0	
17	R Overwrite	0	
18	G Overwrite	0	
19	B Overwrite	0	
20	W Overwrite	0	
21	Red	255	
22	Green	255	
23	Blue	255	

Single Control: Standard Mode 84ch (continued)

Ch	Function	Default	DMX values
24	White	255	
25	Red	255	
26	Green	255	
27	Blue	255	
28	White	255	
29	Red	255	
30	Green	255	
31	Blue	255	
32	White	255	
33	Red	255	
34	Green	255	
35	Blue	255	
36	White	255	
37	Red	255	
38	Green	255	
39	Blue	255	
40	White	255	
41	Red	255	
42	Green	255	
43	Blue	255	
44	White	255	
45	Red	255	
46	Green	255	
47	Blue	255	
48	White	255	
49	Red	255	
50	Green	255	
51	Blue	255	
52	White	255	
53	Red	255	
54	Green	255	
55	Blue	255	
56	White	255	
57	Red	255	
58	Green	255	
59	Blue	255	
60	White	255	
61	Red	255	
62	Green	255	
63	Blue	255	
64	White	255	
65	Red	255	
66	Green	255	
67	Blue	255	
68	White	255	

Single Control: Standard Mode 84ch (continued)

Ch	Function	Default	DMX values
69	Red	255	
70	Green	255	
71	Blue	255	
72	White	255	
73	Red	255	
74	Green	255	
75	Blue	255	
76	White	255	
77	Red	255	
78	Green	255	
79	Blue	255	
80	White	255	
81	Red	255	
82	Green	255	
83	Blue	255	
84	White	255	

Dual Control Pixels : Advanced Mode 128ch

128 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Red Fine	255	Fine byte of Red
3	Green	255	
4	Green Fine	255	Fine byte of Green
5	Blue	255	
6	Blue Fine	255	Fine byte of Blue
7	White	255	
8	White Fine	255	Fine byte of White
9	Red	255	
10	Red Fine	255	Fine byte of Red
11	Green	255	
12	Green Fine	255	Fine byte of Green
13	Blue	255	
14	Blue Fine	255	Fine byte of Blue
15	White	255	
16	White Fine	255	Fine byte of White
17	Red	255	
18	Red Fine	255	Fine byte of Red
19	Green	255	
20	Green Fine	255	Fine byte of Green
21	Blue	255	
22	Blue Fine	255	Fine byte of Blue
23	White	255	
24	White Fine	255	Fine byte of White
25	Red	255	

Dual Control Pixels : Advanced Mode 128ch (continued)

Ch	Function	Default	DMX values
26	Red Fine	255	Fine byte of Red
27	Green	255	
28	Green Fine	255	Fine byte of Green
29	Blue	255	
30	Blue Fine	255	Fine byte of Blue
31	White	255	
32	White Fine	255	Fine byte of White
33	Red	255	
34	Red Fine	255	Fine byte of Red
35	Green	255	
36	Green Fine	255	Fine byte of Green
37	Blue	255	
38	Blue Fine	255	Fine byte of Blue
39	White	255	
40	White Fine	255	Fine byte of White
41	Red	255	
42	Red Fine	255	Fine byte of Red
43	Green	255	
44	Green Fine	255	Fine byte of Green
45	Blue	255	
46	Blue Fine	255	Fine byte of Blue
47	White	255	
48	White Fine	255	Fine byte of White
49	Red	255	
50	Red Fine	255	Fine byte of Red
51	Green	255	
52	Green Fine	255	Fine byte of Green
53	Blue	255	
54	Blue Fine	255	Fine byte of Blue
55	White	255	
56	White Fine	255	Fine byte of White
57	Red	255	
58	Red Fine	255	Fine byte of Red
59	Green	255	
60	Green Fine	255	Fine byte of Green
61	Blue	255	
62	Blue Fine	255	Fine byte of Blue
63	White	255	
64	White Fine	255	Fine byte of White
65	Red	255	
66	Red Fine	255	Fine byte of Red
67	Green	255	
68	Green Fine	255	Fine byte of Green
69	Blue	255	
70	Blue Fine	255	Fine byte of Blue

Dual Control Pixels : Advanced Mode 128ch (continued)

Ch	Function	Default	DMX values
71	White	255	
72	White Fine	255	Fine byte of White
73	Red	255	
74	Red Fine	255	Fine byte of Red
75	Green	255	
76	Green Fine	255	Fine byte of Green
77	Blue	255	
78	Blue Fine	255	Fine byte of Blue
79	White	255	
80	White Fine	255	Fine byte of White
81	Red	255	
82	Red Fine	255	Fine byte of Red
83	Green	255	
84	Green Fine	255	Fine byte of Green
85	Blue	255	
86	Blue Fine	255	Fine byte of Blue
87	White	255	
88	White Fine	255	Fine byte of White
89	Red	255	
90	Red Fine	255	Fine byte of Red
91	Green	255	
92	Green Fine	255	Fine byte of Green
93	Blue	255	
94	Blue Fine	255	Fine byte of Blue
95	White	255	
96	White Fine	255	Fine byte of White
97	Red	255	
98	Red Fine	255	Fine byte of Red
99	Green	255	
100	Green Fine	255	Fine byte of Green
101	Blue	255	
102	Blue Fine	255	Fine byte of Blue
103	White	255	
104	White Fine	255	Fine byte of White
105	Red	255	
106	Red Fine	255	Fine byte of Red
107	Green	255	
108	Green Fine	255	Fine byte of Green
109	Blue	255	
110	Blue Fine	255	Fine byte of Blue
111	White	255	
112	White Fine	255	Fine byte of White
113	Red	255	
114	Red Fine	255	Fine byte of Red
115	Green	255	

Dual Control Pixels : Advanced Mode 128ch (continued)

Ch	Function	Default	DMX values
116	Green Fine	255	Fine byte of Green
117	Blue	255	
118	Blue Fine	255	Fine byte of Blue
119	White	255	
120	White Fine	255	Fine byte of White
121	Red	255	
122	Red Fine	255	Fine byte of Red
123	Green	255	
124	Green Fine	255	Fine byte of Green
125	Blue	255	
126	Blue Fine	255	Fine byte of Blue
127	White	255	
128	White Fine	255	Fine byte of White

Single Control: Advanced Mode 154ch

154 channels

Ch	Function	Default	DMX values
1	Tilt	127	
2	Tilt Fine	255	Fine byte of Tilt
3	Position MSpeed	0	
4	C TC	0	
5	Color Macro1	0	

Single Control: Advanced Mode 154ch (continued)

Ch	Function	Default	DMX values
6	Effect	0	0–0 Open 1–1 Pattern 1 - Macro 2–2 Pattern 2 - Macro 3–3 Pattern 3 - Macro 4–4 Pattern 4 - Macro 5–5 Pattern 5 - Macro 6–6 Pattern 6 - Macro 7–7 Pattern 7 - Macro 8–8 Pattern 8 - Macro 9–9 Pattern 9 - Macro 10–10 Pattern 10 - Macro 11–11 Pattern 11 - Macro 12–12 Pattern 12 - Macro 13–13 Pattern 13 - Macro 14–14 Pattern 14 - Macro 15–15 Pattern 15 - Macro 16–16 Pattern 16 - Macro 17–17 Pattern 17 - Macro 18–18 Pattern 18 - Macro 19–19 Pattern 19 - Macro 20–20 Pattern 20 - Macro 21–21 Pattern 21 - Macro 22–22 Pattern 22 - Macro 23–23 Pattern 23 - Macro 24–24 Pattern 24 - Macro 25–25 Pattern 25 - Macro 26–26 Pattern 26 - Macro 27–27 Pattern 27 - Macro 28–28 Pattern 28 - Macro 29–29 Pattern 29 - Macro 30–30 Pattern 30 - Macro 31–31 Pattern 31 - Macro 32–32 Pattern 32 - Macro 33–33 Pattern 33 - Macro 34–34 Pattern 34 - Macro 35–35 Pattern 35 - Macro 36–36 Pattern 36 - Macro 37–37 Pattern 37 - Macro 38–38 Pattern 38 - Macro 39–39 Pattern 39 - Macro 40–40 Pattern 40 - Macro 41–41 Pattern 41 - Macro 42–42 Pattern 42 - Macro 43–43 Pattern 43 - Macro 44–44 Pattern 44 - Macro 45–45 Pattern 45 - Macro 46–46 Pattern 46 - Macro 47–47 Pattern 47 - Macro 48–48 Pattern 48 - Macro 49–49 Pattern 49 - Macro 50–50 Pattern 50 - Macro 51–51 Pattern 51 - Macro 52–52 Pattern 52 - Macro 53–53 Pattern 53 - Macro 54–54 Pattern 54 - Macro 55–55 Pattern 55 - Macro 56–56 Pattern 56 - Macro 57–57 Pattern 57 - Macro 58–58 Pattern 58 - Macro 59–59 Pattern 59 - Macro 60–60 Pattern 60 - Macro 61–61 Pattern 61 - Macro 62–62 Pattern 62 - Macro 63–63 Pattern 63 - Macro

Single Control: Advanced Mode 154ch (continued)

Ch	Function	Default	DMX values
7	Effect 2	0	0–15 LED Built-In Open 16–17 LED Built-In 1 - Macro 18–19 LED Built-In 2 - Macro 20–21 LED Built-In 3 - Macro 22–23 LED Built-In 4 - Macro 24–25 LED Built-In 5 - Macro 26–27 LED Built-In 6 - Macro 28–29 LED Built-In 7 - Macro 30–31 LED Built-In 8 - Macro 32–33 LED Built-In 9 - Macro 34–35 LED Built-In 10 - Macro 36–37 LED Built-In 11 - Macro 38–39 LED Built-In 12 - Macro 40–41 LED Built-In 13 - Macro 42–43 LED Built-In 14 - Macro 44–45 LED Built-In 15 - Macro 46–47 LED Built-In 16 - Macro 48–49 LED Built-In 17 - Macro 50–51 LED Built-In 18 - Macro 52–53 LED Built-In 19 - Macro 54–55 LED Built-In 20 - Macro 56–57 LED Built-In 21 - Macro 58–59 LED Built-In 22 - Macro 60–61 LED Built-In 23 - Macro 62–63 LED Built-In 24 - Macro 64–65 LED Built-In 25 - Macro 66–67 LED Built-In 26 - Macro 68–69 LED Built-In 27 - Macro 70–71 LED Built-In 28 - Macro 72–73 LED Built-In 29 - Macro 74–75 LED Built-In 30 - Macro 76–77 LED Built-In 31 - Macro 78–79 LED Built-In 32 - Macro 80–81 LED Built-In 33 - Macro 82–83 LED Built-In 34 - Macro 84–85 LED Built-In 35 - Macro 86–87 LED Built-In 36 - Macro 88–89 LED Built-In 37 - Macro 90–91 LED Built-In 38 - Macro 92–93 LED Built-In 39 - Macro 94–95 LED Built-In 40 - Macro 96–97 LED Built-In 41 - Macro 98–99 LED Built-In 42 - Macro 100–101 LED Built-In 43 - Macro 102–103 LED Built-In 44 - Macro 104–105 LED Built-In 45 - Macro 106–107 LED Built-In 46 - Macro 108–109 LED Built-In 47 - Macro 110–111 LED Built-In 48 - Macro 112–113 LED Built-In 49 - Macro 114–115 LED Built-In 50 - Macro 116–117 LED Built-In 51 - Macro 118–119 LED Built-In 52 - Macro 120–121 LED Built-In 53 - Macro 122–123 LED Built-In 54 - Macro 124–125 LED Built-In 55 - Macro 126–127 LED Built-In 56 - Macro 128–129 LED Built-In 57 - Macro 130–131 LED Built-In 58 - Macro 132–133 LED Built-In 59 - Macro 134–135 LED Built-In 60 - Macro 136–137 LED Built-In 61 - Macro 138–139 LED Built-In 62 - Macro 140–141 LED Built-In 63 - Macro

Single Control: Advanced Mode 154ch (continued)

Ch	Function	Default	DMX values
8	Effect Speed 2	128	
9	Effects2Adjust1	0	
10	Color Macro2	0	
11	Background Dimmer	0	
12	Background Dimmer Fine	0	Fine byte of Background Dimmer
13	Dimmer	0	
14	Dimmer Fine	0	Fine byte of Dimmer
15	Shutter / Strobe	22	0–19 Shutter Closed 20–24 Shutter Open 25–25 STROBE · Fast 20 Hz 26–63 STROBE · Fast > Slow 19.5–0.61 Hz 64–64 STROBE · Slow 0.1 Hz 65–69 Shutter Open 70–70 STROBE 100-0% · Fast 20 Hz 71–83 STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 84–84 STROBE 100-0% · Slow 0.1 Hz 85–89 Shutter Open 90–90 STROBE 0-100% · Fast 20 Hz 91–103 STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 104–104 STROBE 0-100% · Slow 0.1 Hz 105–109 Shutter Open 110–110 RANDOM STROBE · Fast 20 Hz 111–123 RANDOM STROBE · Fast > Slow 18.6–1.52 Hz 124–124 RANDOM STROBE · Slow 0.1 Hz 125–129 Shutter Open 130–130 RANDOM STROBE 100-0% · Fast 20 Hz 131–143 RANDOM STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 144–144 RANDOM STROBE 100-0% · Slow 0.1 Hz 145–149 Shutter Open 150–150 RANDOM STROBE 0-100% · Fast 20 Hz 151–163 RANDOM STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 164–164 RANDOM STROBE 0-100% · Slow 0.1 Hz 165–169 Shutter Open 170–170 PULSE STROBE · Fast 20 Hz 171–183 PULSE STROBE · Fast > Slow 18.6–1.52 Hz 184–184 PULSE STROBE · Slow 0.1 Hz 185–189 Shutter Open 190–190 RANDOM PULSE STROBE · Fast 20 Hz 191–203 RANDOM PULSE STROBE · Fast > Slow 18.6–1.52 Hz 204–204 RANDOM PULSE STROBE · Slow 0.1 Hz 205–209 Shutter Open 210–210 STROBE 0-100-0% · Fast 20 Hz 211–223 STROBE 0-100-0% · Fast > Slow 18.6–1.52 Hz 224–224 STROBE 0-100-0% · Slow 0.1 Hz 225–229 Shutter Open 230–230 RANDOM PULSE STROBE 1 · Fast 20 Hz 231–243 RANDOM PULSE STROBE 1 · Fast > Slow 18.6–1.52 … 244–244 RANDOM PULSE STROBE 1 · Slow 0.1 Hz 245–255 Shutter Open
16	Zoom	127	
17	Zoom	127	
18	Control1	0	
19	R Overwrite	0	
20	R Overwrite Fine	0	Fine byte of R Overwrite
21	G Overwrite	0	
22	G Overwrite Fine	0	Fine byte of G Overwrite
23	B Overwrite	0	

Single Control: Advanced Mode 154ch (continued)

Ch	Function	Default	DMX values
24	B Overwrite Fine	0	Fine byte of B Overwrite
25	W Overwrite	0	
26	W Overwrite Fine	0	Fine byte of W Overwrite
27	Red	255	
28	Red Fine	255	Fine byte of Red
29	Green	255	
30	Green Fine	255	Fine byte of Green
31	Blue	255	
32	Blue Fine	255	Fine byte of Blue
33	White	255	
34	White Fine	255	Fine byte of White
35	Red	255	
36	Red Fine	255	Fine byte of Red
37	Green	255	
38	Green Fine	255	Fine byte of Green
39	Blue	255	
40	Blue Fine	255	Fine byte of Blue
41	White	255	
42	White Fine	255	Fine byte of White
43	Red	255	
44	Red Fine	255	Fine byte of Red
45	Green	255	
46	Green Fine	255	Fine byte of Green
47	Blue	255	
48	Blue Fine	255	Fine byte of Blue
49	White	255	
50	White Fine	255	Fine byte of White
51	Red	255	
52	Red Fine	255	Fine byte of Red
53	Green	255	
54	Green Fine	255	Fine byte of Green
55	Blue	255	
56	Blue Fine	255	Fine byte of Blue
57	White	255	
58	White Fine	255	Fine byte of White
59	Red	255	
60	Red Fine	255	Fine byte of Red
61	Green	255	
62	Green Fine	255	Fine byte of Green
63	Blue	255	
64	Blue Fine	255	Fine byte of Blue
65	White	255	
66	White Fine	255	Fine byte of White
67	Red	255	
68	Red Fine	255	Fine byte of Red

Single Control: Advanced Mode 154ch (continued)

Ch	Function	Default	DMX values
69	Green	255	
70	Green Fine	255	Fine byte of Green
71	Blue	255	
72	Blue Fine	255	Fine byte of Blue
73	White	255	
74	White Fine	255	Fine byte of White
75	Red	255	
76	Red Fine	255	Fine byte of Red
77	Green	255	
78	Green Fine	255	Fine byte of Green
79	Blue	255	
80	Blue Fine	255	Fine byte of Blue
81	White	255	
82	White Fine	255	Fine byte of White
83	Red	255	
84	Red Fine	255	Fine byte of Red
85	Green	255	
86	Green Fine	255	Fine byte of Green
87	Blue	255	
88	Blue Fine	255	Fine byte of Blue
89	White	255	
90	White Fine	255	Fine byte of White
91	Red	255	
92	Red Fine	255	Fine byte of Red
93	Green	255	
94	Green Fine	255	Fine byte of Green
95	Blue	255	
96	Blue Fine	255	Fine byte of Blue
97	White	255	
98	White Fine	255	Fine byte of White
99	Red	255	
100	Red Fine	255	Fine byte of Red
101	Green	255	
102	Green Fine	255	Fine byte of Green
103	Blue	255	
104	Blue Fine	255	Fine byte of Blue
105	White	255	
106	White Fine	255	Fine byte of White
107	Red	255	
108	Red Fine	255	Fine byte of Red
109	Green	255	
110	Green Fine	255	Fine byte of Green
111	Blue	255	
112	Blue Fine	255	Fine byte of Blue
113	White	255	

Single Control: Advanced Mode 154ch (continued)

Ch	Function	Default	DMX values
114	White Fine	255	Fine byte of White
115	Red	255	
116	Red Fine	255	Fine byte of Red
117	Green	255	
118	Green Fine	255	Fine byte of Green
119	Blue	255	
120	Blue Fine	255	Fine byte of Blue
121	White	255	
122	White Fine	255	Fine byte of White
123	Red	255	
124	Red Fine	255	Fine byte of Red
125	Green	255	
126	Green Fine	255	Fine byte of Green
127	Blue	255	
128	Blue Fine	255	Fine byte of Blue
129	White	255	
130	White Fine	255	Fine byte of White
131	Red	255	
132	Red Fine	255	Fine byte of Red
133	Green	255	
134	Green Fine	255	Fine byte of Green
135	Blue	255	
136	Blue Fine	255	Fine byte of Blue
137	White	255	
138	White Fine	255	Fine byte of White
139	Red	255	
140	Red Fine	255	Fine byte of Red
141	Green	255	
142	Green Fine	255	Fine byte of Green
143	Blue	255	
144	Blue Fine	255	Fine byte of Blue
145	White	255	
146	White Fine	255	Fine byte of White
147	Red	255	
148	Red Fine	255	Fine byte of Red
149	Green	255	
150	Green Fine	255	Fine byte of Green
151	Blue	255	
152	Blue Fine	255	Fine byte of Blue
153	White	255	
154	White Fine	255	Fine byte of White

Single Control: Full PXL Mode 182ch

182 channels

Ch	Function	Default	DMX values
1	Tilt	127	
2	Tilt Fine	255	Fine byte of Tilt
3	Position MSpeed	0	
4	Zoom	127	
5	Zoom	127	
6	Control1	0	
7	Dimmer	255	
8	Dimmer Fine	255	Fine byte of Dimmer
9	Shutter / Strobe	22	0–19 Shutter Closed 20–24 Shutter Open 25–25 STROBE · Fast 20 Hz 26–63 STROBE · Fast > Slow 19.5–0.61 Hz 64–64 STROBE · Slow 0.1 Hz 65–69 Shutter Open 70–70 STROBE 100-0% · Fast 20 Hz 71–83 STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 84–84 STROBE 100-0% · Slow 0.1 Hz 85–89 Shutter Open 90–90 STROBE 0-100% · Fast 20 Hz 91–103 STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 104–104 STROBE 0-100% · Slow 0.1 Hz 105–109 Shutter Open 110–110 RANDOM STROBE · Fast 20 Hz 111–123 RANDOM STROBE · Fast > Slow 18.6–1.52 Hz 124–124 RANDOM STROBE · Slow 0.1 Hz 125–129 Shutter Open 130–130 RANDOM STROBE 100-0% · Fast 20 Hz 131–143 RANDOM STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 144–144 RANDOM STROBE 100-0% · Slow 0.1 Hz 145–149 Shutter Open 150–150 RANDOM STROBE 0-100% · Fast 20 Hz 151–163 RANDOM STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 164–164 RANDOM STROBE 0-100% · Slow 0.1 Hz 165–169 Shutter Open 170–170 PULSE STROBE · Fast 20 Hz 171–183 PULSE STROBE · Fast > Slow 18.6–1.52 Hz 184–184 PULSE STROBE · Slow 0.1 Hz 185–189 Shutter Open 190–190 RANDOM PULSE STROBE · Fast 20 Hz 191–203 RANDOM PULSE STROBE · Fast > Slow 18.6–1.52 Hz 204–204 RANDOM PULSE STROBE · Slow 0.1 Hz 205–209 Shutter Open 210–210 STROBE 0-100-0% · Fast 20 Hz 211–223 STROBE 0-100-0% · Fast > Slow 18.6–1.52 Hz 224–224 STROBE 0-100-0% · Slow 0.1 Hz 225–229 Shutter Open 230–230 RANDOM PULSE STROBE 1 · Fast 20 Hz 231–243 RANDOM PULSE STROBE 1 · Fast > Slow 18.6–1.52 … 244–244 RANDOM PULSE STROBE 1 · Slow 0.1 Hz 245–255 Shutter Open
10	Red	255	
11	Red Fine	255	Fine byte of Red
12	Green	255	
13	Green Fine	255	Fine byte of Green
14	Blue	255	
15	Blue Fine	255	Fine byte of Blue
16	White	255	

Single Control: Full PXL Mode 182ch (continued)

Ch	Function	Default	DMX values
17	White Fine	255	Fine byte of White
18	Dimmer	255	
19	Dimmer Fine	255	Fine byte of Dimmer
20	Shutter / Strobe	22	0–19 Shutter Closed 20–24 Shutter Open 25–25 STROBE · Fast 20 Hz 26–63 STROBE · Fast > Slow 19.5–0.61 Hz 64–64 STROBE · Slow 0.1 Hz 65–69 Shutter Open 70–70 STROBE 100-0% · Fast 20 Hz 71–83 STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 84–84 STROBE 100-0% · Slow 0.1 Hz 85–89 Shutter Open 90–90 STROBE 0-100% · Fast 20 Hz 91–103 STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 104–104 STROBE 0-100% · Slow 0.1 Hz 105–109 Shutter Open 110–110 RANDOM STROBE · Fast 20 Hz 111–123 RANDOM STROBE · Fast > Slow 18.6–1.52 Hz 124–124 RANDOM STROBE · Slow 0.1 Hz 125–129 Shutter Open 130–130 RANDOM STROBE 100-0% · Fast 20 Hz 131–143 RANDOM STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 144–144 RANDOM STROBE 100-0% · Slow 0.1 Hz 145–149 Shutter Open 150–150 RANDOM STROBE 0-100% · Fast 20 Hz 151–163 RANDOM STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 164–164 RANDOM STROBE 0-100% · Slow 0.1 Hz 165–169 Shutter Open 170–170 PULSE STROBE · Fast 20 Hz 171–183 PULSE STROBE · Fast > Slow 18.6–1.52 Hz 184–184 PULSE STROBE · Slow 0.1 Hz 185–189 Shutter Open 190–190 RANDOM PULSE STROBE · Fast 20 Hz 191–203 RANDOM PULSE STROBE · Fast > Slow 18.6–1.52 Hz 204–204 RANDOM PULSE STROBE · Slow 0.1 Hz 205–209 Shutter Open 210–210 STROBE 0-100-0% · Fast 20 Hz 211–223 STROBE 0-100-0% · Fast > Slow 18.6–1.52 Hz 224–224 STROBE 0-100-0% · Slow 0.1 Hz 225–229 Shutter Open 230–230 RANDOM PULSE STROBE 1 · Fast 20 Hz 231–243 RANDOM PULSE STROBE 1 · Fast > Slow 18.6–1.52 … 244–244 RANDOM PULSE STROBE 1 · Slow 0.1 Hz 245–255 Shutter Open
21	Red	255	
22	Red Fine	255	Fine byte of Red
23	Green	255	
24	Green Fine	255	Fine byte of Green
25	Blue	255	
26	Blue Fine	255	Fine byte of Blue
27	White	255	
28	White Fine	255	Fine byte of White
29	Dimmer	255	
30	Dimmer Fine	255	Fine byte of Dimmer

Single Control: Full PXL Mode 182ch (continued)

Ch	Function	Default	DMX values
31	Shutter / Strobe	22	0–19 Shutter Closed 20–24 Shutter Open 25–25 STROBE · Fast 20 Hz 26–63 STROBE · Fast > Slow 19.5–0.61 Hz 64–64 STROBE · Slow 0.1 Hz 65–69 Shutter Open 70–70 STROBE 100-0% · Fast 20 Hz 71–83 STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 84–84 STROBE 100-0% · Slow 0.1 Hz 85–89 Shutter Open 90–90 STROBE 0-100% · Fast 20 Hz 91–103 STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 104–104 STROBE 0-100% · Slow 0.1 Hz 105–109 Shutter Open 110–110 RANDOM STROBE · Fast 20 Hz 111–123 RANDOM STROBE · Fast > Slow 18.6–1.52 Hz 124–124 RANDOM STROBE · Slow 0.1 Hz 125–129 Shutter Open 130–130 RANDOM STROBE 100-0% · Fast 20 Hz 131–143 RANDOM STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 144–144 RANDOM STROBE 100-0% · Slow 0.1 Hz 145–149 Shutter Open 150–150 RANDOM STROBE 0-100% · Fast 20 Hz 151–163 RANDOM STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 164–164 RANDOM STROBE 0-100% · Slow 0.1 Hz 165–169 Shutter Open 170–170 PULSE STROBE · Fast 20 Hz 171–183 PULSE STROBE · Fast > Slow 18.6–1.52 Hz 184–184 PULSE STROBE · Slow 0.1 Hz 185–189 Shutter Open 190–190 RANDOM PULSE STROBE · Fast 20 Hz 191–203 RANDOM PULSE STROBE · Fast > Slow 18.6–1.52 Hz 204–204 RANDOM PULSE STROBE · Slow 0.1 Hz 205–209 Shutter Open 210–210 STROBE 0-100-0% · Fast 20 Hz 211–223 STROBE 0-100-0% · Fast > Slow 18.6–1.52 Hz 224–224 STROBE 0-100-0% · Slow 0.1 Hz 225–229 Shutter Open 230–230 RANDOM PULSE STROBE 1 · Fast 20 Hz 231–243 RANDOM PULSE STROBE 1 · Fast > Slow 18.6–1.52 … 244–244 RANDOM PULSE STROBE 1 · Slow 0.1 Hz 245–255 Shutter Open
32	Red	255	
33	Red Fine	255	Fine byte of Red
34	Green	255	
35	Green Fine	255	Fine byte of Green
36	Blue	255	
37	Blue Fine	255	Fine byte of Blue
38	White	255	
39	White Fine	255	Fine byte of White
40	Dimmer	255	
41	Dimmer Fine	255	Fine byte of Dimmer

Single Control: Full PXL Mode 182ch (continued)

Ch	Function	Default	DMX values
42	Shutter / Strobe	22	0–19 Shutter Closed 20–24 Shutter Open 25–25 STROBE · Fast 20 Hz 26–63 STROBE · Fast > Slow 19.5–0.61 Hz 64–64 STROBE · Slow 0.1 Hz 65–69 Shutter Open 70–70 STROBE 100-0% · Fast 20 Hz 71–83 STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 84–84 STROBE 100-0% · Slow 0.1 Hz 85–89 Shutter Open 90–90 STROBE 0-100% · Fast 20 Hz 91–103 STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 104–104 STROBE 0-100% · Slow 0.1 Hz 105–109 Shutter Open 110–110 RANDOM STROBE · Fast 20 Hz 111–123 RANDOM STROBE · Fast > Slow 18.6–1.52 Hz 124–124 RANDOM STROBE · Slow 0.1 Hz 125–129 Shutter Open 130–130 RANDOM STROBE 100-0% · Fast 20 Hz 131–143 RANDOM STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 144–144 RANDOM STROBE 100-0% · Slow 0.1 Hz 145–149 Shutter Open 150–150 RANDOM STROBE 0-100% · Fast 20 Hz 151–163 RANDOM STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 164–164 RANDOM STROBE 0-100% · Slow 0.1 Hz 165–169 Shutter Open 170–170 PULSE STROBE · Fast 20 Hz 171–183 PULSE STROBE · Fast > Slow 18.6–1.52 Hz 184–184 PULSE STROBE · Slow 0.1 Hz 185–189 Shutter Open 190–190 RANDOM PULSE STROBE · Fast 20 Hz 191–203 RANDOM PULSE STROBE · Fast > Slow 18.6–1.52 Hz 204–204 RANDOM PULSE STROBE · Slow 0.1 Hz 205–209 Shutter Open 210–210 STROBE 0-100-0% · Fast 20 Hz 211–223 STROBE 0-100-0% · Fast > Slow 18.6–1.52 Hz 224–224 STROBE 0-100-0% · Slow 0.1 Hz 225–229 Shutter Open 230–230 RANDOM PULSE STROBE 1 · Fast 20 Hz 231–243 RANDOM PULSE STROBE 1 · Fast > Slow 18.6–1.52 … 244–244 RANDOM PULSE STROBE 1 · Slow 0.1 Hz 245–255 Shutter Open
43	Red	255	
44	Red Fine	255	Fine byte of Red
45	Green	255	
46	Green Fine	255	Fine byte of Green
47	Blue	255	
48	Blue Fine	255	Fine byte of Blue
49	White	255	
50	White Fine	255	Fine byte of White
51	Dimmer	255	
52	Dimmer Fine	255	Fine byte of Dimmer

Single Control: Full PXL Mode 182ch (continued)

Ch	Function	Default	DMX values
53	Shutter / Strobe	22	0–19 Shutter Closed 20–24 Shutter Open 25–25 STROBE · Fast 20 Hz 26–63 STROBE · Fast > Slow 19.5–0.61 Hz 64–64 STROBE · Slow 0.1 Hz 65–69 Shutter Open 70–70 STROBE 100-0% · Fast 20 Hz 71–83 STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 84–84 STROBE 100-0% · Slow 0.1 Hz 85–89 Shutter Open 90–90 STROBE 0-100% · Fast 20 Hz 91–103 STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 104–104 STROBE 0-100% · Slow 0.1 Hz 105–109 Shutter Open 110–110 RANDOM STROBE · Fast 20 Hz 111–123 RANDOM STROBE · Fast > Slow 18.6–1.52 Hz 124–124 RANDOM STROBE · Slow 0.1 Hz 125–129 Shutter Open 130–130 RANDOM STROBE 100-0% · Fast 20 Hz 131–143 RANDOM STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 144–144 RANDOM STROBE 100-0% · Slow 0.1 Hz 145–149 Shutter Open 150–150 RANDOM STROBE 0-100% · Fast 20 Hz 151–163 RANDOM STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 164–164 RANDOM STROBE 0-100% · Slow 0.1 Hz 165–169 Shutter Open 170–170 PULSE STROBE · Fast 20 Hz 171–183 PULSE STROBE · Fast > Slow 18.6–1.52 Hz 184–184 PULSE STROBE · Slow 0.1 Hz 185–189 Shutter Open 190–190 RANDOM PULSE STROBE · Fast 20 Hz 191–203 RANDOM PULSE STROBE · Fast > Slow 18.6–1.52 Hz 204–204 RANDOM PULSE STROBE · Slow 0.1 Hz 205–209 Shutter Open 210–210 STROBE 0-100-0% · Fast 20 Hz 211–223 STROBE 0-100-0% · Fast > Slow 18.6–1.52 Hz 224–224 STROBE 0-100-0% · Slow 0.1 Hz 225–229 Shutter Open 230–230 RANDOM PULSE STROBE 1 · Fast 20 Hz 231–243 RANDOM PULSE STROBE 1 · Fast > Slow 18.6–1.52 … 244–244 RANDOM PULSE STROBE 1 · Slow 0.1 Hz 245–255 Shutter Open
54	Red	255	
55	Red Fine	255	Fine byte of Red
56	Green	255	
57	Green Fine	255	Fine byte of Green
58	Blue	255	
59	Blue Fine	255	Fine byte of Blue
60	White	255	
61	White Fine	255	Fine byte of White
62	Dimmer	255	
63	Dimmer Fine	255	Fine byte of Dimmer

Single Control: Full PXL Mode 182ch (continued)

Ch	Function	Default	DMX values
64	Shutter / Strobe	22	0–19 Shutter Closed 20–24 Shutter Open 25–25 STROBE · Fast 20 Hz 26–63 STROBE · Fast > Slow 19.5–0.61 Hz 64–64 STROBE · Slow 0.1 Hz 65–69 Shutter Open 70–70 STROBE 100-0% · Fast 20 Hz 71–83 STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 84–84 STROBE 100-0% · Slow 0.1 Hz 85–89 Shutter Open 90–90 STROBE 0-100% · Fast 20 Hz 91–103 STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 104–104 STROBE 0-100% · Slow 0.1 Hz 105–109 Shutter Open 110–110 RANDOM STROBE · Fast 20 Hz 111–123 RANDOM STROBE · Fast > Slow 18.6–1.52 Hz 124–124 RANDOM STROBE · Slow 0.1 Hz 125–129 Shutter Open 130–130 RANDOM STROBE 100-0% · Fast 20 Hz 131–143 RANDOM STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 144–144 RANDOM STROBE 100-0% · Slow 0.1 Hz 145–149 Shutter Open 150–150 RANDOM STROBE 0-100% · Fast 20 Hz 151–163 RANDOM STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 164–164 RANDOM STROBE 0-100% · Slow 0.1 Hz 165–169 Shutter Open 170–170 PULSE STROBE · Fast 20 Hz 171–183 PULSE STROBE · Fast > Slow 18.6–1.52 Hz 184–184 PULSE STROBE · Slow 0.1 Hz 185–189 Shutter Open 190–190 RANDOM PULSE STROBE · Fast 20 Hz 191–203 RANDOM PULSE STROBE · Fast > Slow 18.6–1.52 Hz 204–204 RANDOM PULSE STROBE · Slow 0.1 Hz 205–209 Shutter Open 210–210 STROBE 0-100-0% · Fast 20 Hz 211–223 STROBE 0-100-0% · Fast > Slow 18.6–1.52 Hz 224–224 STROBE 0-100-0% · Slow 0.1 Hz 225–229 Shutter Open 230–230 RANDOM PULSE STROBE 1 · Fast 20 Hz 231–243 RANDOM PULSE STROBE 1 · Fast > Slow 18.6–1.52 … 244–244 RANDOM PULSE STROBE 1 · Slow 0.1 Hz 245–255 Shutter Open
65	Red	255	
66	Red Fine	255	Fine byte of Red
67	Green	255	
68	Green Fine	255	Fine byte of Green
69	Blue	255	
70	Blue Fine	255	Fine byte of Blue
71	White	255	
72	White Fine	255	Fine byte of White
73	Dimmer	255	
74	Dimmer Fine	255	Fine byte of Dimmer

Single Control: Full PXL Mode 182ch (continued)

Ch	Function	Default	DMX values
75	Shutter / Strobe	22	0–19 Shutter Closed 20–24 Shutter Open 25–25 STROBE · Fast 20 Hz 26–63 STROBE · Fast > Slow 19.5–0.61 Hz 64–64 STROBE · Slow 0.1 Hz 65–69 Shutter Open 70–70 STROBE 100-0% · Fast 20 Hz 71–83 STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 84–84 STROBE 100-0% · Slow 0.1 Hz 85–89 Shutter Open 90–90 STROBE 0-100% · Fast 20 Hz 91–103 STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 104–104 STROBE 0-100% · Slow 0.1 Hz 105–109 Shutter Open 110–110 RANDOM STROBE · Fast 20 Hz 111–123 RANDOM STROBE · Fast > Slow 18.6–1.52 Hz 124–124 RANDOM STROBE · Slow 0.1 Hz 125–129 Shutter Open 130–130 RANDOM STROBE 100-0% · Fast 20 Hz 131–143 RANDOM STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 144–144 RANDOM STROBE 100-0% · Slow 0.1 Hz 145–149 Shutter Open 150–150 RANDOM STROBE 0-100% · Fast 20 Hz 151–163 RANDOM STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 164–164 RANDOM STROBE 0-100% · Slow 0.1 Hz 165–169 Shutter Open 170–170 PULSE STROBE · Fast 20 Hz 171–183 PULSE STROBE · Fast > Slow 18.6–1.52 Hz 184–184 PULSE STROBE · Slow 0.1 Hz 185–189 Shutter Open 190–190 RANDOM PULSE STROBE · Fast 20 Hz 191–203 RANDOM PULSE STROBE · Fast > Slow 18.6–1.52 Hz 204–204 RANDOM PULSE STROBE · Slow 0.1 Hz 205–209 Shutter Open 210–210 STROBE 0-100-0% · Fast 20 Hz 211–223 STROBE 0-100-0% · Fast > Slow 18.6–1.52 Hz 224–224 STROBE 0-100-0% · Slow 0.1 Hz 225–229 Shutter Open 230–230 RANDOM PULSE STROBE 1 · Fast 20 Hz 231–243 RANDOM PULSE STROBE 1 · Fast > Slow 18.6–1.52 … 244–244 RANDOM PULSE STROBE 1 · Slow 0.1 Hz 245–255 Shutter Open
76	Red	255	
77	Red Fine	255	Fine byte of Red
78	Green	255	
79	Green Fine	255	Fine byte of Green
80	Blue	255	
81	Blue Fine	255	Fine byte of Blue
82	White	255	
83	White Fine	255	Fine byte of White
84	Dimmer	255	
85	Dimmer Fine	255	Fine byte of Dimmer

Single Control: Full PXL Mode 182ch (continued)

Ch	Function	Default	DMX values
86	Shutter / Strobe	22	0–19 Shutter Closed 20–24 Shutter Open 25–25 STROBE · Fast 20 Hz 26–63 STROBE · Fast > Slow 19.5–0.61 Hz 64–64 STROBE · Slow 0.1 Hz 65–69 Shutter Open 70–70 STROBE 100-0% · Fast 20 Hz 71–83 STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 84–84 STROBE 100-0% · Slow 0.1 Hz 85–89 Shutter Open 90–90 STROBE 0-100% · Fast 20 Hz 91–103 STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 104–104 STROBE 0-100% · Slow 0.1 Hz 105–109 Shutter Open 110–110 RANDOM STROBE · Fast 20 Hz 111–123 RANDOM STROBE · Fast > Slow 18.6–1.52 Hz 124–124 RANDOM STROBE · Slow 0.1 Hz 125–129 Shutter Open 130–130 RANDOM STROBE 100-0% · Fast 20 Hz 131–143 RANDOM STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 144–144 RANDOM STROBE 100-0% · Slow 0.1 Hz 145–149 Shutter Open 150–150 RANDOM STROBE 0-100% · Fast 20 Hz 151–163 RANDOM STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 164–164 RANDOM STROBE 0-100% · Slow 0.1 Hz 165–169 Shutter Open 170–170 PULSE STROBE · Fast 20 Hz 171–183 PULSE STROBE · Fast > Slow 18.6–1.52 Hz 184–184 PULSE STROBE · Slow 0.1 Hz 185–189 Shutter Open 190–190 RANDOM PULSE STROBE · Fast 20 Hz 191–203 RANDOM PULSE STROBE · Fast > Slow 18.6–1.52 Hz 204–204 RANDOM PULSE STROBE · Slow 0.1 Hz 205–209 Shutter Open 210–210 STROBE 0-100-0% · Fast 20 Hz 211–223 STROBE 0-100-0% · Fast > Slow 18.6–1.52 Hz 224–224 STROBE 0-100-0% · Slow 0.1 Hz 225–229 Shutter Open 230–230 RANDOM PULSE STROBE 1 · Fast 20 Hz 231–243 RANDOM PULSE STROBE 1 · Fast > Slow 18.6–1.52 … 244–244 RANDOM PULSE STROBE 1 · Slow 0.1 Hz 245–255 Shutter Open
87	Red	255	
88	Red Fine	255	Fine byte of Red
89	Green	255	
90	Green Fine	255	Fine byte of Green
91	Blue	255	
92	Blue Fine	255	Fine byte of Blue
93	White	255	
94	White Fine	255	Fine byte of White
95	Dimmer	255	
96	Dimmer Fine	255	Fine byte of Dimmer

Single Control: Full PXL Mode 182ch (continued)

Ch	Function	Default	DMX values
97	Shutter / Strobe	22	0–19 Shutter Closed 20–24 Shutter Open 25–25 STROBE · Fast 20 Hz 26–63 STROBE · Fast > Slow 19.5–0.61 Hz 64–64 STROBE · Slow 0.1 Hz 65–69 Shutter Open 70–70 STROBE 100-0% · Fast 20 Hz 71–83 STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 84–84 STROBE 100-0% · Slow 0.1 Hz 85–89 Shutter Open 90–90 STROBE 0-100% · Fast 20 Hz 91–103 STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 104–104 STROBE 0-100% · Slow 0.1 Hz 105–109 Shutter Open 110–110 RANDOM STROBE · Fast 20 Hz 111–123 RANDOM STROBE · Fast > Slow 18.6–1.52 Hz 124–124 RANDOM STROBE · Slow 0.1 Hz 125–129 Shutter Open 130–130 RANDOM STROBE 100-0% · Fast 20 Hz 131–143 RANDOM STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 144–144 RANDOM STROBE 100-0% · Slow 0.1 Hz 145–149 Shutter Open 150–150 RANDOM STROBE 0-100% · Fast 20 Hz 151–163 RANDOM STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 164–164 RANDOM STROBE 0-100% · Slow 0.1 Hz 165–169 Shutter Open 170–170 PULSE STROBE · Fast 20 Hz 171–183 PULSE STROBE · Fast > Slow 18.6–1.52 Hz 184–184 PULSE STROBE · Slow 0.1 Hz 185–189 Shutter Open 190–190 RANDOM PULSE STROBE · Fast 20 Hz 191–203 RANDOM PULSE STROBE · Fast > Slow 18.6–1.52 Hz 204–204 RANDOM PULSE STROBE · Slow 0.1 Hz 205–209 Shutter Open 210–210 STROBE 0-100-0% · Fast 20 Hz 211–223 STROBE 0-100-0% · Fast > Slow 18.6–1.52 Hz 224–224 STROBE 0-100-0% · Slow 0.1 Hz 225–229 Shutter Open 230–230 RANDOM PULSE STROBE 1 · Fast 20 Hz 231–243 RANDOM PULSE STROBE 1 · Fast > Slow 18.6–1.52 … 244–244 RANDOM PULSE STROBE 1 · Slow 0.1 Hz 245–255 Shutter Open
98	Red	255	
99	Red Fine	255	Fine byte of Red
100	Green	255	
101	Green Fine	255	Fine byte of Green
102	Blue	255	
103	Blue Fine	255	Fine byte of Blue
104	White	255	
105	White Fine	255	Fine byte of White
106	Dimmer	255	
107	Dimmer Fine	255	Fine byte of Dimmer

Single Control: Full PXL Mode 182ch (continued)

Ch	Function	Default	DMX values
108	Shutter / Strobe	22	0–19 Shutter Closed 20–24 Shutter Open 25–25 STROBE · Fast 20 Hz 26–63 STROBE · Fast > Slow 19.5–0.61 Hz 64–64 STROBE · Slow 0.1 Hz 65–69 Shutter Open 70–70 STROBE 100-0% · Fast 20 Hz 71–83 STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 84–84 STROBE 100-0% · Slow 0.1 Hz 85–89 Shutter Open 90–90 STROBE 0-100% · Fast 20 Hz 91–103 STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 104–104 STROBE 0-100% · Slow 0.1 Hz 105–109 Shutter Open 110–110 RANDOM STROBE · Fast 20 Hz 111–123 RANDOM STROBE · Fast > Slow 18.6–1.52 Hz 124–124 RANDOM STROBE · Slow 0.1 Hz 125–129 Shutter Open 130–130 RANDOM STROBE 100-0% · Fast 20 Hz 131–143 RANDOM STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 144–144 RANDOM STROBE 100-0% · Slow 0.1 Hz 145–149 Shutter Open 150–150 RANDOM STROBE 0-100% · Fast 20 Hz 151–163 RANDOM STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 164–164 RANDOM STROBE 0-100% · Slow 0.1 Hz 165–169 Shutter Open 170–170 PULSE STROBE · Fast 20 Hz 171–183 PULSE STROBE · Fast > Slow 18.6–1.52 Hz 184–184 PULSE STROBE · Slow 0.1 Hz 185–189 Shutter Open 190–190 RANDOM PULSE STROBE · Fast 20 Hz 191–203 RANDOM PULSE STROBE · Fast > Slow 18.6–1.52 Hz 204–204 RANDOM PULSE STROBE · Slow 0.1 Hz 205–209 Shutter Open 210–210 STROBE 0-100-0% · Fast 20 Hz 211–223 STROBE 0-100-0% · Fast > Slow 18.6–1.52 Hz 224–224 STROBE 0-100-0% · Slow 0.1 Hz 225–229 Shutter Open 230–230 RANDOM PULSE STROBE 1 · Fast 20 Hz 231–243 RANDOM PULSE STROBE 1 · Fast > Slow 18.6–1.52 … 244–244 RANDOM PULSE STROBE 1 · Slow 0.1 Hz 245–255 Shutter Open
109	Red	255	
110	Red Fine	255	Fine byte of Red
111	Green	255	
112	Green Fine	255	Fine byte of Green
113	Blue	255	
114	Blue Fine	255	Fine byte of Blue
115	White	255	
116	White Fine	255	Fine byte of White
117	Dimmer	255	
118	Dimmer Fine	255	Fine byte of Dimmer

Single Control: Full PXL Mode 182ch (continued)

Ch	Function	Default	DMX values
119	Shutter / Strobe	22	0–19 Shutter Closed 20–24 Shutter Open 25–25 STROBE · Fast 20 Hz 26–63 STROBE · Fast > Slow 19.5–0.61 Hz 64–64 STROBE · Slow 0.1 Hz 65–69 Shutter Open 70–70 STROBE 100-0% · Fast 20 Hz 71–83 STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 84–84 STROBE 100-0% · Slow 0.1 Hz 85–89 Shutter Open 90–90 STROBE 0-100% · Fast 20 Hz 91–103 STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 104–104 STROBE 0-100% · Slow 0.1 Hz 105–109 Shutter Open 110–110 RANDOM STROBE · Fast 20 Hz 111–123 RANDOM STROBE · Fast > Slow 18.6–1.52 Hz 124–124 RANDOM STROBE · Slow 0.1 Hz 125–129 Shutter Open 130–130 RANDOM STROBE 100-0% · Fast 20 Hz 131–143 RANDOM STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 144–144 RANDOM STROBE 100-0% · Slow 0.1 Hz 145–149 Shutter Open 150–150 RANDOM STROBE 0-100% · Fast 20 Hz 151–163 RANDOM STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 164–164 RANDOM STROBE 0-100% · Slow 0.1 Hz 165–169 Shutter Open 170–170 PULSE STROBE · Fast 20 Hz 171–183 PULSE STROBE · Fast > Slow 18.6–1.52 Hz 184–184 PULSE STROBE · Slow 0.1 Hz 185–189 Shutter Open 190–190 RANDOM PULSE STROBE · Fast 20 Hz 191–203 RANDOM PULSE STROBE · Fast > Slow 18.6–1.52 Hz 204–204 RANDOM PULSE STROBE · Slow 0.1 Hz 205–209 Shutter Open 210–210 STROBE 0-100-0% · Fast 20 Hz 211–223 STROBE 0-100-0% · Fast > Slow 18.6–1.52 Hz 224–224 STROBE 0-100-0% · Slow 0.1 Hz 225–229 Shutter Open 230–230 RANDOM PULSE STROBE 1 · Fast 20 Hz 231–243 RANDOM PULSE STROBE 1 · Fast > Slow 18.6–1.52 … 244–244 RANDOM PULSE STROBE 1 · Slow 0.1 Hz 245–255 Shutter Open
120	Red	255	
121	Red Fine	255	Fine byte of Red
122	Green	255	
123	Green Fine	255	Fine byte of Green
124	Blue	255	
125	Blue Fine	255	Fine byte of Blue
126	White	255	
127	White Fine	255	Fine byte of White
128	Dimmer	255	
129	Dimmer Fine	255	Fine byte of Dimmer

Single Control: Full PXL Mode 182ch (continued)

Ch	Function	Default	DMX values
130	Shutter / Strobe	22	0–19 Shutter Closed 20–24 Shutter Open 25–25 STROBE · Fast 20 Hz 26–63 STROBE · Fast > Slow 19.5–0.61 Hz 64–64 STROBE · Slow 0.1 Hz 65–69 Shutter Open 70–70 STROBE 100-0% · Fast 20 Hz 71–83 STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 84–84 STROBE 100-0% · Slow 0.1 Hz 85–89 Shutter Open 90–90 STROBE 0-100% · Fast 20 Hz 91–103 STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 104–104 STROBE 0-100% · Slow 0.1 Hz 105–109 Shutter Open 110–110 RANDOM STROBE · Fast 20 Hz 111–123 RANDOM STROBE · Fast > Slow 18.6–1.52 Hz 124–124 RANDOM STROBE · Slow 0.1 Hz 125–129 Shutter Open 130–130 RANDOM STROBE 100-0% · Fast 20 Hz 131–143 RANDOM STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 144–144 RANDOM STROBE 100-0% · Slow 0.1 Hz 145–149 Shutter Open 150–150 RANDOM STROBE 0-100% · Fast 20 Hz 151–163 RANDOM STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 164–164 RANDOM STROBE 0-100% · Slow 0.1 Hz 165–169 Shutter Open 170–170 PULSE STROBE · Fast 20 Hz 171–183 PULSE STROBE · Fast > Slow 18.6–1.52 Hz 184–184 PULSE STROBE · Slow 0.1 Hz 185–189 Shutter Open 190–190 RANDOM PULSE STROBE · Fast 20 Hz 191–203 RANDOM PULSE STROBE · Fast > Slow 18.6–1.52 Hz 204–204 RANDOM PULSE STROBE · Slow 0.1 Hz 205–209 Shutter Open 210–210 STROBE 0-100-0% · Fast 20 Hz 211–223 STROBE 0-100-0% · Fast > Slow 18.6–1.52 Hz 224–224 STROBE 0-100-0% · Slow 0.1 Hz 225–229 Shutter Open 230–230 RANDOM PULSE STROBE 1 · Fast 20 Hz 231–243 RANDOM PULSE STROBE 1 · Fast > Slow 18.6–1.52 … 244–244 RANDOM PULSE STROBE 1 · Slow 0.1 Hz 245–255 Shutter Open
131	Red	255	
132	Red Fine	255	Fine byte of Red
133	Green	255	
134	Green Fine	255	Fine byte of Green
135	Blue	255	
136	Blue Fine	255	Fine byte of Blue
137	White	255	
138	White Fine	255	Fine byte of White
139	Dimmer	255	
140	Dimmer Fine	255	Fine byte of Dimmer

Single Control: Full PXL Mode 182ch (continued)

Ch	Function	Default	DMX values
141	Shutter / Strobe	22	0–19 Shutter Closed 20–24 Shutter Open 25–25 STROBE · Fast 20 Hz 26–63 STROBE · Fast > Slow 19.5–0.61 Hz 64–64 STROBE · Slow 0.1 Hz 65–69 Shutter Open 70–70 STROBE 100-0% · Fast 20 Hz 71–83 STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 84–84 STROBE 100-0% · Slow 0.1 Hz 85–89 Shutter Open 90–90 STROBE 0-100% · Fast 20 Hz 91–103 STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 104–104 STROBE 0-100% · Slow 0.1 Hz 105–109 Shutter Open 110–110 RANDOM STROBE · Fast 20 Hz 111–123 RANDOM STROBE · Fast > Slow 18.6–1.52 Hz 124–124 RANDOM STROBE · Slow 0.1 Hz 125–129 Shutter Open 130–130 RANDOM STROBE 100-0% · Fast 20 Hz 131–143 RANDOM STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 144–144 RANDOM STROBE 100-0% · Slow 0.1 Hz 145–149 Shutter Open 150–150 RANDOM STROBE 0-100% · Fast 20 Hz 151–163 RANDOM STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 164–164 RANDOM STROBE 0-100% · Slow 0.1 Hz 165–169 Shutter Open 170–170 PULSE STROBE · Fast 20 Hz 171–183 PULSE STROBE · Fast > Slow 18.6–1.52 Hz 184–184 PULSE STROBE · Slow 0.1 Hz 185–189 Shutter Open 190–190 RANDOM PULSE STROBE · Fast 20 Hz 191–203 RANDOM PULSE STROBE · Fast > Slow 18.6–1.52 Hz 204–204 RANDOM PULSE STROBE · Slow 0.1 Hz 205–209 Shutter Open 210–210 STROBE 0-100-0% · Fast 20 Hz 211–223 STROBE 0-100-0% · Fast > Slow 18.6–1.52 Hz 224–224 STROBE 0-100-0% · Slow 0.1 Hz 225–229 Shutter Open 230–230 RANDOM PULSE STROBE 1 · Fast 20 Hz 231–243 RANDOM PULSE STROBE 1 · Fast > Slow 18.6–1.52 … 244–244 RANDOM PULSE STROBE 1 · Slow 0.1 Hz 245–255 Shutter Open
142	Red	255	
143	Red Fine	255	Fine byte of Red
144	Green	255	
145	Green Fine	255	Fine byte of Green
146	Blue	255	
147	Blue Fine	255	Fine byte of Blue
148	White	255	
149	White Fine	255	Fine byte of White
150	Dimmer	255	
151	Dimmer Fine	255	Fine byte of Dimmer

Single Control: Full PXL Mode 182ch (continued)

Ch	Function	Default	DMX values
152	Shutter / Strobe	22	0–19 Shutter Closed 20–24 Shutter Open 25–25 STROBE · Fast 20 Hz 26–63 STROBE · Fast > Slow 19.5–0.61 Hz 64–64 STROBE · Slow 0.1 Hz 65–69 Shutter Open 70–70 STROBE 100-0% · Fast 20 Hz 71–83 STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 84–84 STROBE 100-0% · Slow 0.1 Hz 85–89 Shutter Open 90–90 STROBE 0-100% · Fast 20 Hz 91–103 STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 104–104 STROBE 0-100% · Slow 0.1 Hz 105–109 Shutter Open 110–110 RANDOM STROBE · Fast 20 Hz 111–123 RANDOM STROBE · Fast > Slow 18.6–1.52 Hz 124–124 RANDOM STROBE · Slow 0.1 Hz 125–129 Shutter Open 130–130 RANDOM STROBE 100-0% · Fast 20 Hz 131–143 RANDOM STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 144–144 RANDOM STROBE 100-0% · Slow 0.1 Hz 145–149 Shutter Open 150–150 RANDOM STROBE 0-100% · Fast 20 Hz 151–163 RANDOM STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 164–164 RANDOM STROBE 0-100% · Slow 0.1 Hz 165–169 Shutter Open 170–170 PULSE STROBE · Fast 20 Hz 171–183 PULSE STROBE · Fast > Slow 18.6–1.52 Hz 184–184 PULSE STROBE · Slow 0.1 Hz 185–189 Shutter Open 190–190 RANDOM PULSE STROBE · Fast 20 Hz 191–203 RANDOM PULSE STROBE · Fast > Slow 18.6–1.52 Hz 204–204 RANDOM PULSE STROBE · Slow 0.1 Hz 205–209 Shutter Open 210–210 STROBE 0-100-0% · Fast 20 Hz 211–223 STROBE 0-100-0% · Fast > Slow 18.6–1.52 Hz 224–224 STROBE 0-100-0% · Slow 0.1 Hz 225–229 Shutter Open 230–230 RANDOM PULSE STROBE 1 · Fast 20 Hz 231–243 RANDOM PULSE STROBE 1 · Fast > Slow 18.6–1.52 … 244–244 RANDOM PULSE STROBE 1 · Slow 0.1 Hz 245–255 Shutter Open
153	Red	255	
154	Red Fine	255	Fine byte of Red
155	Green	255	
156	Green Fine	255	Fine byte of Green
157	Blue	255	
158	Blue Fine	255	Fine byte of Blue
159	White	255	
160	White Fine	255	Fine byte of White
161	Dimmer	255	
162	Dimmer Fine	255	Fine byte of Dimmer

Single Control: Full PXL Mode 182ch (continued)

Ch	Function	Default	DMX values
163	Shutter / Strobe	22	0–19 Shutter Closed 20–24 Shutter Open 25–25 STROBE · Fast 20 Hz 26–63 STROBE · Fast > Slow 19.5–0.61 Hz 64–64 STROBE · Slow 0.1 Hz 65–69 Shutter Open 70–70 STROBE 100-0% · Fast 20 Hz 71–83 STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 84–84 STROBE 100-0% · Slow 0.1 Hz 85–89 Shutter Open 90–90 STROBE 0-100% · Fast 20 Hz 91–103 STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 104–104 STROBE 0-100% · Slow 0.1 Hz 105–109 Shutter Open 110–110 RANDOM STROBE · Fast 20 Hz 111–123 RANDOM STROBE · Fast > Slow 18.6–1.52 Hz 124–124 RANDOM STROBE · Slow 0.1 Hz 125–129 Shutter Open 130–130 RANDOM STROBE 100-0% · Fast 20 Hz 131–143 RANDOM STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 144–144 RANDOM STROBE 100-0% · Slow 0.1 Hz 145–149 Shutter Open 150–150 RANDOM STROBE 0-100% · Fast 20 Hz 151–163 RANDOM STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 164–164 RANDOM STROBE 0-100% · Slow 0.1 Hz 165–169 Shutter Open 170–170 PULSE STROBE · Fast 20 Hz 171–183 PULSE STROBE · Fast > Slow 18.6–1.52 Hz 184–184 PULSE STROBE · Slow 0.1 Hz 185–189 Shutter Open 190–190 RANDOM PULSE STROBE · Fast 20 Hz 191–203 RANDOM PULSE STROBE · Fast > Slow 18.6–1.52 Hz 204–204 RANDOM PULSE STROBE · Slow 0.1 Hz 205–209 Shutter Open 210–210 STROBE 0-100-0% · Fast 20 Hz 211–223 STROBE 0-100-0% · Fast > Slow 18.6–1.52 Hz 224–224 STROBE 0-100-0% · Slow 0.1 Hz 225–229 Shutter Open 230–230 RANDOM PULSE STROBE 1 · Fast 20 Hz 231–243 RANDOM PULSE STROBE 1 · Fast > Slow 18.6–1.52 … 244–244 RANDOM PULSE STROBE 1 · Slow 0.1 Hz 245–255 Shutter Open
164	Red	255	
165	Red Fine	255	Fine byte of Red
166	Green	255	
167	Green Fine	255	Fine byte of Green
168	Blue	255	
169	Blue Fine	255	Fine byte of Blue
170	White	255	
171	White Fine	255	Fine byte of White
172	Dimmer	255	
173	Dimmer Fine	255	Fine byte of Dimmer

Single Control: Full PXL Mode 182ch (continued)

Ch	Function	Default	DMX values
174	Shutter / Strobe	22	0–19 Shutter Closed 20–24 Shutter Open 25–25 STROBE · Fast 20 Hz 26–63 STROBE · Fast > Slow 19.5–0.61 Hz 64–64 STROBE · Slow 0.1 Hz 65–69 Shutter Open 70–70 STROBE 100-0% · Fast 20 Hz 71–83 STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 84–84 STROBE 100-0% · Slow 0.1 Hz 85–89 Shutter Open 90–90 STROBE 0-100% · Fast 20 Hz 91–103 STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 104–104 STROBE 0-100% · Slow 0.1 Hz 105–109 Shutter Open 110–110 RANDOM STROBE · Fast 20 Hz 111–123 RANDOM STROBE · Fast > Slow 18.6–1.52 Hz 124–124 RANDOM STROBE · Slow 0.1 Hz 125–129 Shutter Open 130–130 RANDOM STROBE 100-0% · Fast 20 Hz 131–143 RANDOM STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 144–144 RANDOM STROBE 100-0% · Slow 0.1 Hz 145–149 Shutter Open 150–150 RANDOM STROBE 0-100% · Fast 20 Hz 151–163 RANDOM STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 164–164 RANDOM STROBE 0-100% · Slow 0.1 Hz 165–169 Shutter Open 170–170 PULSE STROBE · Fast 20 Hz 171–183 PULSE STROBE · Fast > Slow 18.6–1.52 Hz 184–184 PULSE STROBE · Slow 0.1 Hz 185–189 Shutter Open 190–190 RANDOM PULSE STROBE · Fast 20 Hz 191–203 RANDOM PULSE STROBE · Fast > Slow 18.6–1.52 Hz 204–204 RANDOM PULSE STROBE · Slow 0.1 Hz 205–209 Shutter Open 210–210 STROBE 0-100-0% · Fast 20 Hz 211–223 STROBE 0-100-0% · Fast > Slow 18.6–1.52 Hz 224–224 STROBE 0-100-0% · Slow 0.1 Hz 225–229 Shutter Open 230–230 RANDOM PULSE STROBE 1 · Fast 20 Hz 231–243 RANDOM PULSE STROBE 1 · Fast > Slow 18.6–1.52 … 244–244 RANDOM PULSE STROBE 1 · Slow 0.1 Hz 245–255 Shutter Open
175	Red	255	
176	Red Fine	255	Fine byte of Red
177	Green	255	
178	Green Fine	255	Fine byte of Green
179	Blue	255	
180	Blue Fine	255	Fine byte of Blue
181	White	255	
182	White Fine	255	Fine byte of White

Single Control: Tour Mode 186ch

186 channels

Ch	Function	Default	DMX values
1	Tilt	127	
2	Tilt Fine	255	Fine byte of Tilt
3	Position MSpeed	0	

Single Control: Tour Mode 186ch (continued)

Ch	Function	Default	DMX values
4	C TC	0	
5	Color Macro1	0	

Single Control: Tour Mode 186ch (continued)

Ch	Function	Default	DMX values
6	Effect	0	0–0 Open 1–1 Pattern 1 - Macro 2–2 Pattern 2 - Macro 3–3 Pattern 3 - Macro 4–4 Pattern 4 - Macro 5–5 Pattern 5 - Macro 6–6 Pattern 6 - Macro 7–7 Pattern 7 - Macro 8–8 Pattern 8 - Macro 9–9 Pattern 9 - Macro 10–10 Pattern 10 - Macro 11–11 Pattern 11 - Macro 12–12 Pattern 12 - Macro 13–13 Pattern 13 - Macro 14–14 Pattern 14 - Macro 15–15 Pattern 15 - Macro 16–16 Pattern 16 - Macro 17–17 Pattern 17 - Macro 18–18 Pattern 18 - Macro 19–19 Pattern 19 - Macro 20–20 Pattern 20 - Macro 21–21 Pattern 21 - Macro 22–22 Pattern 22 - Macro 23–23 Pattern 23 - Macro 24–24 Pattern 24 - Macro 25–25 Pattern 25 - Macro 26–26 Pattern 26 - Macro 27–27 Pattern 27 - Macro 28–28 Pattern 28 - Macro 29–29 Pattern 29 - Macro 30–30 Pattern 30 - Macro 31–31 Pattern 31 - Macro 32–32 Pattern 32 - Macro 33–33 Pattern 33 - Macro 34–34 Pattern 34 - Macro 35–35 Pattern 35 - Macro 36–36 Pattern 36 - Macro 37–37 Pattern 37 - Macro 38–38 Pattern 38 - Macro 39–39 Pattern 39 - Macro 40–40 Pattern 40 - Macro 41–41 Pattern 41 - Macro 42–42 Pattern 42 - Macro 43–43 Pattern 43 - Macro 44–44 Pattern 44 - Macro 45–45 Pattern 45 - Macro 46–46 Pattern 46 - Macro 47–47 Pattern 47 - Macro 48–48 Pattern 48 - Macro 49–49 Pattern 49 - Macro 50–50 Pattern 50 - Macro 51–51 Pattern 51 - Macro 52–52 Pattern 52 - Macro 53–53 Pattern 53 - Macro 54–54 Pattern 54 - Macro 55–55 Pattern 55 - Macro 56–56 Pattern 56 - Macro 57–57 Pattern 57 - Macro 58–58 Pattern 58 - Macro 59–59 Pattern 59 - Macro 60–60 Pattern 60 - Macro 61–61 Pattern 61 - Macro 62–62 Pattern 62 - Macro 63–63 Pattern 63 - Macro

Single Control: Tour Mode 186ch (continued)

Ch	Function	Default	DMX values
7	Effect 2	0	0–15 LED Built-In Open 16–17 LED Built-In 1 - Macro 18–19 LED Built-In 2 - Macro 20–21 LED Built-In 3 - Macro 22–23 LED Built-In 4 - Macro 24–25 LED Built-In 5 - Macro 26–27 LED Built-In 6 - Macro 28–29 LED Built-In 7 - Macro 30–31 LED Built-In 8 - Macro 32–33 LED Built-In 9 - Macro 34–35 LED Built-In 10 - Macro 36–37 LED Built-In 11 - Macro 38–39 LED Built-In 12 - Macro 40–41 LED Built-In 13 - Macro 42–43 LED Built-In 14 - Macro 44–45 LED Built-In 15 - Macro 46–47 LED Built-In 16 - Macro 48–49 LED Built-In 17 - Macro 50–51 LED Built-In 18 - Macro 52–53 LED Built-In 19 - Macro 54–55 LED Built-In 20 - Macro 56–57 LED Built-In 21 - Macro 58–59 LED Built-In 22 - Macro 60–61 LED Built-In 23 - Macro 62–63 LED Built-In 24 - Macro 64–65 LED Built-In 25 - Macro 66–67 LED Built-In 26 - Macro 68–69 LED Built-In 27 - Macro 70–71 LED Built-In 28 - Macro 72–73 LED Built-In 29 - Macro 74–75 LED Built-In 30 - Macro 76–77 LED Built-In 31 - Macro 78–79 LED Built-In 32 - Macro 80–81 LED Built-In 33 - Macro 82–83 LED Built-In 34 - Macro 84–85 LED Built-In 35 - Macro 86–87 LED Built-In 36 - Macro 88–89 LED Built-In 37 - Macro 90–91 LED Built-In 38 - Macro 92–93 LED Built-In 39 - Macro 94–95 LED Built-In 40 - Macro 96–97 LED Built-In 41 - Macro 98–99 LED Built-In 42 - Macro 100–101 LED Built-In 43 - Macro 102–103 LED Built-In 44 - Macro 104–105 LED Built-In 45 - Macro 106–107 LED Built-In 46 - Macro 108–109 LED Built-In 47 - Macro 110–111 LED Built-In 48 - Macro 112–113 LED Built-In 49 - Macro 114–115 LED Built-In 50 - Macro 116–117 LED Built-In 51 - Macro 118–119 LED Built-In 52 - Macro 120–121 LED Built-In 53 - Macro 122–123 LED Built-In 54 - Macro 124–125 LED Built-In 55 - Macro 126–127 LED Built-In 56 - Macro 128–129 LED Built-In 57 - Macro 130–131 LED Built-In 58 - Macro 132–133 LED Built-In 59 - Macro 134–135 LED Built-In 60 - Macro 136–137 LED Built-In 61 - Macro 138–139 LED Built-In 62 - Macro 140–141 LED Built-In 63 - Macro

Single Control: Tour Mode 186ch (continued)

Ch	Function	Default	DMX values
8	Effect Speed 2	128	
9	Effects2Adjust1	0	
10	Color Macro2	0	
11	Background Dimmer	0	
12	Background Dimmer Fine	0	Fine byte of Background Dimmer
13	Dimmer	0	
14	Dimmer Fine	0	Fine byte of Dimmer
15	Shutter / Strobe	22	0–19 Shutter Closed 20–24 Shutter Open 25–25 STROBE · Fast 20 Hz 26–63 STROBE · Fast > Slow 19.5–0.61 Hz 64–64 STROBE · Slow 0.1 Hz 65–69 Shutter Open 70–70 STROBE 100-0% · Fast 20 Hz 71–83 STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 84–84 STROBE 100-0% · Slow 0.1 Hz 85–89 Shutter Open 90–90 STROBE 0-100% · Fast 20 Hz 91–103 STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 104–104 STROBE 0-100% · Slow 0.1 Hz 105–109 Shutter Open 110–110 RANDOM STROBE · Fast 20 Hz 111–123 RANDOM STROBE · Fast > Slow 18.6–1.52 Hz 124–124 RANDOM STROBE · Slow 0.1 Hz 125–129 Shutter Open 130–130 RANDOM STROBE 100-0% · Fast 20 Hz 131–143 RANDOM STROBE 100-0% · Fast > Slow 18.6–1.52 Hz 144–144 RANDOM STROBE 100-0% · Slow 0.1 Hz 145–149 Shutter Open 150–150 RANDOM STROBE 0-100% · Fast 20 Hz 151–163 RANDOM STROBE 0-100% · Fast > Slow 18.6–1.52 Hz 164–164 RANDOM STROBE 0-100% · Slow 0.1 Hz 165–169 Shutter Open 170–170 PULSE STROBE · Fast 20 Hz 171–183 PULSE STROBE · Fast > Slow 18.6–1.52 Hz 184–184 PULSE STROBE · Slow 0.1 Hz 185–189 Shutter Open 190–190 RANDOM PULSE STROBE · Fast 20 Hz 191–203 RANDOM PULSE STROBE · Fast > Slow 18.6–1.52 Hz 204–204 RANDOM PULSE STROBE · Slow 0.1 Hz 205–209 Shutter Open 210–210 STROBE 0-100-0% · Fast 20 Hz 211–223 STROBE 0-100-0% · Fast > Slow 18.6–1.52 Hz 224–224 STROBE 0-100-0% · Slow 0.1 Hz 225–229 Shutter Open 230–230 RANDOM PULSE STROBE 1 · Fast 20 Hz 231–243 RANDOM PULSE STROBE 1 · Fast > Slow 18.6–1.52 … 244–244 RANDOM PULSE STROBE 1 · Slow 0.1 Hz 245–255 Shutter Open
16	Zoom	127	
17	Zoom	127	
18	Control1	0	
19	R Overwrite	0	
20	R Overwrite Fine	0	Fine byte of R Overwrite
21	G Overwrite	0	
22	G Overwrite Fine	0	Fine byte of G Overwrite
23	B Overwrite	0	

Single Control: Tour Mode 186ch (continued)

Ch	Function	Default	DMX values
24	B Overwrite Fine	0	Fine byte of B Overwrite
25	W Overwrite	0	
26	W Overwrite Fine	0	Fine byte of W Overwrite
27	Dimmer	255	
28	Dimmer Fine	255	Fine byte of Dimmer
29	Red	255	
30	Red Fine	255	Fine byte of Red
31	Green	255	
32	Green Fine	255	Fine byte of Green
33	Blue	255	
34	Blue Fine	255	Fine byte of Blue
35	White	255	
36	White Fine	255	Fine byte of White
37	Dimmer	255	
38	Dimmer Fine	255	Fine byte of Dimmer
39	Red	255	
40	Red Fine	255	Fine byte of Red
41	Green	255	
42	Green Fine	255	Fine byte of Green
43	Blue	255	
44	Blue Fine	255	Fine byte of Blue
45	White	255	
46	White Fine	255	Fine byte of White
47	Dimmer	255	
48	Dimmer Fine	255	Fine byte of Dimmer
49	Red	255	
50	Red Fine	255	Fine byte of Red
51	Green	255	
52	Green Fine	255	Fine byte of Green
53	Blue	255	
54	Blue Fine	255	Fine byte of Blue
55	White	255	
56	White Fine	255	Fine byte of White
57	Dimmer	255	
58	Dimmer Fine	255	Fine byte of Dimmer
59	Red	255	
60	Red Fine	255	Fine byte of Red
61	Green	255	
62	Green Fine	255	Fine byte of Green
63	Blue	255	
64	Blue Fine	255	Fine byte of Blue
65	White	255	
66	White Fine	255	Fine byte of White
67	Dimmer	255	
68	Dimmer Fine	255	Fine byte of Dimmer

Single Control: Tour Mode 186ch (continued)

Ch	Function	Default	DMX values
69	Red	255	
70	Red Fine	255	Fine byte of Red
71	Green	255	
72	Green Fine	255	Fine byte of Green
73	Blue	255	
74	Blue Fine	255	Fine byte of Blue
75	White	255	
76	White Fine	255	Fine byte of White
77	Dimmer	255	
78	Dimmer Fine	255	Fine byte of Dimmer
79	Red	255	
80	Red Fine	255	Fine byte of Red
81	Green	255	
82	Green Fine	255	Fine byte of Green
83	Blue	255	
84	Blue Fine	255	Fine byte of Blue
85	White	255	
86	White Fine	255	Fine byte of White
87	Dimmer	255	
88	Dimmer Fine	255	Fine byte of Dimmer
89	Red	255	
90	Red Fine	255	Fine byte of Red
91	Green	255	
92	Green Fine	255	Fine byte of Green
93	Blue	255	
94	Blue Fine	255	Fine byte of Blue
95	White	255	
96	White Fine	255	Fine byte of White
97	Dimmer	255	
98	Dimmer Fine	255	Fine byte of Dimmer
99	Red	255	
100	Red Fine	255	Fine byte of Red
101	Green	255	
102	Green Fine	255	Fine byte of Green
103	Blue	255	
104	Blue Fine	255	Fine byte of Blue
105	White	255	
106	White Fine	255	Fine byte of White
107	Dimmer	255	
108	Dimmer Fine	255	Fine byte of Dimmer
109	Red	255	
110	Red Fine	255	Fine byte of Red
111	Green	255	
112	Green Fine	255	Fine byte of Green
113	Blue	255	

Single Control: Tour Mode 186ch (continued)

Ch	Function	Default	DMX values
114	Blue Fine	255	Fine byte of Blue
115	White	255	
116	White Fine	255	Fine byte of White
117	Dimmer	255	
118	Dimmer Fine	255	Fine byte of Dimmer
119	Red	255	
120	Red Fine	255	Fine byte of Red
121	Green	255	
122	Green Fine	255	Fine byte of Green
123	Blue	255	
124	Blue Fine	255	Fine byte of Blue
125	White	255	
126	White Fine	255	Fine byte of White
127	Dimmer	255	
128	Dimmer Fine	255	Fine byte of Dimmer
129	Red	255	
130	Red Fine	255	Fine byte of Red
131	Green	255	
132	Green Fine	255	Fine byte of Green
133	Blue	255	
134	Blue Fine	255	Fine byte of Blue
135	White	255	
136	White Fine	255	Fine byte of White
137	Dimmer	255	
138	Dimmer Fine	255	Fine byte of Dimmer
139	Red	255	
140	Red Fine	255	Fine byte of Red
141	Green	255	
142	Green Fine	255	Fine byte of Green
143	Blue	255	
144	Blue Fine	255	Fine byte of Blue
145	White	255	
146	White Fine	255	Fine byte of White
147	Dimmer	255	
148	Dimmer Fine	255	Fine byte of Dimmer
149	Red	255	
150	Red Fine	255	Fine byte of Red
151	Green	255	
152	Green Fine	255	Fine byte of Green
153	Blue	255	
154	Blue Fine	255	Fine byte of Blue
155	White	255	
156	White Fine	255	Fine byte of White
157	Dimmer	255	
158	Dimmer Fine	255	Fine byte of Dimmer

Single Control: Tour Mode 186ch (continued)

Ch	Function	Default	DMX values
159	Red	255	
160	Red Fine	255	Fine byte of Red
161	Green	255	
162	Green Fine	255	Fine byte of Green
163	Blue	255	
164	Blue Fine	255	Fine byte of Blue
165	White	255	
166	White Fine	255	Fine byte of White
167	Dimmer	255	
168	Dimmer Fine	255	Fine byte of Dimmer
169	Red	255	
170	Red Fine	255	Fine byte of Red
171	Green	255	
172	Green Fine	255	Fine byte of Green
173	Blue	255	
174	Blue Fine	255	Fine byte of Blue
175	White	255	
176	White Fine	255	Fine byte of White
177	Dimmer	255	
178	Dimmer Fine	255	Fine byte of Dimmer
179	Red	255	
180	Red Fine	255	Fine byte of Red
181	Green	255	
182	Green Fine	255	Fine byte of Green
183	Blue	255	
184	Blue Fine	255	Fine byte of Blue
185	White	255	
186	White Fine	255	Fine byte of White