CKC Lighting

FC Pendant 300



Manufacturer	**CKC Lighting**
Type	**PAR**
DMX modes	**8**
DMX footprint	**1, 4, 5, 9, 10, 17 channels**
Beam angle	**45°**
Size (W × H × D)	**200 × 320 × 200 mm**
GDTF fixture type	**C122F142-0848-42F7-9049-CD…**

Controls

Extra LED colours · RGB colour mixing · Colour wheel · Strobe · Dimmer

Safety-relevant functions

Strobe

DMX modes

Dimmer 1CH	1 ch
Color 4CH	4 ch
HSI 4CH	4 ch
RGBWL 5CH	5 ch
HSI 9CH	9 ch
16bit 10CH	10 ch
Standard 10CH	10 ch
Extended 17CH	17 ch

Dimmer 1CH

1 channel

Ch	Function	Default	DMX values
1	Dimmer	0	0–62 0 percent 63–126 25 percent 127–190 50 percent 191–254 75 percent 255–255 100 percent

Color 4CH

4 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–62 0 percent 63–126 25 percent 127–190 50 percent 191–254 75 percent 255–255 100 percent
2	Dimmer Fine	0	Fine byte of Dimmer

Color 4CH (continued)

Ch	Function	Default	DMX values
3	Color Wheel	0	0–19 Open 20–20 2000 (wheel slot 2) 21–21 2100 (wheel slot 3) 22–22 2200 (wheel slot 4) 23–23 2300 (wheel slot 5) 24–24 2400 (wheel slot 6) 25–25 2500 (wheel slot 7) 26–26 2600 (wheel slot 8) 27–27 2700 (wheel slot 9) 28–28 2800 (wheel slot 10) 29–29 2900 (wheel slot 11) 30–30 3000 (wheel slot 12) 31–31 3100 (wheel slot 13) 32–32 3200 (wheel slot 14) 33–33 3300 (wheel slot 15) 34–34 3400 (wheel slot 16) 35–35 3500 (wheel slot 17) 36–36 3600 (wheel slot 18) 37–37 3700 (wheel slot 19) 38–38 3800 (wheel slot 20) 39–39 3900 (wheel slot 21) 40–40 4000 (wheel slot 22) 41–41 4100 (wheel slot 23) 42–42 4200 (wheel slot 24) 43–43 4300 (wheel slot 25) 44–44 4400 (wheel slot 26) 45–45 4500 (wheel slot 27) 46–46 4600 (wheel slot 28) 47–47 4700 (wheel slot 29) 48–48 4800 (wheel slot 30) 49–49 4900 (wheel slot 31) 50–50 5000 (wheel slot 32) 51–51 5100 (wheel slot 33) 52–52 5200 (wheel slot 34) 53–53 5300 (wheel slot 35) 54–54 5400 (wheel slot 36) 55–55 5500 (wheel slot 37) 56–56 56000 (wheel slot 38) 57–57 5700 (wheel slot 39) 58–58 5800 (wheel slot 40) 59–59 5900 (wheel slot 41) 60–60 6000 (wheel slot 42) 61–61 6100 (wheel slot 43) 62–62 6200 (wheel slot 44) 63–63 6300 (wheel slot 45) 64–64 6400 (wheel slot 46) 65–65 6500 (wheel slot 47) 66–66 6600 (wheel slot 48) 67–67 6700 (wheel slot 49) 68–68 6800 (wheel slot 50) 69–69 6900 (wheel slot 51) 70–70 7000 (wheel slot 52) 71–71 7100 (wheel slot 53) 72–72 7200 (wheel slot 54) 73–73 7300 (wheel slot 55) 74–74 7400 (wheel slot 56) 75–75 7500 (wheel slot 57) 76–76 7600 (wheel slot 58) 77–77 7700 (wheel slot 59) 78–78 7800 (wheel slot 60) 79–79 7900 (wheel slot 61) 80–80 8000 (wheel slot 62) 81–81 8100 (wheel slot 63) 82–100 8200 (wheel slot 64)

Color 4CH (continued)

Ch	Function	Default	DMX values
4	Color Wheel 2	0	0–0 Open 1–1 Pale Yellow (wheel slot 1) 2–2 Straw (wheel slot 2) 3–3 Gold Tint (wheel slot 3) 4–4 Spring Yellow (wheel slot 4) 5–5 Medium Yellow (wheel slot 5) 6–6 Yellow (wheel slot 6) 7–7 Deep Amber (wheel slot 7) 8–8 Deep Straw (wheel slot 8) 9–9 Loving Amber (wheel slot 9) 10–10 Gold Amber (wheel slot 10) 11–11 Orange (wheel slot 11) 12–12 Deep Orange (wheel slot 12) 13–13 Dark Amber (wheel slot 13) 14–14 Millennium Gold (wheel slot 14) 15–15 Deep Golden Amber (wheel slot 15) 16–16 Scarlet (wheel slot 16) 17–17 Primary Red (wheel slot 17) 18–18 Bright Red (wheel slot 18) 19–19 Medium Red (wheel slot 19) 20–20 Fire (wheel slot 20) 21–21 Pink (wheel slot 21) 22–22 Medium Pink (wheel slot 22) 23–23 Dark Pink (wheel slot 23) 24–24 Bright Pink (wheel slot 24) 25–25 Bright Rose (wheel slot 25) 26–26 Special Rose Pink (wheel slot 26) 27–27 Vanity Fair (wheel slot 27) 28–28 Magenta (wheel slot 28) 29–29 Dark Magenta (wheel slot 29) 30–30 Rose Purple (wheel slot 30) 31–31 Mauve (wheel slot 31) 32–32 Medium Purple (wheel slot 32) 33–33 Lavender (wheel slot 33) 34–34 Palace blue (wheel slot 34) 35–35 Dark Blue (wheel slot 35) 36–36 Medium Blue (wheel slot 36) 37–37 Deep Blue (wheel slot 37) 38–38 Daylight Blue (wheel slot 38) 39–39 Slate Blue (wheel slot 39) 40–40 Light Blue (wheel slot 40) 41–41 Sky Blue (wheel slot 41) 42–42 Pale Navy Blue (wheel slot 42) 43–43 Marine Blue (wheel slot 43) 44–44 Peacock Blue (wheel slot 44) 45–45 Lagoon Blue (wheel slot 45) 46–46 Medium Blue Green (wheel slot 46) 47–47 Dark Yellow Green (wheel slot 47) 48–48 Primary Green (wheel slot 48) 49–49 Fern Green (wheel slot 49) 50–50 Moss Green (wheel slot 50) 51–51 Dark Green (wheel slot 51) 52–52 Lime Green (wheel slot 52) 53–53 Pale Green (wheel slot 53) 54–54 Quarter CT Blue (wheel slot 54) 55–55 Half CT Blue (wheel slot 55) 56–56 Full CT Blue (wheel slot 56) 57–57 Double CT Blue (wheel slot 57) 58–58 Quarter CT Orange (wheel slot 58) 59–59 Half CT Orange (wheel slot 59) 60–60 Full CT Orange (wheel slot 60) 61–179 No Function 180–201 Clockwise fast to slow 202–207 Stop

HSI 4CH

4 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–62 0 percent 63–126 25 percent 127–190 50 percent 191–254 75 percent 255–255 100 percent
2	Dimmer Fine	0	Fine byte of Dimmer
3	H SBHue	0	
4	H SBSaturation	0	

RGBWL 5CH

5 channels

Ch	Function	Default	DMX values
1	Red	0	
2	Green	0	
3	Blue	0	
4	White	0	
5	Color Add GY	0	

HSI 9CH

9 channels

Ch	Function	Default	DMX values
1	Shutter / Strobe	50	0–31 Shutter Closed 32–63 No Function (Shutter Open) 64–95 Strobe Effect Slow to Fast 96–127 No Function (Shutter Open) 128–159 Pulse-Effect in Sequences 160–191 No Function (Shutter Open) 192–223 Random Strobe Effect Slow to Fast 224–255 No Function (Shutter Open)
2	Dimmer	0	0–62 0 percent 63–126 25 percent 127–190 50 percent 191–254 75 percent 255–255 100 percent
3	Dimmer Fine	0	Fine byte of Dimmer
4	H SBHue	0	
5	H SBSaturation	0	

HSI 9CH (continued)

Ch	Function	Default	DMX values
6	Color Wheel	0	0–19 Open 20–20 2000 (wheel slot 2) 21–21 2100 (wheel slot 3) 22–22 2200 (wheel slot 4) 23–23 2300 (wheel slot 5) 24–24 2400 (wheel slot 6) 25–25 2500 (wheel slot 7) 26–26 2600 (wheel slot 8) 27–27 2700 (wheel slot 9) 28–28 2800 (wheel slot 10) 29–29 2900 (wheel slot 11) 30–30 3000 (wheel slot 12) 31–31 3100 (wheel slot 13) 32–32 3200 (wheel slot 14) 33–33 3300 (wheel slot 15) 34–34 3400 (wheel slot 16) 35–35 3500 (wheel slot 17) 36–36 3600 (wheel slot 18) 37–37 3700 (wheel slot 19) 38–38 3800 (wheel slot 20) 39–39 3900 (wheel slot 21) 40–40 4000 (wheel slot 22) 41–41 4100 (wheel slot 23) 42–42 4200 (wheel slot 24) 43–43 4300 (wheel slot 25) 44–44 4400 (wheel slot 26) 45–45 4500 (wheel slot 27) 46–46 4600 (wheel slot 28) 47–47 4700 (wheel slot 29) 48–48 4800 (wheel slot 30) 49–49 4900 (wheel slot 31) 50–50 5000 (wheel slot 32) 51–51 5100 (wheel slot 33) 52–52 5200 (wheel slot 34) 53–53 5300 (wheel slot 35) 54–54 5400 (wheel slot 36) 55–55 5500 (wheel slot 37) 56–56 56000 (wheel slot 38) 57–57 5700 (wheel slot 39) 58–58 5800 (wheel slot 40) 59–59 5900 (wheel slot 41) 60–60 6000 (wheel slot 42) 61–61 6100 (wheel slot 43) 62–62 6200 (wheel slot 44) 63–63 6300 (wheel slot 45) 64–64 6400 (wheel slot 46) 65–65 6500 (wheel slot 47) 66–66 6600 (wheel slot 48) 67–67 6700 (wheel slot 49) 68–68 6800 (wheel slot 50) 69–69 6900 (wheel slot 51) 70–70 7000 (wheel slot 52) 71–71 7100 (wheel slot 53) 72–72 7200 (wheel slot 54) 73–73 7300 (wheel slot 55) 74–74 7400 (wheel slot 56) 75–75 7500 (wheel slot 57) 76–76 7600 (wheel slot 58) 77–77 7700 (wheel slot 59) 78–78 7800 (wheel slot 60) 79–79 7900 (wheel slot 61) 80–80 8000 (wheel slot 62) 81–81 8100 (wheel slot 63) 82–100 8200 (wheel slot 64)

HSI 9CH (continued)

Ch	Function	Default	DMX values
7	Color Wheel 2	0	0–0 Open 1–1 Pale Yellow (wheel slot 1) 2–2 Straw (wheel slot 2) 3–3 Gold Tint (wheel slot 3) 4–4 Spring Yellow (wheel slot 4) 5–5 Medium Yellow (wheel slot 5) 6–6 Yellow (wheel slot 6) 7–7 Deep Amber (wheel slot 7) 8–8 Deep Straw (wheel slot 8) 9–9 Loving Amber (wheel slot 9) 10–10 Gold Amber (wheel slot 10) 11–11 Orange (wheel slot 11) 12–12 Deep Orange (wheel slot 12) 13–13 Dark Amber (wheel slot 13) 14–14 Millennium Gold (wheel slot 14) 15–15 Deep Golden Amber (wheel slot 15) 16–16 Scarlet (wheel slot 16) 17–17 Primary Red (wheel slot 17) 18–18 Bright Red (wheel slot 18) 19–19 Medium Red (wheel slot 19) 20–20 Fire (wheel slot 20) 21–21 Pink (wheel slot 21) 22–22 Medium Pink (wheel slot 22) 23–23 Dark Pink (wheel slot 23) 24–24 Bright Pink (wheel slot 24) 25–25 Bright Rose (wheel slot 25) 26–26 Special Rose Pink (wheel slot 26) 27–27 Vanity Fair (wheel slot 27) 28–28 Magenta (wheel slot 28) 29–29 Dark Magenta (wheel slot 29) 30–30 Rose Purple (wheel slot 30) 31–31 Mauve (wheel slot 31) 32–32 Medium Purple (wheel slot 32) 33–33 Lavender (wheel slot 33) 34–34 Palace blue (wheel slot 34) 35–35 Dark Blue (wheel slot 35) 36–36 Medium Blue (wheel slot 36) 37–37 Deep Blue (wheel slot 37) 38–38 Daylight Blue (wheel slot 38) 39–39 Slate Blue (wheel slot 39) 40–40 Light Blue (wheel slot 40) 41–41 Sky Blue (wheel slot 41) 42–42 Pale Navy Blue (wheel slot 42) 43–43 Marine Blue (wheel slot 43) 44–44 Peacock Blue (wheel slot 44) 45–45 Lagoon Blue (wheel slot 45) 46–46 Medium Blue Green (wheel slot 46) 47–47 Dark Yellow Green (wheel slot 47) 48–48 Primary Green (wheel slot 48) 49–49 Fern Green (wheel slot 49) 50–50 Moss Green (wheel slot 50) 51–51 Dark Green (wheel slot 51) 52–52 Lime Green (wheel slot 52) 53–53 Pale Green (wheel slot 53) 54–54 Quarter CT Blue (wheel slot 54) 55–55 Half CT Blue (wheel slot 55) 56–56 Full CT Blue (wheel slot 56) 57–57 Double CT Blue (wheel slot 57) 58–58 Quarter CT Orange (wheel slot 58) 59–59 Half CT Orange (wheel slot 59) 60–60 Full CT Orange (wheel slot 60) 61–179 No Function 180–201 Clockwise fast to slow 202–207 Stop

HSI 9CH (continued)

Ch	Function	Default	DMX values
8	Dimmer Mode	0	0–20 Standard 21–40 Stage 41–60 TV 61–80 Architectural 81–100 Theatre 101–120 Stage 2 121–121 0s 122–122 0*1s 123–123 0*2 124–124 0*3s 125–125 0*4s 126–126 0*5s 127–127 0*6s 128–128 0*7 129–129 0*8s 130–130 0*9s 131–131 1s 132–132 1*5s 133–133 2s 134–134 3s 135–135 4s 136–136 5s 137–137 6s 138–138 7s 139–139 8s 140–140 9s 141–141 10s 142–255 Idle
9	Function	0	

16bit 10CH

10 channels

Ch	Function	Default	DMX values
1	Red	0	
2	Red Fine	0	Fine byte of Red
3	Green	0	
4	Green Fine	0	Fine byte of Green
5	Blue	0	
6	Blue Fine	0	Fine byte of Blue
7	White	0	
8	White Fine	0	Fine byte of White
9	Color Add GY	0	
10	Color Add GY Fine	0	Fine byte of Color Add GY

Standard 10CH

10 channels

Ch	Function	Default	DMX values
1	Shutter / Strobe	50	0–31 Shutter Closed 32–63 No Function (Shutter Open) 64–95 Strobe Effect Slow to Fast 96–127 No Function (Shutter Open) 128–159 Pulse-Effect in Sequences 160–191 No Function (Shutter Open) 192–223 Random Strobe Effect Slow to Fast 224–255 No Function (Shutter Open)

Standard 10CH (continued)

Ch	Function	Default	DMX values
2	Dimmer	0	0–62 0 percent 63–126 25 percent 127–190 50 percent 191–254 75 percent 255–255 100 percent
3	Dimmer Fine	0	Fine byte of Dimmer
4	Red	0	
5	Green	0	
6	Blue	0	

Standard 10CH (continued)

Ch	Function	Default	DMX values
7	Color Wheel	0	0–19 Open 20–20 2000 (wheel slot 2) 21–21 2100 (wheel slot 3) 22–22 2200 (wheel slot 4) 23–23 2300 (wheel slot 5) 24–24 2400 (wheel slot 6) 25–25 2500 (wheel slot 7) 26–26 2600 (wheel slot 8) 27–27 2700 (wheel slot 9) 28–28 2800 (wheel slot 10) 29–29 2900 (wheel slot 11) 30–30 3000 (wheel slot 12) 31–31 3100 (wheel slot 13) 32–32 3200 (wheel slot 14) 33–33 3300 (wheel slot 15) 34–34 3400 (wheel slot 16) 35–35 3500 (wheel slot 17) 36–36 3600 (wheel slot 18) 37–37 3700 (wheel slot 19) 38–38 3800 (wheel slot 20) 39–39 3900 (wheel slot 21) 40–40 4000 (wheel slot 22) 41–41 4100 (wheel slot 23) 42–42 4200 (wheel slot 24) 43–43 4300 (wheel slot 25) 44–44 4400 (wheel slot 26) 45–45 4500 (wheel slot 27) 46–46 4600 (wheel slot 28) 47–47 4700 (wheel slot 29) 48–48 4800 (wheel slot 30) 49–49 4900 (wheel slot 31) 50–50 5000 (wheel slot 32) 51–51 5100 (wheel slot 33) 52–52 5200 (wheel slot 34) 53–53 5300 (wheel slot 35) 54–54 5400 (wheel slot 36) 55–55 5500 (wheel slot 37) 56–56 56000 (wheel slot 38) 57–57 5700 (wheel slot 39) 58–58 5800 (wheel slot 40) 59–59 5900 (wheel slot 41) 60–60 6000 (wheel slot 42) 61–61 6100 (wheel slot 43) 62–62 6200 (wheel slot 44) 63–63 6300 (wheel slot 45) 64–64 6400 (wheel slot 46) 65–65 6500 (wheel slot 47) 66–66 6600 (wheel slot 48) 67–67 6700 (wheel slot 49) 68–68 6800 (wheel slot 50) 69–69 6900 (wheel slot 51) 70–70 7000 (wheel slot 52) 71–71 7100 (wheel slot 53) 72–72 7200 (wheel slot 54) 73–73 7300 (wheel slot 55) 74–74 7400 (wheel slot 56) 75–75 7500 (wheel slot 57) 76–76 7600 (wheel slot 58) 77–77 7700 (wheel slot 59) 78–78 7800 (wheel slot 60) 79–79 7900 (wheel slot 61) 80–80 8000 (wheel slot 62) 81–81 8100 (wheel slot 63) 82–100 8200 (wheel slot 64)

Standard 10CH (continued)

Ch	Function	Default	DMX values
8	Color Wheel 2	0	0–0 Open 1–1 Pale Yellow (wheel slot 1) 2–2 Straw (wheel slot 2) 3–3 Gold Tint (wheel slot 3) 4–4 Spring Yellow (wheel slot 4) 5–5 Medium Yellow (wheel slot 5) 6–6 Yellow (wheel slot 6) 7–7 Deep Amber (wheel slot 7) 8–8 Deep Straw (wheel slot 8) 9–9 Loving Amber (wheel slot 9) 10–10 Gold Amber (wheel slot 10) 11–11 Orange (wheel slot 11) 12–12 Deep Orange (wheel slot 12) 13–13 Dark Amber (wheel slot 13) 14–14 Millennium Gold (wheel slot 14) 15–15 Deep Golden Amber (wheel slot 15) 16–16 Scarlet (wheel slot 16) 17–17 Primary Red (wheel slot 17) 18–18 Bright Red (wheel slot 18) 19–19 Medium Red (wheel slot 19) 20–20 Fire (wheel slot 20) 21–21 Pink (wheel slot 21) 22–22 Medium Pink (wheel slot 22) 23–23 Dark Pink (wheel slot 23) 24–24 Bright Pink (wheel slot 24) 25–25 Bright Rose (wheel slot 25) 26–26 Special Rose Pink (wheel slot 26) 27–27 Vanity Fair (wheel slot 27) 28–28 Magenta (wheel slot 28) 29–29 Dark Magenta (wheel slot 29) 30–30 Rose Purple (wheel slot 30) 31–31 Mauve (wheel slot 31) 32–32 Medium Purple (wheel slot 32) 33–33 Lavender (wheel slot 33) 34–34 Palace blue (wheel slot 34) 35–35 Dark Blue (wheel slot 35) 36–36 Medium Blue (wheel slot 36) 37–37 Deep Blue (wheel slot 37) 38–38 Daylight Blue (wheel slot 38) 39–39 Slate Blue (wheel slot 39) 40–40 Light Blue (wheel slot 40) 41–41 Sky Blue (wheel slot 41) 42–42 Pale Navy Blue (wheel slot 42) 43–43 Marine Blue (wheel slot 43) 44–44 Peacock Blue (wheel slot 44) 45–45 Lagoon Blue (wheel slot 45) 46–46 Medium Blue Green (wheel slot 46) 47–47 Dark Yellow Green (wheel slot 47) 48–48 Primary Green (wheel slot 48) 49–49 Fern Green (wheel slot 49) 50–50 Moss Green (wheel slot 50) 51–51 Dark Green (wheel slot 51) 52–52 Lime Green (wheel slot 52) 53–53 Pale Green (wheel slot 53) 54–54 Quarter CT Blue (wheel slot 54) 55–55 Half CT Blue (wheel slot 55) 56–56 Full CT Blue (wheel slot 56) 57–57 Double CT Blue (wheel slot 57) 58–58 Quarter CT Orange (wheel slot 58) 59–59 Half CT Orange (wheel slot 59) 60–60 Full CT Orange (wheel slot 60) 61–179 No Function 180–201 Clockwise fast to slow 202–207 Stop

Standard 10CH (continued)

Ch	Function	Default	DMX values
9	Dimmer Mode	0	0–20 Standard 21–40 Stage 41–60 TV 61–80 Architectural 81–100 Theatre 101–120 Stage 2 121–121 0s 122–122 0*1s 123–123 0*2 124–124 0*3s 125–125 0*4s 126–126 0*5s 127–127 0*6s 128–128 0*7 129–129 0*8s 130–130 0*9s 131–131 1s 132–132 1*5s 133–133 2s 134–134 3s 135–135 4s 136–136 5s 137–137 6s 138–138 7s 139–139 8s 140–140 9s 141–141 10s 142–255 Idle
10	Function	0	

Extended 17CH

17 channels

Ch	Function	Default	DMX values
1	Shutter / Strobe	50	0–31 Closed 32–63 Open 64–94 Strobe Min 95–95 Strobe Max 96–127 Open 128–158 Strobe Pulse Min 159–159 Strobe Pulse Max 160–191 Open 192–222 Random Strobe Min 223–223 Random Strobe Max 224–255 Open
2	Dimmer	0	0–62 0 percent 63–126 25 percent 127–190 50 percent 191–254 75 percent 255–255 100 percent
3	Dimmer Fine	0	Fine byte of Dimmer
4	Red	0	
5	Red Fine	0	Fine byte of Red
6	Green	0	
7	Green Fine	0	Fine byte of Green
8	Blue	0	
9	Blue Fine	0	Fine byte of Blue
10	White	0	

Extended 17CH (continued)

Ch	Function	Default	DMX values
11	White Fine	0	Fine byte of White
12	Color Add GY	0	
13	Color Add GY Fine	0	Fine byte of Color Add GY

Extended 17CH (continued)

Ch	Function	Default	DMX values
14	Color Wheel	0	0–19 Open (wheel slot 1) 20–20 2000 (wheel slot 2) 21–21 2100 (wheel slot 3) 22–22 2200 (wheel slot 4) 23–23 2300 (wheel slot 5) 24–24 2400 (wheel slot 6) 25–25 2500 (wheel slot 7) 26–26 2600 (wheel slot 8) 27–27 2700 (wheel slot 9) 28–28 2800 (wheel slot 10) 29–29 2900 (wheel slot 11) 30–30 3000 (wheel slot 12) 31–31 3100 (wheel slot 13) 32–32 3200 (wheel slot 14) 33–33 3300 (wheel slot 15) 34–34 3400 (wheel slot 16) 35–35 3500 (wheel slot 17) 36–36 3600 (wheel slot 18) 37–37 3700 (wheel slot 19) 38–38 3800 (wheel slot 20) 39–39 3900 (wheel slot 21) 40–40 4000 (wheel slot 22) 41–41 4100 (wheel slot 23) 42–42 4200 (wheel slot 24) 43–43 4300 (wheel slot 25) 44–44 4400 (wheel slot 26) 45–45 4500 (wheel slot 27) 46–46 4600 (wheel slot 28) 47–47 4700 (wheel slot 29) 48–48 4800 (wheel slot 30) 49–49 4900 (wheel slot 31) 50–50 5000 (wheel slot 32) 51–51 5100 (wheel slot 33) 52–52 5200 (wheel slot 34) 53–53 5300 (wheel slot 35) 54–54 5400 (wheel slot 36) 55–55 5500 (wheel slot 37) 56–56 56000 (wheel slot 38) 57–57 5700 (wheel slot 39) 58–58 5800 (wheel slot 40) 59–59 5900 (wheel slot 41) 60–60 6000 (wheel slot 42) 61–61 6100 (wheel slot 43) 62–62 6200 (wheel slot 44) 63–63 6300 (wheel slot 45) 64–64 6400 (wheel slot 46) 65–65 6500 (wheel slot 47) 66–66 6600 (wheel slot 48) 67–67 6700 (wheel slot 49) 68–68 6800 (wheel slot 50) 69–69 6900 (wheel slot 51) 70–70 7000 (wheel slot 52) 71–71 7100 (wheel slot 53) 72–72 7200 (wheel slot 54) 73–73 7300 (wheel slot 55) 74–74 7400 (wheel slot 56) 75–75 7500 (wheel slot 57) 76–76 7600 (wheel slot 58) 77–77 7700 (wheel slot 59) 78–78 7800 (wheel slot 60) 79–79 7900 (wheel slot 61) 80–80 8000 (wheel slot 62) 81–81 8100 (wheel slot 63) 82–100 8200 (wheel slot 64)

Extended 17CH (continued)

Ch	Function	Default	DMX values
15	Color Wheel 2	0	0–0 Open 1–1 Pale Yellow (wheel slot 1) 2–2 Straw (wheel slot 2) 3–3 Gold Tint (wheel slot 3) 4–4 Spring Yellow (wheel slot 4) 5–5 Medium Yellow (wheel slot 5) 6–6 Yellow (wheel slot 6) 7–7 Deep Amber (wheel slot 7) 8–8 Deep Straw (wheel slot 8) 9–9 Loving Amber (wheel slot 9) 10–10 Gold Amber (wheel slot 10) 11–11 Orange (wheel slot 11) 12–12 Deep Orange (wheel slot 12) 13–13 Dark Amber (wheel slot 13) 14–14 Millennium Gold (wheel slot 14) 15–15 Deep Golden Amber (wheel slot 15) 16–16 Scarlet (wheel slot 16) 17–17 Primary Red (wheel slot 17) 18–18 Bright Red (wheel slot 18) 19–19 Medium Red (wheel slot 19) 20–20 Fire (wheel slot 20) 21–21 Pink (wheel slot 21) 22–22 Medium Pink (wheel slot 22) 23–23 Dark Pink (wheel slot 23) 24–24 Bright Pink (wheel slot 24) 25–25 Bright Rose (wheel slot 25) 26–26 Special Rose Pink (wheel slot 26) 27–27 Vanity Fair (wheel slot 27) 28–28 Magenta (wheel slot 28) 29–29 Dark Magenta (wheel slot 29) 30–30 Rose Purple (wheel slot 30) 31–31 Mauve (wheel slot 31) 32–32 Medium Purple (wheel slot 32) 33–33 Lavender (wheel slot 33) 34–34 Palace blue (wheel slot 34) 35–35 Dark Blue (wheel slot 35) 36–36 Medium Blue (wheel slot 36) 37–37 Deep Blue (wheel slot 37) 38–38 Daylight Blue (wheel slot 38) 39–39 Slate Blue (wheel slot 39) 40–40 Light Blue (wheel slot 40) 41–41 Sky Blue (wheel slot 41) 42–42 Pale Navy Blue (wheel slot 42) 43–43 Marine Blue (wheel slot 43) 44–44 Peacock Blue (wheel slot 44) 45–45 Lagoon Blue (wheel slot 45) 46–46 Medium Blue Green (wheel slot 46) 47–47 Dark Yellow Green (wheel slot 47) 48–48 Primary Green (wheel slot 48) 49–49 Fern Green (wheel slot 49) 50–50 Moss Green (wheel slot 50) 51–51 Dark Green (wheel slot 51) 52–52 Lime Green (wheel slot 52) 53–53 Pale Green (wheel slot 53) 54–54 Quarter CT Blue (wheel slot 54) 55–55 Half CT Blue (wheel slot 55) 56–56 Full CT Blue (wheel slot 56) 57–57 Double CT Blue (wheel slot 57) 58–58 Quarter CT Orange (wheel slot 58) 59–59 Half CT Orange (wheel slot 59) 60–60 Full CT Orange (wheel slot 60) 61–179 No Function 180–201 Clockwise fast to slow 202–207 Stop

Extended 17CH (continued)

Ch	Function	Default	DMX values
16	Dimmer Mode	0	0–20 Standard 21–40 Stage 41–60 TV 61–80 Architectural 81–100 Theatre 101–120 Stage 2 121–121 0s 122–122 0*1s 123–123 0*2 124–124 0*3s 125–125 0*4s 126–126 0*5s 127–127 0*6s 128–128 0*7 129–129 0*8s 130–130 0*9s 131–131 1s 132–132 1*5s 133–133 2s 134–134 3s 135–135 4s 136–136 5s 137–137 6s 138–138 7s 139–139 8s 140–140 9s 141–141 10s 142–255 Idle
17	Function	0	