CKC Lighting

P500 FC



Manufacturer	**CKC Lighting**
Type	**PAR**
DMX modes	**6**
DMX footprint	**1, 6, 9, 11, 14, 18 channels**
Beam angle	**22°**
Size (W × H × D)	**217 × 354 × 217 mm**
GDTF fixture type	**F8118755-6DAC-4D2C-868F-99…**

Controls

Extra LED colours · RGB colour mixing · Colour temperature · Colour wheel · Strobe · Dimmer

Safety-relevant functions

Strobe

DMX modes

Dimmer	1 ch
Dimmer Color	6 ch
CMY	9 ch
Standard	11 ch
CMY Extended	14 ch
Extended	18 ch

Dimmer

1 channel

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open

Dimmer Color

6 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open
2	Dimmer Fine	0	Fine byte of Dimmer
3	Shutter / Strobe	0	0–31 Shutter closed 32–63 No function (shutter open) 64–95 Strobe effect - slow to fast 96–127 No function (shutter open) 128–159 Pulse effect (in sequence) 160–191 No function (shutter open) 192–223 Random strobe effect - slow to fast 224–255 No function (shutter open)
4	C TC	0	

Dimmer Color (continued)

Ch	Function	Default	DMX values
5	Color Wheel	0	0–0 Open 1–1 LEE 007 - Pale Yellow (wheel slot 1) 2–2 LEE 103 - Straw (wheel slot 2) 3–3 LEE 151 - Gold Tint (wheel slot 3) 4–4 LEE 100 - Spring Yellow (wheel slot 4) 5–5 LEE 010 - Medium Yellow (wheel slot 5) 6–6 LEE 101 - Yellow (wheel slot 6) 7–7 LEE 104 - Deep Amber (wheel slot 7) 8–8 LEE 015 - Deep Straw (wheel slot 8) 9–9 LEE 179 - Chrome Orange (wheel slot 9) 10–10 LEE 021 - Gold Amber (wheel slot 10) 11–11 LEE 105 - Orange (wheel slot 11) 12–12 LEE 158 - Deep Orange (wheel slot 12) 13–13 LEE 022 - Dark Amber (wheel slot 13) 14–14 LEE 778 - Millenium Gold (wheel slot 14) 15–15 LEE 135 - Deep Gold Amber (wheel slot 15) 16–16 LEE 024 - Scarlet (wheel slot 16) 17–17 LEE 106 - Primary Red (wheel slot 17) 18–18 LEE 026 - Bright Red (wheel slot 18) 19–19 LEE 027 - Medium Red (wheel slot 19) 20–20 LEE 019 - Fire (wheel slot 20) 21–21 LEE 157 - Pink (wheel slot 21) 22–22 LEE 036 - Medium Pink (wheel slot 22) 23–23 LEE 111 - Dark Pink (wheel slot 23) 24–24 LEE 128 - Bright Pink (wheel slot 24) 25–25 LEE 148 - Bright Rose (wheel slot 25) 26–26 LEE 332 - Special Rose Pink (wheel slot 26) 27–27 LEE 793 - Vanity Fair (wheel slot 27) 28–28 LEE 113 - Magenta (wheel slot 28) 29–29 LEE 046 - Dark Magenta (wheel slot 29) 30–30 LEE 048 - Rose Purple (wheel slot 30) 31–31 LEE 126 - Mauve (wheel slot 31) 32–32 LEE 049 - Medium Purple (wheel slot 32) 33–33 LEE 058 - Lavender (wheel slot 33) 34–34 LEE 197 - Alice Blue (wheel slot 34) 35–35 LEE 119 - Dark Blue (wheel slot 35) 36–36 LEE 132 - Medium Blue (wheel slot 36) 37–37 LEE 120 - Deep Blue (wheel slot 37) 38–38 LEE 165 - Daylight Blue (wheel slot 38) 39–39 LEE 161 - Slate Blue (wheel slot 39) 40–40 LEE 118 - Light Blue (wheel slot 40) 41–41 LEE 068 - Sky Blue (wheel slot 41) 42–42 LEE 143 - Pale Navy Blue (wheel slot 42) 43–43 LEE 131 - Marine Blue (wheel slot 43) 44–44 LEE 115 - Peacock Blue (wheel slot 44) 45–45 LEE 172 - Lagoon Blue (wheel slot 45) 46–46 LEE 116 - Medium Blue Green (wheel slot 46) 47–47 LEE 090 - Dark Yellow Green (wheel slot 47) 48–48 LEE 139 - Primary Green (wheel slot 48) 49–49 LEE 122 - Fern Green (wheel slot 49) 50–50 LEE 089 - Moss Green (wheel slot 50) 51–51 LEE 124 - Dark Green (wheel slot 51) 52–52 LEE 088 - Lime Green (wheel slot 52) 53–53 LEE 138 - Pale Green (wheel slot 53) 54–54 LEE 203 - Quarter C T Blue (wheel slot 54) 55–55 LEE 202 - Half C T Blue (wheel slot 55) 56–56 LEE 201 - Full C T Blue (wheel slot 56) 57–57 LEE 200 - Double C T Blue (wheel slot 57) 58–58 LEE 206 - Quarter C T Orange (wheel slot 58) 59–59 LEE 205 - Half C T Orange (wheel slot 59) 60–60 LEE 204 - Full C T Orange (wheel slot 60) 61–179 No Function 180–201 Clockwise fast to slow 202–207 Stop

Dimmer Color (continued)

Ch	Function	Default	DMX values
6	Function	0	

CMY

9 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open
2	Dimmer Fine	0	Fine byte of Dimmer
3	Shutter / Strobe	0	0–31 Shutter closed 32–63 No function (shutter open) 64–95 Strobe effect - slow to fast 96–127 No function (shutter open) 128–159 Pulse effect (in sequence) 160–191 No function (shutter open) 192–223 Random strobe effect - slow to fast 224–255 No function (shutter open)
4	Color Add C	0	0–254 0 % 255–255 100 %
5	Color Add M	0	0–254 0 % 255–255 100 %
6	Color Add Y	0	0–254 0 % 255–255 100 %
7	C TC	0	

CMY (continued)

Ch	Function	Default	DMX values
8	Color Wheel	0	0–0 Open 1–1 LEE 007 - Pale Yellow (wheel slot 1) 2–2 LEE 103 - Straw (wheel slot 2) 3–3 LEE 151 - Gold Tint (wheel slot 3) 4–4 LEE 100 - Spring Yellow (wheel slot 4) 5–5 LEE 010 - Medium Yellow (wheel slot 5) 6–6 LEE 101 - Yellow (wheel slot 6) 7–7 LEE 104 - Deep Amber (wheel slot 7) 8–8 LEE 015 - Deep Straw (wheel slot 8) 9–9 LEE 179 - Chrome Orange (wheel slot 9) 10–10 LEE 021 - Gold Amber (wheel slot 10) 11–11 LEE 105 - Orange (wheel slot 11) 12–12 LEE 158 - Deep Orange (wheel slot 12) 13–13 LEE 022 - Dark Amber (wheel slot 13) 14–14 LEE 778 - Millenium Gold (wheel slot 14) 15–15 LEE 135 - Deep Gold Amber (wheel slot 15) 16–16 LEE 024 - Scarlet (wheel slot 16) 17–17 LEE 106 - Primary Red (wheel slot 17) 18–18 LEE 026 - Bright Red (wheel slot 18) 19–19 LEE 027 - Medium Red (wheel slot 19) 20–20 LEE 019 - Fire (wheel slot 20) 21–21 LEE 157 - Pink (wheel slot 21) 22–22 LEE 036 - Medium Pink (wheel slot 22) 23–23 LEE 111 - Dark Pink (wheel slot 23) 24–24 LEE 128 - Bright Pink (wheel slot 24) 25–25 LEE 148 - Bright Rose (wheel slot 25) 26–26 LEE 332 - Special Rose Pink (wheel slot 26) 27–27 LEE 793 - Vanity Fair (wheel slot 27) 28–28 LEE 113 - Magenta (wheel slot 28) 29–29 LEE 046 - Dark Magenta (wheel slot 29) 30–30 LEE 048 - Rose Purple (wheel slot 30) 31–31 LEE 126 - Mauve (wheel slot 31) 32–32 LEE 049 - Medium Purple (wheel slot 32) 33–33 LEE 058 - Lavender (wheel slot 33) 34–34 LEE 197 - Alice Blue (wheel slot 34) 35–35 LEE 119 - Dark Blue (wheel slot 35) 36–36 LEE 132 - Medium Blue (wheel slot 36) 37–37 LEE 120 - Deep Blue (wheel slot 37) 38–38 LEE 165 - Daylight Blue (wheel slot 38) 39–39 LEE 161 - Slate Blue (wheel slot 39) 40–40 LEE 118 - Light Blue (wheel slot 40) 41–41 LEE 068 - Sky Blue (wheel slot 41) 42–42 LEE 143 - Pale Navy Blue (wheel slot 42) 43–43 LEE 131 - Marine Blue (wheel slot 43) 44–44 LEE 115 - Peacock Blue (wheel slot 44) 45–45 LEE 172 - Lagoon Blue (wheel slot 45) 46–46 LEE 116 - Medium Blue Green (wheel slot 46) 47–47 LEE 090 - Dark Yellow Green (wheel slot 47) 48–48 LEE 139 - Primary Green (wheel slot 48) 49–49 LEE 122 - Fern Green (wheel slot 49) 50–50 LEE 089 - Moss Green (wheel slot 50) 51–51 LEE 124 - Dark Green (wheel slot 51) 52–52 LEE 088 - Lime Green (wheel slot 52) 53–53 LEE 138 - Pale Green (wheel slot 53) 54–54 LEE 203 - Quarter C T Blue (wheel slot 54) 55–55 LEE 202 - Half C T Blue (wheel slot 55) 56–56 LEE 201 - Full C T Blue (wheel slot 56) 57–57 LEE 200 - Double C T Blue (wheel slot 57) 58–58 LEE 206 - Quarter C T Orange (wheel slot 58) 59–59 LEE 205 - Half C T Orange (wheel slot 59) 60–60 LEE 204 - Full C T Orange (wheel slot 60) 61–179 No Function 180–201 Clockwise fast to slow 202–207 Stop

CMY (continued)

Ch	Function	Default	DMX values
9	Function	0	

Standard

11 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open
2	Dimmer Fine	0	Fine byte of Dimmer
3	Shutter / Strobe	0	0–31 Shutter closed 32–63 No function (shutter open) 64–95 Strobe effect - slow to fast 96–127 No function (shutter open) 128–159 Pulse effect (in sequence) 160–191 No function (shutter open) 192–223 Random strobe effect - slow to fast 224–255 No function (shutter open)
4	Red	0	0–254 0 % 255–255 100 %
5	Green	0	0–254 0 % 255–255 100 %
6	Blue	0	0–254 0 % 255–255 100 %
7	Color Add GC	0	0–254 0 % 255–255 100 %
8	Color Add RY	0	0–254 0 % 255–255 100 %
9	C TC	0	

Standard (continued)

Ch	Function	Default	DMX values
10	Color Wheel	0	0–0 Open 1–1 LEE 007 - Pale Yellow (wheel slot 1) 2–2 LEE 103 - Straw (wheel slot 2) 3–3 LEE 151 - Gold Tint (wheel slot 3) 4–4 LEE 100 - Spring Yellow (wheel slot 4) 5–5 LEE 010 - Medium Yellow (wheel slot 5) 6–6 LEE 101 - Yellow (wheel slot 6) 7–7 LEE 104 - Deep Amber (wheel slot 7) 8–8 LEE 015 - Deep Straw (wheel slot 8) 9–9 LEE 179 - Chrome Orange (wheel slot 9) 10–10 LEE 021 - Gold Amber (wheel slot 10) 11–11 LEE 105 - Orange (wheel slot 11) 12–12 LEE 158 - Deep Orange (wheel slot 12) 13–13 LEE 022 - Dark Amber (wheel slot 13) 14–14 LEE 778 - Millenium Gold (wheel slot 14) 15–15 LEE 135 - Deep Gold Amber (wheel slot 15) 16–16 LEE 024 - Scarlet (wheel slot 16) 17–17 LEE 106 - Primary Red (wheel slot 17) 18–18 LEE 026 - Bright Red (wheel slot 18) 19–19 LEE 027 - Medium Red (wheel slot 19) 20–20 LEE 019 - Fire (wheel slot 20) 21–21 LEE 157 - Pink (wheel slot 21) 22–22 LEE 036 - Medium Pink (wheel slot 22) 23–23 LEE 111 - Dark Pink (wheel slot 23) 24–24 LEE 128 - Bright Pink (wheel slot 24) 25–25 LEE 148 - Bright Rose (wheel slot 25) 26–26 LEE 332 - Special Rose Pink (wheel slot 26) 27–27 LEE 793 - Vanity Fair (wheel slot 27) 28–28 LEE 113 - Magenta (wheel slot 28) 29–29 LEE 046 - Dark Magenta (wheel slot 29) 30–30 LEE 048 - Rose Purple (wheel slot 30) 31–31 LEE 126 - Mauve (wheel slot 31) 32–32 LEE 049 - Medium Purple (wheel slot 32) 33–33 LEE 058 - Lavender (wheel slot 33) 34–34 LEE 197 - Alice Blue (wheel slot 34) 35–35 LEE 119 - Dark Blue (wheel slot 35) 36–36 LEE 132 - Medium Blue (wheel slot 36) 37–37 LEE 120 - Deep Blue (wheel slot 37) 38–38 LEE 165 - Daylight Blue (wheel slot 38) 39–39 LEE 161 - Slate Blue (wheel slot 39) 40–40 LEE 118 - Light Blue (wheel slot 40) 41–41 LEE 068 - Sky Blue (wheel slot 41) 42–42 LEE 143 - Pale Navy Blue (wheel slot 42) 43–43 LEE 131 - Marine Blue (wheel slot 43) 44–44 LEE 115 - Peacock Blue (wheel slot 44) 45–45 LEE 172 - Lagoon Blue (wheel slot 45) 46–46 LEE 116 - Medium Blue Green (wheel slot 46) 47–47 LEE 090 - Dark Yellow Green (wheel slot 47) 48–48 LEE 139 - Primary Green (wheel slot 48) 49–49 LEE 122 - Fern Green (wheel slot 49) 50–50 LEE 089 - Moss Green (wheel slot 50) 51–51 LEE 124 - Dark Green (wheel slot 51) 52–52 LEE 088 - Lime Green (wheel slot 52) 53–53 LEE 138 - Pale Green (wheel slot 53) 54–54 LEE 203 - Quarter C T Blue (wheel slot 54) 55–55 LEE 202 - Half C T Blue (wheel slot 55) 56–56 LEE 201 - Full C T Blue (wheel slot 56) 57–57 LEE 200 - Double C T Blue (wheel slot 57) 58–58 LEE 206 - Quarter C T Orange (wheel slot 58) 59–59 LEE 205 - Half C T Orange (wheel slot 59) 60–60 LEE 204 - Full C T Orange (wheel slot 60) 61–179 No Function 180–201 Clockwise fast to slow 202–207 Stop

Standard (continued)

Ch	Function	Default	DMX values
11	Function	0	

CMY Extended

14 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open
2	Dimmer Fine	0	Fine byte of Dimmer
3	Shutter / Strobe	0	0–31 Shutter closed 32–63 No function (shutter open) 64–95 Strobe effect - slow to fast 96–127 No function (shutter open) 128–159 Pulse effect (in sequence) 160–191 No function (shutter open) 192–223 Random strobe effect - slow to fast 224–255 No function (shutter open)
4	Color Add C	0	0–254 0 % 255–255 100 %
5	Color Add C Fine	0	Fine byte of Color Add C
6	Color Add M	0	0–254 0 % 255–255 100 %
7	Color Add M Fine	0	Fine byte of Color Add M
8	Color Add Y	0	0–254 0 % 255–255 100 %
9	Color Add Y Fine	0	Fine byte of Color Add Y
10	C TC	0	

CMY Extended (continued)

Ch	Function	Default	DMX values
11	Color Wheel	0	0–0 No Color selected 1–1 LEE 007 - Pale Yellow (wheel slot 1) 2–2 LEE 103 - Straw (wheel slot 2) 3–3 LEE 151 - Gold Tint (wheel slot 3) 4–4 LEE 100 - Spring Yellow (wheel slot 4) 5–5 LEE 010 - Medium Yellow (wheel slot 5) 6–6 LEE 101 - Yellow (wheel slot 6) 7–7 LEE 104 - Deep Amber (wheel slot 7) 8–8 LEE 015 - Deep Straw (wheel slot 8) 9–9 LEE 179 - Chrome Orange (wheel slot 9) 10–10 LEE 021 - Gold Amber (wheel slot 10) 11–11 LEE 105 - Orange (wheel slot 11) 12–12 LEE 158 - Deep Orange (wheel slot 12) 13–13 LEE 022 - Dark Amber (wheel slot 13) 14–14 LEE 778 - Millenium Gold (wheel slot 14) 15–15 LEE 135 - Deep Gold Amber (wheel slot 15) 16–16 LEE 024 - Scarlet (wheel slot 16) 17–17 LEE 106 - Primary Red (wheel slot 17) 18–18 LEE 026 - Bright Red (wheel slot 18) 19–19 LEE 027 - Medium Red (wheel slot 19) 20–20 LEE 019 - Fire (wheel slot 20) 21–21 LEE 157 - Pink (wheel slot 21) 22–22 LEE 036 - Medium Pink (wheel slot 22) 23–23 LEE 111 - Dark Pink (wheel slot 23) 24–24 LEE 128 - Bright Pink (wheel slot 24) 25–25 LEE 148 - Bright Rose (wheel slot 25) 26–26 LEE 332 - Special Rose Pink (wheel slot 26) 27–27 LEE 793 - Vanity Fair (wheel slot 27) 28–28 LEE 113 - Magenta (wheel slot 28) 29–29 LEE 046 - Dark Magenta (wheel slot 29) 30–30 LEE 048 - Rose Purple (wheel slot 30) 31–31 LEE 126 - Mauve (wheel slot 31) 32–32 LEE 049 - Medium Purple (wheel slot 32) 33–33 LEE 058 - Lavender (wheel slot 33) 34–34 LEE 197 - Alice Blue (wheel slot 34) 35–35 LEE 119 - Dark Blue (wheel slot 35) 36–36 LEE 132 - Medium Blue (wheel slot 36) 37–37 LEE 120 - Deep Blue (wheel slot 37) 38–38 LEE 165 - Daylight Blue (wheel slot 38) 39–39 LEE 161 - Slate Blue (wheel slot 39) 40–40 LEE 118 - Light Blue (wheel slot 40) 41–41 LEE 068 - Sky Blue (wheel slot 41) 42–42 LEE 143 - Pale Navy Blue (wheel slot 42) 43–43 LEE 131 - Marine Blue (wheel slot 43) 44–44 LEE 115 - Peacock Blue (wheel slot 44) 45–45 LEE 172 - Lagoon Blue (wheel slot 45) 46–46 LEE 116 - Medium Blue Green (wheel slot 46) 47–47 LEE 090 - Dark Yellow Green (wheel slot 47) 48–48 LEE 139 - Primary Green (wheel slot 48) 49–49 LEE 122 - Fern Green (wheel slot 49) 50–50 LEE 089 - Moss Green (wheel slot 50) 51–51 LEE 124 - Dark Green (wheel slot 51) 52–52 LEE 088 - Lime Green (wheel slot 52) 53–53 LEE 138 - Pale Green (wheel slot 53) 54–54 LEE 203 - Quarter C T Blue (wheel slot 54) 55–55 LEE 202 - Half C T Blue (wheel slot 55) 56–56 LEE 201 - Full C T Blue (wheel slot 56) 57–57 LEE 200 - Double C T Blue (wheel slot 57) 58–58 LEE 206 - Quarter C T Orange (wheel slot 58) 59–59 LEE 205 - Half C T Orange (wheel slot 59) 60–60 LEE 204 - Full C T Orange (wheel slot 60) 61–179 No Function 180–201 Clockwise fast to slow 202–207 Stop

CMY Extended (continued)

Ch	Function	Default	DMX values
12	Color RGBGreen	0	0–0 Idle 1–127 Full Minus Green to Neutral 128–128 Neutral White 129–255 Neutral to Full Plus Green
13	Dimmer Mode	0	0–20 Standard 21–40 Stage 41–60 TV 61–80 Architectural 81–100 Theatre 101–120 Stage 2 121–121 0s 122–122 01s 123–123 02s 124–124 03s 125–125 04s 126–126 05s 127–127 06s 128–128 07s 129–129 08s 130–130 09s 131–131 1s 132–132 1*5s 133–133 2s 134–134 3s 135–135 4s 136–136 5s 137–137 6s 138–138 7s 139–139 8s 140–140 9s 141–141 10s 142–255 Idle
14	Function	0	

Extended

18 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open
2	Dimmer Fine	0	Fine byte of Dimmer
3	Shutter / Strobe	0	0–31 Shutter closed 32–63 No function (shutter open) 64–95 Strobe effect - slow to fast 96–127 No function (shutter open) 128–159 Pulse effect (in sequence) 160–191 No function (shutter open) 192–223 Random strobe effect - slow to fast 224–255 No function (shutter open)
4	Red	0	0–254 0 % 255–255 100 %
5	Red Fine	0	Fine byte of Red
6	Green	0	0–254 0 % 255–255 100 %
7	Green Fine	0	Fine byte of Green
8	Blue	0	0–254 0 % 255–255 100 %
9	Blue Fine	0	Fine byte of Blue

Extended (continued)

Ch	Function	Default	DMX values
10	Color Add GC	0	0–254 0 % 255–255 100 %
11	Color Add GC Fine	0	Fine byte of Color Add GC
12	Color Add RY	0	0–254 0 % 255–255 100 %
13	Color Add RY Fine	0	Fine byte of Color Add RY
14	C TC	0	

Extended (continued)

Ch	Function	Default	DMX values
15	Color Wheel	0	0–0 Open 1–1 LEE 007 - Pale Yellow (wheel slot 1) 2–2 LEE 103 - Straw (wheel slot 2) 3–3 LEE 151 - Gold Tint (wheel slot 3) 4–4 LEE 100 - Spring Yellow (wheel slot 4) 5–5 LEE 010 - Medium Yellow (wheel slot 5) 6–6 LEE 101 - Yellow (wheel slot 6) 7–7 LEE 104 - Deep Amber (wheel slot 7) 8–8 LEE 015 - Deep Straw (wheel slot 8) 9–9 LEE 179 - Chrome Orange (wheel slot 9) 10–10 LEE 021 - Gold Amber (wheel slot 10) 11–11 LEE 105 - Orange (wheel slot 11) 12–12 LEE 158 - Deep Orange (wheel slot 12) 13–13 LEE 022 - Dark Amber (wheel slot 13) 14–14 LEE 778 - Millenium Gold (wheel slot 14) 15–15 LEE 135 - Deep Gold Amber (wheel slot 15) 16–16 LEE 024 - Scarlet (wheel slot 16) 17–17 LEE 106 - Primary Red (wheel slot 17) 18–18 LEE 026 - Bright Red (wheel slot 18) 19–19 LEE 027 - Medium Red (wheel slot 19) 20–20 LEE 019 - Fire (wheel slot 20) 21–21 LEE 157 - Pink (wheel slot 21) 22–22 LEE 036 - Medium Pink (wheel slot 22) 23–23 LEE 111 - Dark Pink (wheel slot 23) 24–24 LEE 128 - Bright Pink (wheel slot 24) 25–25 LEE 148 - Bright Rose (wheel slot 25) 26–26 LEE 332 - Special Rose Pink (wheel slot 26) 27–27 LEE 793 - Vanity Fair (wheel slot 27) 28–28 LEE 113 - Magenta (wheel slot 28) 29–29 LEE 046 - Dark Magenta (wheel slot 29) 30–30 LEE 048 - Rose Purple (wheel slot 30) 31–31 LEE 126 - Mauve (wheel slot 31) 32–32 LEE 049 - Medium Purple (wheel slot 32) 33–33 LEE 058 - Lavender (wheel slot 33) 34–34 LEE 197 - Alice Blue (wheel slot 34) 35–35 LEE 119 - Dark Blue (wheel slot 35) 36–36 LEE 132 - Medium Blue (wheel slot 36) 37–37 LEE 120 - Deep Blue (wheel slot 37) 38–38 LEE 165 - Daylight Blue (wheel slot 38) 39–39 LEE 161 - Slate Blue (wheel slot 39) 40–40 LEE 118 - Light Blue (wheel slot 40) 41–41 LEE 068 - Sky Blue (wheel slot 41) 42–42 LEE 143 - Pale Navy Blue (wheel slot 42) 43–43 LEE 131 - Marine Blue (wheel slot 43) 44–44 LEE 115 - Peacock Blue (wheel slot 44) 45–45 LEE 172 - Lagoon Blue (wheel slot 45) 46–46 LEE 116 - Medium Blue Green (wheel slot 46) 47–47 LEE 090 - Dark Yellow Green (wheel slot 47) 48–48 LEE 139 - Primary Green (wheel slot 48) 49–49 LEE 122 - Fern Green (wheel slot 49) 50–50 LEE 089 - Moss Green (wheel slot 50) 51–51 LEE 124 - Dark Green (wheel slot 51) 52–52 LEE 088 - Lime Green (wheel slot 52) 53–53 LEE 138 - Pale Green (wheel slot 53) 54–54 LEE 203 - Quarter C T Blue (wheel slot 54) 55–55 LEE 202 - Half C T Blue (wheel slot 55) 56–56 LEE 201 - Full C T Blue (wheel slot 56) 57–57 LEE 200 - Double C T Blue (wheel slot 57) 58–58 LEE 206 - Quarter C T Orange (wheel slot 58) 59–59 LEE 205 - Half C T Orange (wheel slot 59) 60–60 LEE 204 - Full C T Orange (wheel slot 60) 61–179 No Function 180–201 Clockwise fast to slow 202–207 Stop

Extended (continued)

Ch	Function	Default	DMX values
16	Color RGBGreen	0	0–0 Idle 1–127 Full Minus Green to Neutral 128–128 Neutral White 129–255 Neutral to Full Plus Green
17	Dimmer Mode	0	0–20 Standard 21–40 Stage 41–60 TV 61–80 Architectural 81–100 Theatre 101–120 Stage 2 121–121 0s 122–122 01s 123–123 02s 124–124 03s 125–125 04s 126–126 05s 127–127 06s 128–128 07s 129–129 08s 130–130 09s 131–131 1s 132–132 1*5s 133–133 2s 134–134 3s 135–135 4s 136–136 5s 137–137 6s 138–138 7s 139–139 8s 140–140 9s 141–141 10s 142–255 Idle
18	Function	0	