
CKC Lighting

V8IP



Manufacturer	**CKC Lighting**
Type	**Profile spot**
DMX modes	**2**
DMX footprint	**36, 52 channels**
Beam angle	**6-53°**
Pan range	**540°**
Tilt range	**270°**
Size (W × H × D)	**396 × 604 × 291 mm**
GDTF fixture type	**55C52BA5-E8EF-4CA3-A2BD-9F…**

Controls

Focus · Frost · Iris · Prism · Prism rotation · Zoom · CMY colour mixing · Colour temperature · Colour wheel · Strobe · Dimmer · Pan and tilt · Movement speed · Animation wheel · Gobos · Gobo rotation

Safety-relevant functions

Fixture reset · Strobe

DMX modes

Standard 36CH	36 ch
Extended 52CH	52 ch

Standard 36CH

36 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Pan Fine	0	Fine byte of Pan
3	Tilt	128	
4	Tilt Fine	0	Fine byte of Tilt
5	Dimmer	0	0–254 Closed 255–255 Open
6	Dimmer Fine	0	Fine byte of Dimmer
7	Shutter / Strobe	50	0–31 Shutter closed 32–63 Shutter open1 64–94 min strobe 95–95 max strobe 96–127 shutter open2 128–158 min Pulse 159–159 max Pulse 160–191 shutter open3 192–222 min Random 223–223 max Random 224–255 shutter open4
8	Cyan	0	
9	Magenta	0	
10	Yellow	0	
11	C TO	0	0–254 6500K 255–255 2900K
12	Color Wheel	0	0–4 Color off (open) (wheel slot 1) 5–114 Color index 115–119 Open (wheel slot 1) 120–129 Deep Red (wheel slot 2) 130–139 Medium Blue (wheel slot 3) 140–149 Deep Green (wheel slot 4) 150–159 Amber (wheel slot 5) 160–169 Congo Blue (wheel slot 6) 170–179 CTB (wheel slot 7) 180–191 Color off (open) (wheel slot 1) 192–222 Slow to Fast CW 223–223 Stop 224–255 Fast to Slow CCW
13	Color Wheel Fine	0	Fine byte of Color Wheel
14	Gobo	0	0–5 Open (wheel slot 1) 6–20 Gobo 1 (wheel slot 2) 21–35 Gobo 2 (wheel slot 3) 36–50 Gobo 3 (wheel slot 4) 51–65 Gobo 4 (wheel slot 5) 66–80 Gobo 5 (wheel slot 6) 81–95 Gobo 6 (wheel slot 7) 96–110 Gobo 1 shake (wheel slot 2) 111–125 Gobo 2 shake (wheel slot 3) 126–140 Gobo 3 shake (wheel slot 4) 141–155 Gobo 4 shake (wheel slot 5) 156–170 Gobo 5 shake (wheel slot 6) 171–185 Gobo 6 shake (wheel slot 7) 186–192 open (wheel slot 1) 193–223 Slow to Fast CW 224–224 stop 225–255 Fast to Slow CCW

Standard 36CH (continued)

Ch	Function	Default	DMX values
15	Gobo Rotation	0	0–127 Gobo Indexing 128–190 Slow to Fast CW 191–191 stop 192–255 Fast to Slow CCW
16	Gobo Rotation Fine	0	Fine byte of Gobo Rotation
17	Gobo 2	0	0–5 open (wheel slot 1) 6–18 Gobo 1 (wheel slot 2) 19–31 Gobo 2 (wheel slot 3) 32–44 Gobo 3 (wheel slot 4) 45–57 Gobo 4 (wheel slot 5) 58–70 Gobo 5 (wheel slot 6) 71–83 Gobo 6 (wheel slot 7) 84–96 Gobo 7 (wheel slot 8) 97–109 Gobo 1 shake (wheel slot 2) 110–122 Gobo 2 shake (wheel slot 3) 123–135 Gobo 3 shake (wheel slot 4) 136–148 Gobo 4 shake (wheel slot 5) 149–161 Gobo 5 shake (wheel slot 6) 162–174 Gobo 6 shake (wheel slot 7) 175–187 Gobo 7 shake (wheel slot 8) 188–192 open (wheel slot 1) 193–223 Slow to Fast CW 224–224 stop 225–255 Fast to Slow CCW
18	Zoom	128	
19	Focus	0	
20	Iris	0	0–224 open 225–225 close 226–234 Pulse up slow 235–235 Pulse up fast 236–244 Pulse dowm slow 245–245 Pulse dowm fast 246–254 Random fast 255–255 Random slow
21	Prism	0	0–5 no Prism (wheel slot 1) 6–130 6 liner Prism (wheel slot 2) 131–255 4 Facet Prism (wheel slot 3)
22	Prism Rotation	0	0–5 Rot Off 6–128 index 0-540 129–191 slow to fast CW 192–192 STOP 193–255 fast to slow CCW
23	Frost1	0	
24	Frost2	0	
25	Animation Wheel1	0	0–5 Rot Off 6–128 index 0-540 129–191 Slow to Fast CW 192–192 stop 193–255 Fast to Slow CCW
26	Blade1A	0	
27	Blade1B	0	
28	Blade2A	0	
29	Blade2B	0	
30	Blade3A	0	
31	Blade3B	0	
32	Blade4A	0	

Standard 36CH (continued)

Ch	Function	Default	DMX values
33	Blade4B	0	
34	Shaper Rot	128	0–254 Rotation from 0 255–255 Rotation from 120
35	Dimmer Mode	0	0–20 Standard 21–40 Stage 41–60 TV 61–80 Architectural 81–100 Theater 101–255 Default to Unit Setting
36	Control1	0	0–5 No function 6–17 Invert Pan on(hold 3s) 18–29 Invert Pan off(hold 3s) 30–41 Invert Tilt on(hold 3s) 42–53 Invert Tilt off (hold 3s) 54–65 Fan Auto (hold 3s) 66–70 Fan Silent(hold 3s) 71–77 Fan High(hold 3s) 78–89 Linear Dimmer Curve(hold 3s) 90–101 Square Dimmer Curve (hold 3s) 102–113 Inv-Square Dimmer Curve(hold 3s) 114–125 S - Dimmer Curve(hold 3s) 126–137 1200 Hz(hold 3s) 138–149 3600 Hz (hold 3s) 150–161 5000Hz(hold 3s) 162–173 10000Hz(hold 3s) 174–185 15000 Hz(hold 3s) 186–197 20000Hz(hold 3s) 198–209 25000 Hz (hold 3s) 210–221 Reset Pan/Tilt(hold 3s) 222–233 Reset only Head(hold 3s) 234–255 Reset All Functions (hold 3s)

Extended 52CH

52 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Pan Fine	0	Fine byte of Pan
3	Tilt	128	
4	Tilt Fine	0	Fine byte of Tilt
5	Dimmer	0	0–254 Closed 255–255 Open
6	Dimmer Fine	0	Fine byte of Dimmer
7	Shutter / Strobe	50	0–31 Shutter closed 32–63 Shutter open1 64–94 min strobe 95–95 max strobe 96–127 shutter open2 128–158 min Pulse 159–159 max Pulse 160–191 shutter open3 192–222 min Random 223–223 max Random 224–255 shutter open4
8	Cyan	0	
9	Cyan Fine	0	Fine byte of Cyan
10	Magenta	0	

Extended 52CH (continued)

Ch	Function	Default	DMX values
11	Magenta Fine	0	Fine byte of Magenta
12	Yellow	0	
13	Yellow Fine	0	Fine byte of Yellow
14	C TO	0	0–254 6500K 255–255 2900K
15	C TO Fine	0	Fine byte of C TO
16	Color Wheel	0	0–4 Color off (open) (wheel slot 1) 5–114 Color index 115–119 Open (wheel slot 1) 120–129 Deep Red (wheel slot 2) 130–139 Medium Blue (wheel slot 3) 140–149 Deep Green (wheel slot 4) 150–159 Amber (wheel slot 5) 160–169 Congo Blue (wheel slot 6) 170–179 CTB (wheel slot 7) 180–191 Color off (open) (wheel slot 1) 192–222 Slow to Fast CW 223–223 Stop 224–255 Fast to Slow CCW
17	Color Wheel Fine	0	Fine byte of Color Wheel
18	Gobo	0	0–5 Open (wheel slot 1) 6–20 Gobo 1 (wheel slot 2) 21–35 Gobo 2 (wheel slot 3) 36–50 Gobo 3 (wheel slot 4) 51–65 Gobo 4 (wheel slot 5) 66–80 Gobo 5 (wheel slot 6) 81–95 Gobo 6 (wheel slot 7) 96–110 Gobo 1 shake (wheel slot 2) 111–125 Gobo 2 shake (wheel slot 3) 126–140 Gobo 3 shake (wheel slot 4) 141–155 Gobo 4 shake (wheel slot 5) 156–170 Gobo 5 shake (wheel slot 6) 171–185 Gobo 6 shake (wheel slot 7) 186–192 open (wheel slot 1) 193–223 Slow to Fast CW 224–224 stop 225–255 Fast to Slow CCW
19	Gobo Rotation	0	0–127 Gobo Indexing 128–190 Slow to Fast CW 191–191 stop 192–255 Fast to Slow CCW
20	Gobo Rotation Fine	0	Fine byte of Gobo Rotation

Extended 52CH (continued)

Ch	Function	Default	DMX values
21	Gobo 2	0	0–5 open (wheel slot 1) 6–18 Gobo 1 (wheel slot 2) 19–31 Gobo 2 (wheel slot 3) 32–44 Gobo 3 (wheel slot 4) 45–57 Gobo 4 (wheel slot 5) 58–70 Gobo 5 (wheel slot 6) 71–83 Gobo 6 (wheel slot 7) 84–96 Gobo 7 (wheel slot 8) 97–109 Gobo 1 shake (wheel slot 2) 110–122 Gobo 2 shake (wheel slot 3) 123–135 Gobo 3 shake (wheel slot 4) 136–148 Gobo 4 shake (wheel slot 5) 149–161 Gobo 5 shake (wheel slot 6) 162–174 Gobo 6 shake (wheel slot 7) 175–187 Gobo 7 shake (wheel slot 8) 188–192 open (wheel slot 1) 193–223 Slow to Fast CW 224–224 stop 225–255 Fast to Slow CCW
22	Zoom	128	
23	Zoom Fine	0	Fine byte of Zoom
24	Focus	0	
25	Focus Fine	0	Fine byte of Focus
26	Iris	0	0–224 open 225–225 close 226–234 Pulse up slow 235–235 Pulse up fast 236–244 Pulse dowm slow 245–245 Pulse dowm fast 246–254 Random fast 255–255 Random slow
27	Prism	0	0–5 no Prism (wheel slot 1) 6–130 6 liner Prism (wheel slot 2) 131–255 4 Facet Prism (wheel slot 3)
28	Prism Rotation	0	0–5 Rot Off 6–128 index 0-540 129–191 slow to fast CW 192–192 STOP 193–255 fast to slow CCW
29	Frost1	0	
30	Frost2	0	
31	Animation Wheel1	0	0–5 Rot Off 6–128 index 0-540 129–191 Slow to Fast CW 192–192 stop 193–255 Fast to Slow CCW
32	Blade1A	0	
33	Blade1A Fine	0	Fine byte of Blade1A
34	Blade1B	0	
35	Blade1B Fine	0	Fine byte of Blade1B
36	Blade2A	0	
37	Blade2A Fine	0	Fine byte of Blade2A
38	Blade2B	0	
39	Blade2B Fine	0	Fine byte of Blade2B
40	Blade3A	0	

Extended 52CH (continued)

Ch	Function	Default	DMX values
41	Blade3A Fine	0	Fine byte of Blade3A
42	Blade3B	0	
43	Blade3B Fine	0	Fine byte of Blade3B
44	Blade4A	0	
45	Blade4A Fine	0	Fine byte of Blade4A
46	Blade4B	0	
47	Blade4B Fine	0	Fine byte of Blade4B
48	Shaper Rot	128	0–254 Rotation from 0 255–255 Rotation from 120
49	Shaper Rot Fine	0	Fine byte of Shaper Rot
50	Position MSpeed	0	
51	Dimmer Mode	0	0–20 Standard 21–40 Stage 41–60 TV 61–80 Architectural 81–100 Theater 101–255 Default to Unit Setting
52	Control1	0	0–5 No function 6–17 Invert Pan on(hold 3s) 18–29 Invert Pan off(hold 3s) 30–41 Invert Tilt on(hold 3s) 42–53 Invert Tilt off (hold 3s) 54–65 Fan Auto (hold 3s) 66–70 Fan Silent(hold 3s) 71–77 Fan High(hold 3s) 78–89 Linear Dimmer Curve(hold 3s) 90–101 Square Dimmer Curve (hold 3s) 102–113 Inv-Square Dimmer Curve(hold 3s) 114–125 S - Dimmer Curve(hold 3s) 126–137 1200 Hz(hold 3s) 138–149 3600 Hz (hold 3s) 150–161 5000Hz(hold 3s) 162–173 10000Hz(hold 3s) 174–185 15000 Hz(hold 3s) 186–197 20000Hz(hold 3s) 198–209 25000 Hz (hold 3s) 210–221 Reset Pan/Tilt(hold 3s) 222–233 Reset only Head(hold 3s) 234–255 Reset All Functions (hold 3s)