CLF Lighting

# POSEIDON wash XS



| | |
|---|---|
| Manufacturer | **CLF Lighting** |
| Type | **Moving head** |
| DMX modes | **3** |
| DMX footprint | **20, 27, 55 channels** |
| Beam angle | **4-60°** |
| Pan range | **540°** |
| Tilt range | **246°** |
| Heads / cells | **2** |
| Size (W × H × D) | **190 × 260 × 190 mm** |
| GDTF fixture type | **E73D77A5-3B8B-40E7-B9B7-99…** |

## Controls

Zoom · Extra LED colours · Colour temperature · Colour wheel · Strobe · Dimmer · Pixel control · Movement speed · Gobos · Gobo rotation

## Safety-relevant functions

Fixture reset · Service functions

## DMX modes

| | |
|---|---|
| Mode1 - 20Ch | 20 ch |
| Mode2 - 27Ch 1 | 27 ch |
| Mode3 - 55Ch 1 | 55 ch |

## Mode1 - 20Ch

20 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Shutter / Strobe | 24 | 0–19 Closed<br>20–24 Open<br>25–63 Shutter1Strobe 2 · Str Fast 15–1.36 Hz<br>64–64 Shutter1Strobe 2 · Str Slow 1 Hz<br>65–69 Shutter1 3<br>70–83 StrobePulseOpen Max<br>84–84 StrobePulseOpen Min<br>85–89 open<br>90–103 StrobePulseClose Max<br>104–104 StrobePulseClose Min<br>105–109 Open<br>110–124 Shutter1StrobeRandom 8<br>125–129 open<br>130–149 Open<br>150–164 Shutter1StrobeRandomPulseClose 12<br>165–169 Open<br>170–183 Shutter Burst 14 strobe · Burst Min 1–18.6 Hz<br>184–184 Shutter Burst 14 strobe · Burst Max 20 Hz<br>185–189 Open<br>190–203 Rnd Burst 16 strobe · Rnd Burst Max 10–1.64 Hz<br>204–204 Rnd Burst 16 strobe · Rnd Burst Min 1 Hz<br>205–209 Open<br>210–223 StrobePulse Max<br>224–224 StrobePulse Min<br>225–229 Open<br>230–243 ShutterBurst 20 strobe · Burst Max 10–1.64 Hz<br>244–244 ShutterBurst 20 strobe · Burst Min 1 Hz<br>245–255 Open |
| 2 | Dimmer | 0 | 0–254 Closed<br>255–255 Open |
| 3 | Pan | 128 | 0–127 Min<br>128–254 Home<br>255–255 Max |
| 4 | Pan Fine | 0 | Fine byte of Pan |
| 5 | Tilt | 127 | 0–126 Min<br>127–254 Home<br>255–255 Max |
| 6 | Tilt Fine | 255 | Fine byte of Tilt |
| 7 | Position MSpeed | 0 | 0–254 Fast<br>255–255 Slow |
| 8 | Zoom | 255 | 0–126 Wide<br>127–254 Normal<br>255–255 Narrow |

## Mode1 - 20Ch (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 9 | Control1 | 0 | 0–9 No Function<br>10–14 Fixture Reset<br>60–64 Regulated FAN<br>65–69 Max FAN<br>70–74 Silent1 FAN<br>75–79 Silent2 FAN<br>80–89 No function<br>90–99 Calibrated Color<br>100–104 Raw Color<br>105–129 No function<br>130–134 1200HZ<br>135–139 2400HZ<br>140–144 4800HZ<br>145–149 10000HZ<br>150–154 No Function<br>155–164 Zoom Normal<br>165–169 Zoom Wide<br>170–174 No Function<br>175–179 W-DMX Reset<br>180–184 No Function<br>185–194 Normal<br>195–199 Smooth 1<br>200–204 Smooth 2<br>205–209 Smooth 3<br>210–214 Smooth 4<br>215–229 No Function<br>230–234 Pos reset<br>235–239 No Funktion<br>240–244 Zoom reset<br>245–249 No Function<br>250–255 Display ON |

## Mode1 - 20Ch (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **10** | Color Wheel | 0 | 0–4 ColorMix Activ (wheel slot 1)<br>5–5 RosaPink L002 (wheel slot 2)<br>6–6 Medium Bastard Amber L004 (wheel slot 3)<br>7–7 Pale Yellow L007 (wheel slot 4)<br>8–8 Dank Salmon L008 (wheel slot 5)<br>9–9 Pale Amber Gold L009 (wheel slot 6)<br>10–10 Medium Yellow L010 (wheel slot 7)<br>11–11 Straw Tint L013 (wheel slot 8)<br>12–12 Deep Straw L015 (wheel slot 9)<br>13–13 Surprice Peach L017 (wheel slot 10)<br>14–14 Medium Amber L020 (wheel slot 11)<br>15–15 Dank Amber L022 (wheel slot 12)<br>16–16 Sunset Red L025 (wheel slot 13)<br>17–17 Bright Red 026 (wheel slot 14)<br>18–18 Medium Pink L036 (wheel slot 15)<br>19–19 Rose Purple L048 (wheel slot 16)<br>20–20 Lavender L058 (wheel slot 17)<br>21–21 Pale Blue L063 (wheel slot 18)<br>22–22 Sky Blue L068 (wheel slot 19)<br>23–23 Tokio Blue L071 (wheel slot 20)<br>24–24 Evening Blue L075 (wheel slot 21)<br>25–25 Lime Green L088 (wheel slot 22)<br>26–26 Moos Green L089 (wheel slot 23)<br>27–27 Dark Yellow Green L090 (wheel slot 24)<br>28–28 Yellow L101 (wheel slot 25)<br>29–29 Straw L103 (wheel slot 26)<br>30–30 Deep Amber L104 (wheel slot 27)<br>31–31 Orange L105 (wheel slot 28)<br>32–32 Primary Red L106 (wheel slot 29)<br>33–33 Light Rose L107 (wheel slot 30)<br>34–34 English Rose L108 (wheel slot 31)<br>35–35 Light Salmon L109 (wheel slot 32)<br>36–36 Middle Rose L110 (wheel slot 33)<br>37–37 Dark Pink L111 (wheel slot 34)<br>38–38 Magenta L113 (wheel slot 35)<br>39–39 Peacock Blue L115 (wheel slot 36)<br>40–40 Steel Blue L117 (wheel slot 37)<br>41–41 Light Blue L118 (wheel slot 38)<br>42–42 Dark Blue L119 (wheel slot 39)<br>43–43 LEE Green L121 (wheel slot 40)<br>44–44 Fern Green L122 (wheel slot 41)<br>45–45 Dark Green L124 (wheel slot 42)<br>46–46 Mauve L126 (wheel slot 43)<br>47–47 Smokey Pink L127 (wheel slot 44)<br>48–48 Brigh Pink L128 (wheel slot 45)<br>49–49 Marine Blue L131 (wheel slot 46)<br>50–50 Medium Blue L132 (wheel slot 47)<br>51–51 Golden Amber L134 (wheel slot 48)<br>52–52 Deep golden Amber L135 (wheel slot 49)<br>53–53 Special Lavender L137 (wheel slot 50)<br>54–54 Pale Green L138 (wheel slot 51)<br>55–55 Primary Green L139 (wheel slot 52)<br>56–56 Summer Blue L140 (wheel slot 53)<br>57–57 Bright blue L141 (wheel slot 54)<br>58–58 Pale Violet L142 (wheel slot 55)<br>59–59 Pale Navy Blue L143 (wheel slot 56)<br>60–60 No color Blue L144 (wheel slot 57)<br>61–61 Apricot L147 (wheel slot 58)<br>62–62 Bright Rose L148 (wheel slot 59)<br>63–63 Gold Tint L151 (wheel slot 60)<br>64–64 Pale Gold L152 (wheel slot 61)<br>65–65 Pale Salmon L153 (wheel slot 62)<br>66–66 Pale Rose L154 (wheel slot 63)<br>67–67 Chocolate L156 (wheel slot 64) |

## Mode1 - 20Ch (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **11** | Red | 255 | |
| **12** | Green | 255 | |
| **13** | Blue | 255 | |
| **14** | Color Add GY | 255 | |
| **15** | Gobo | 0 | 0–4 Open (wheel slot 1)<br>5–9 Wheel Slot 1 (wheel slot 2)<br>10–14 Wheel Slot 2 (wheel slot 3)<br>15–19 Wheel Slot 3 (wheel slot 4)<br>20–24 Wheel Slot 4 (wheel slot 5)<br>25–29 Wheel Slot 5 (wheel slot 6)<br>30–34 Wheel Slot 6 (wheel slot 7)<br>35–39 Wheel Slot 7 (wheel slot 8)<br>40–44 Wheel Slot 8 (wheel slot 9)<br>45–49 Wheel Slot 9 (wheel slot 10)<br>50–54 Wheel Slot 10 (wheel slot 11)<br>55–59 Wheel Slot 11 (wheel slot 12)<br>60–64 Wheel Slot 12 (wheel slot 13)<br>65–69 Wheel Slot 13 (wheel slot 14)<br>70–74 Wheel Slot 14 (wheel slot 15)<br>75–79 Wheel Slot 15 (wheel slot 16)<br>80–84 Wheel Slot 16 (wheel slot 17)<br>85–89 Wheel Slot 17 (wheel slot 18)<br>90–94 Wheel Slot 18 (wheel slot 19)<br>95–99 Wheel Slot 19 (wheel slot 20)<br>100–104 Wheel Slot 20 (wheel slot 21)<br>105–109 Wheel Slot 21 (wheel slot 22)<br>110–114 Wheel Slot 22 (wheel slot 23)<br>115–119 Wheel Slot 23 (wheel slot 24)<br>120–124 Wheel Slot 24 (wheel slot 25)<br>125–129 Wheel Slot 25 (wheel slot 26)<br>130–134 Wheel Slot 26 (wheel slot 27)<br>135–139 Wheel Slot 27 (wheel slot 28)<br>140–144 Wheel Slot 28 (wheel slot 29)<br>145–149 Wheel Slot 29 (wheel slot 30)<br>150–154 Wheel Slot 30 (wheel slot 31)<br>155–159 Wheel Slot 31 (wheel slot 32)<br>160–164 Wheel Slot 32 (wheel slot 33)<br>165–169 Wheel Slot 33 (wheel slot 34)<br>170–174 Wheel Slot 34 (wheel slot 35)<br>175–179 Wheel Slot 35 (wheel slot 36)<br>180–184 Wheel Slot 36 (wheel slot 37)<br>185–189 Wheel Slot 37 (wheel slot 38)<br>190–194 Wheel Slot 38 (wheel slot 39)<br>195–199 Wheel Slot 39 (wheel slot 40)<br>200–204 Wheel Slot 40 (wheel slot 41)<br>205–209 Wheel Slot 41 (wheel slot 42)<br>210–214 Wheel Slot 42 (wheel slot 43)<br>215–219 Wheel Slot 43 (wheel slot 44)<br>220–224 Wheel Slot 44 (wheel slot 45)<br>225–229 Wheel Slot 45 (wheel slot 46)<br>230–234 Wheel Slot 46 (wheel slot 47)<br>235–239 Wheel Slot 47 (wheel slot 48)<br>240–244 Wheel Slot 48 (wheel slot 49)<br>245–249 Wheel Slot 49 (wheel slot 50)<br>250–254 Wheel Slot 50 (wheel slot 51)<br>255–255 Wheel Slot 51 (wheel slot 52) |

## Mode1 - 20Ch (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **16** | Gobo 2 | 0 | 0–4 Open (wheel slot 1)<br>5–9 Wheel Slot 1 (wheel slot 2)<br>10–14 Wheel Slot 2 (wheel slot 3)<br>15–19 Wheel Slot 3 (wheel slot 4)<br>20–24 Wheel Slot 4 (wheel slot 5)<br>25–29 Wheel Slot 5 (wheel slot 6)<br>30–34 Wheel Slot 6 (wheel slot 7)<br>35–39 Wheel Slot 7 (wheel slot 8)<br>40–44 Wheel Slot 8 (wheel slot 9)<br>45–49 Wheel Slot 9 (wheel slot 10)<br>50–54 Wheel Slot 10 (wheel slot 11)<br>55–59 Wheel Slot 11 (wheel slot 12)<br>60–64 Wheel Slot 12 (wheel slot 13)<br>65–69 Wheel Slot 13 (wheel slot 14)<br>70–74 Wheel Slot 14 (wheel slot 15)<br>75–79 Wheel Slot 15 (wheel slot 16)<br>80–84 Wheel Slot 16 (wheel slot 17)<br>85–89 Wheel Slot 17 (wheel slot 18)<br>90–94 Wheel Slot 18 (wheel slot 19)<br>95–99 Wheel Slot 19 (wheel slot 20)<br>100–104 Wheel Slot 20 (wheel slot 21)<br>105–109 Wheel Slot 21 (wheel slot 22)<br>110–114 Wheel Slot 22 (wheel slot 23)<br>115–119 Wheel Slot 23 (wheel slot 24)<br>120–255 Wheel Slot 24 (wheel slot 25) |
| **17** | Gobo Rotation | 0 | 0–125 >>><br>126–126 ><br>127–128 Stop<br>129–254 <<br>255–255 <<< |
| **18** | Reserved 18 | 0 | |

## Mode1 - 20Ch (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **19** | Color Wheel | 0 | 0–4 ColorMix Activ (wheel slot 1)<br>5–5 RosaPink L002 (wheel slot 2)<br>6–6 Medium Bastard Amber L004 (wheel slot 3)<br>7–7 Pale Yellow L007 (wheel slot 4)<br>8–8 Dank Salmon L008 (wheel slot 5)<br>9–9 Pale Amber Gold L009 (wheel slot 6)<br>10–10 Medium Yellow L010 (wheel slot 7)<br>11–11 Straw Tint L013 (wheel slot 8)<br>12–12 Deep Straw L015 (wheel slot 9)<br>13–13 Surprice Peach L017 (wheel slot 10)<br>14–14 Medium Amber L020 (wheel slot 11)<br>15–15 Dank Amber L022 (wheel slot 12)<br>16–16 Sunset Red L025 (wheel slot 13)<br>17–17 Bright Red 026 (wheel slot 14)<br>18–18 Medium Pink L036 (wheel slot 15)<br>19–19 Rose Purple L048 (wheel slot 16)<br>20–20 Lavender L058 (wheel slot 17)<br>21–21 Pale Blue L063 (wheel slot 18)<br>22–22 Sky Blue L068 (wheel slot 19)<br>23–23 Tokio Blue L071 (wheel slot 20)<br>24–24 Evening Blue L075 (wheel slot 21)<br>25–25 Lime Green L088 (wheel slot 22)<br>26–26 Moos Green L089 (wheel slot 23)<br>27–27 Dark Yellow Green L090 (wheel slot 24)<br>28–28 Yellow L101 (wheel slot 25)<br>29–29 Straw L103 (wheel slot 26)<br>30–30 Deep Amber L104 (wheel slot 27)<br>31–31 Orange L105 (wheel slot 28)<br>32–32 Primary Red L106 (wheel slot 29)<br>33–33 Light Rose L107 (wheel slot 30)<br>34–34 English Rose L108 (wheel slot 31)<br>35–35 Light Salmon L109 (wheel slot 32)<br>36–36 Middle Rose L110 (wheel slot 33)<br>37–37 Dark Pink L111 (wheel slot 34)<br>38–38 Magenta L113 (wheel slot 35)<br>39–39 Peacock Blue L115 (wheel slot 36)<br>40–40 Steel Blue L117 (wheel slot 37)<br>41–41 Light Blue L118 (wheel slot 38)<br>42–42 Dark Blue L119 (wheel slot 39)<br>43–43 LEE Green L121 (wheel slot 40)<br>44–44 Fern Green L122 (wheel slot 41)<br>45–45 Dark Green L124 (wheel slot 42)<br>46–46 Mauve L126 (wheel slot 43)<br>47–47 Smokey Pink L127 (wheel slot 44)<br>48–48 Brigh Pink L128 (wheel slot 45)<br>49–49 Marine Blue L131 (wheel slot 46)<br>50–50 Medium Blue L132 (wheel slot 47)<br>51–51 Golden Amber L134 (wheel slot 48)<br>52–52 Deep golden Amber L135 (wheel slot 49)<br>53–53 Special Lavender L137 (wheel slot 50)<br>54–54 Pale Green L138 (wheel slot 51)<br>55–55 Primary Green L139 (wheel slot 52)<br>56–56 Summer Blue L140 (wheel slot 53)<br>57–57 Bright blue L141 (wheel slot 54)<br>58–58 Pale Violet L142 (wheel slot 55)<br>59–59 Pale Navy Blue L143 (wheel slot 56)<br>60–60 No color Blue L144 (wheel slot 57)<br>61–61 Apricot L147 (wheel slot 58)<br>62–62 Bright Rose L148 (wheel slot 59)<br>63–63 Gold Tint L151 (wheel slot 60)<br>64–64 Pale Gold L152 (wheel slot 61)<br>65–65 Pale Salmon L153 (wheel slot 62)<br>66–66 Pale Rose L154 (wheel slot 63)<br>67–67 Chocolate L156 (wheel slot 64) |

### Mode1 - 20Ch (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **20** | Dimmer | 0 | 0–254 Closed<br>255–255 Open |

## Mode2 - 27Ch 1

27 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **1** | Shutter / Strobe | 24 | 0–19 Closed<br>20–24 Open<br>25–63 Shutter1Strobe 2 · Str Fast 15–1.36 Hz<br>64–64 Shutter1Strobe 2 · Str Slow 1 Hz<br>65–69 Shutter1 3<br>70–83 StrobePulseOpen Max<br>84–84 StrobePulseOpen Min<br>85–89 open<br>90–103 StrobePulseClose Max<br>104–104 StrobePulseClose Min<br>105–109 Open<br>110–124 Shutter1StrobeRandom 8<br>125–129 open<br>130–149 Open<br>150–164 Shutter1StrobeRandomPulseClose 12<br>165–169 Open<br>170–183 Shutter Burst 14 strobe · Burst Min 1–18.6 Hz<br>184–184 Shutter Burst 14 strobe · Burst Max 20 Hz<br>185–189 Open<br>190–203 Rnd Burst 16 strobe · Rnd Burst Max 10–1.64 Hz<br>204–204 Rnd Burst 16 strobe · Rnd Burst Min 1 Hz<br>205–209 Open<br>210–223 StrobePulse Max<br>224–224 StrobePulse Min<br>225–229 Open<br>230–243 ShutterBurst 20 strobe · Burst Max 10–1.64 Hz<br>244–244 ShutterBurst 20 strobe · Burst Min 1 Hz<br>245–255 Open |
| **2** | Dimmer | 0 | 0–254 Closed<br>255–255 Open |
| **3** | Dimmer Fine | 0 | Fine byte of Dimmer |
| **4** | Pan | 128 | 0–127 Min<br>128–254 Home<br>255–255 Max |
| **5** | Pan Fine | 0 | Fine byte of Pan |
| **6** | Tilt | 127 | 0–126 Min<br>127–254 Home<br>255–255 Max |
| **7** | Tilt Fine | 255 | Fine byte of Tilt |
| **8** | Position MSpeed | 0 | 0–254 Fast<br>255–255 Slow |
| **9** | Zoom | 255 | 0–126 Wide<br>127–254 Normal<br>255–255 Narrow |

## Mode2 - 27Ch 1 (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **10** | Control1 | 0 | 0–9 No Function<br>10–14 Fixture Reset<br>60–64 Regulated FAN<br>65–69 Max FAN<br>70–74 Silent1 FAN<br>75–79 Silent2 FAN<br>80–89 No function<br>90–99 Calibrated Color<br>100–104 Raw Color<br>105–129 No function<br>130–134 1200HZ<br>135–139 2400HZ<br>140–144 4800HZ<br>145–149 10000HZ<br>150–154 No Function<br>155–164 Zoom Normal<br>165–169 Zoom Wide<br>170–174 No Function<br>175–179 W-DMX Reset<br>180–184 No Function<br>185–194 Normal<br>195–199 Smooth 1<br>200–204 Smooth 2<br>205–209 Smooth 3<br>210–214 Smooth 4<br>215–229 No Function<br>230–234 Pos reset<br>235–239 No Funktion<br>240–244 Zoom reset<br>245–249 No Function<br>250–255 Display ON |

## Mode2 - 27Ch 1 (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **11** | Color Wheel | 0 | 0–4 ColorMix Activ (wheel slot 1)<br>5–5 RosaPink L002 (wheel slot 2)<br>6–6 Medium Bastard Amber L004 (wheel slot 3)<br>7–7 Pale Yellow L007 (wheel slot 4)<br>8–8 Dank Salmon L008 (wheel slot 5)<br>9–9 Pale Amber Gold L009 (wheel slot 6)<br>10–10 Medium Yellow L010 (wheel slot 7)<br>11–11 Straw Tint L013 (wheel slot 8)<br>12–12 Deep Straw L015 (wheel slot 9)<br>13–13 Surprice Peach L017 (wheel slot 10)<br>14–14 Medium Amber L020 (wheel slot 11)<br>15–15 Dank Amber L022 (wheel slot 12)<br>16–16 Sunset Red L025 (wheel slot 13)<br>17–17 Bright Red 026 (wheel slot 14)<br>18–18 Medium Pink L036 (wheel slot 15)<br>19–19 Rose Purple L048 (wheel slot 16)<br>20–20 Lavender L058 (wheel slot 17)<br>21–21 Pale Blue L063 (wheel slot 18)<br>22–22 Sky Blue L068 (wheel slot 19)<br>23–23 Tokio Blue L071 (wheel slot 20)<br>24–24 Evening Blue L075 (wheel slot 21)<br>25–25 Lime Green L088 (wheel slot 22)<br>26–26 Moos Green L089 (wheel slot 23)<br>27–27 Dark Yellow Green L090 (wheel slot 24)<br>28–28 Yellow L101 (wheel slot 25)<br>29–29 Straw L103 (wheel slot 26)<br>30–30 Deep Amber L104 (wheel slot 27)<br>31–31 Orange L105 (wheel slot 28)<br>32–32 Primary Red L106 (wheel slot 29)<br>33–33 Light Rose L107 (wheel slot 30)<br>34–34 English Rose L108 (wheel slot 31)<br>35–35 Light Salmon L109 (wheel slot 32)<br>36–36 Middle Rose L110 (wheel slot 33)<br>37–37 Dark Pink L111 (wheel slot 34)<br>38–38 Magenta L113 (wheel slot 35)<br>39–39 Peacock Blue L115 (wheel slot 36)<br>40–40 Steel Blue L117 (wheel slot 37)<br>41–41 Light Blue L118 (wheel slot 38)<br>42–42 Dark Blue L119 (wheel slot 39)<br>43–43 LEE Green L121 (wheel slot 40)<br>44–44 Fern Green L122 (wheel slot 41)<br>45–45 Dark Green L124 (wheel slot 42)<br>46–46 Mauve L126 (wheel slot 43)<br>47–47 Smokey Pink L127 (wheel slot 44)<br>48–48 Brigh Pink L128 (wheel slot 45)<br>49–49 Marine Blue L131 (wheel slot 46)<br>50–50 Medium Blue L132 (wheel slot 47)<br>51–51 Golden Amber L134 (wheel slot 48)<br>52–52 Deep golden Amber L135 (wheel slot 49)<br>53–53 Special Lavender L137 (wheel slot 50)<br>54–54 Pale Green L138 (wheel slot 51)<br>55–55 Primary Green L139 (wheel slot 52)<br>56–56 Summer Blue L140 (wheel slot 53)<br>57–57 Bright blue L141 (wheel slot 54)<br>58–58 Pale Violet L142 (wheel slot 55)<br>59–59 Pale Navy Blue L143 (wheel slot 56)<br>60–60 No color Blue L144 (wheel slot 57)<br>61–61 Apricot L147 (wheel slot 58)<br>62–62 Bright Rose L148 (wheel slot 59)<br>63–63 Gold Tint L151 (wheel slot 60)<br>64–64 Pale Gold L152 (wheel slot 61)<br>65–65 Pale Salmon L153 (wheel slot 62)<br>66–66 Pale Rose L154 (wheel slot 63)<br>67–67 Chocolate L156 (wheel slot 64) |

## Mode2 - 27Ch 1 (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **12** | Red | 255 | |
| **13** | Red Fine | 255 | Fine byte of Red |
| **14** | Green | 255 | |
| **15** | Green Fine | 255 | Fine byte of Green |
| **16** | Blue | 255 | |
| **17** | Blue Fine | 255 | Fine byte of Blue |
| **18** | Color Add GY | 255 | |
| **19** | Color Add GY Fine | 255 | Fine byte of Color Add GY |
| **20** | C TC | 0 | 0–5 Open<br>6–254 10000K<br>255–255 2500K |
| **21** | Tint | 1 | 0–0 No Function<br>1–127 Minus Green<br>128–254 Neutral<br>255–255 Plus Green |

## Mode2 - 27Ch 1 (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 22 | Gobo | 0 | 0–4 Open (wheel slot 1)<br>5–9 Wheel Slot 1 (wheel slot 2)<br>10–14 Wheel Slot 2 (wheel slot 3)<br>15–19 Wheel Slot 3 (wheel slot 4)<br>20–24 Wheel Slot 4 (wheel slot 5)<br>25–29 Wheel Slot 5 (wheel slot 6)<br>30–34 Wheel Slot 6 (wheel slot 7)<br>35–39 Wheel Slot 7 (wheel slot 8)<br>40–44 Wheel Slot 8 (wheel slot 9)<br>45–49 Wheel Slot 9 (wheel slot 10)<br>50–54 Wheel Slot 10 (wheel slot 11)<br>55–59 Wheel Slot 11 (wheel slot 12)<br>60–64 Wheel Slot 12 (wheel slot 13)<br>65–69 Wheel Slot 13 (wheel slot 14)<br>70–74 Wheel Slot 14 (wheel slot 15)<br>75–79 Wheel Slot 15 (wheel slot 16)<br>80–84 Wheel Slot 16 (wheel slot 17)<br>85–89 Wheel Slot 17 (wheel slot 18)<br>90–94 Wheel Slot 18 (wheel slot 19)<br>95–99 Wheel Slot 19 (wheel slot 20)<br>100–104 Wheel Slot 20 (wheel slot 21)<br>105–109 Wheel Slot 21 (wheel slot 22)<br>110–114 Wheel Slot 22 (wheel slot 23)<br>115–119 Wheel Slot 23 (wheel slot 24)<br>120–124 Wheel Slot 24 (wheel slot 25)<br>125–129 Wheel Slot 25 (wheel slot 26)<br>130–134 Wheel Slot 26 (wheel slot 27)<br>135–139 Wheel Slot 27 (wheel slot 28)<br>140–144 Wheel Slot 28 (wheel slot 29)<br>145–149 Wheel Slot 29 (wheel slot 30)<br>150–154 Wheel Slot 30 (wheel slot 31)<br>155–159 Wheel Slot 31 (wheel slot 32)<br>160–164 Wheel Slot 32 (wheel slot 33)<br>165–169 Wheel Slot 33 (wheel slot 34)<br>170–174 Wheel Slot 34 (wheel slot 35)<br>175–179 Wheel Slot 35 (wheel slot 36)<br>180–184 Wheel Slot 36 (wheel slot 37)<br>185–189 Wheel Slot 37 (wheel slot 38)<br>190–194 Wheel Slot 38 (wheel slot 39)<br>195–199 Wheel Slot 39 (wheel slot 40)<br>200–204 Wheel Slot 40 (wheel slot 41)<br>205–209 Wheel Slot 41 (wheel slot 42)<br>210–214 Wheel Slot 42 (wheel slot 43)<br>215–219 Wheel Slot 43 (wheel slot 44)<br>220–224 Wheel Slot 44 (wheel slot 45)<br>225–229 Wheel Slot 45 (wheel slot 46)<br>230–234 Wheel Slot 46 (wheel slot 47)<br>235–239 Wheel Slot 47 (wheel slot 48)<br>240–244 Wheel Slot 48 (wheel slot 49)<br>245–249 Wheel Slot 49 (wheel slot 50)<br>250–254 Wheel Slot 50 (wheel slot 51)<br>255–255 Wheel Slot 51 (wheel slot 52) |

## Mode2 - 27Ch 1 (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **23** | Gobo 2 | 0 | 0–4 Open (wheel slot 1)<br>5–9 Wheel Slot 1 (wheel slot 2)<br>10–14 Wheel Slot 2 (wheel slot 3)<br>15–19 Wheel Slot 3 (wheel slot 4)<br>20–24 Wheel Slot 4 (wheel slot 5)<br>25–29 Wheel Slot 5 (wheel slot 6)<br>30–34 Wheel Slot 6 (wheel slot 7)<br>35–39 Wheel Slot 7 (wheel slot 8)<br>40–44 Wheel Slot 8 (wheel slot 9)<br>45–49 Wheel Slot 9 (wheel slot 10)<br>50–54 Wheel Slot 10 (wheel slot 11)<br>55–59 Wheel Slot 11 (wheel slot 12)<br>60–64 Wheel Slot 12 (wheel slot 13)<br>65–69 Wheel Slot 13 (wheel slot 14)<br>70–74 Wheel Slot 14 (wheel slot 15)<br>75–79 Wheel Slot 15 (wheel slot 16)<br>80–84 Wheel Slot 16 (wheel slot 17)<br>85–89 Wheel Slot 17 (wheel slot 18)<br>90–94 Wheel Slot 18 (wheel slot 19)<br>95–99 Wheel Slot 19 (wheel slot 20)<br>100–104 Wheel Slot 20 (wheel slot 21)<br>105–109 Wheel Slot 21 (wheel slot 22)<br>110–114 Wheel Slot 22 (wheel slot 23)<br>115–119 Wheel Slot 23 (wheel slot 24)<br>120–255 Wheel Slot 24 (wheel slot 25) |
| **24** | Gobo Rotation | 0 | 0–125 >>><br>126–126 ><br>127–128 Stop<br>129–254 <<br>255–255 <<< |
| **25** | Reserved 25 | 0 | |

## Mode2 - 27Ch 1 (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **26** | Color Wheel | 0 | 0–4 ColorMix Activ (wheel slot 1)<br>5–5 RosaPink L002 (wheel slot 2)<br>6–6 Medium Bastard Amber L004 (wheel slot 3)<br>7–7 Pale Yellow L007 (wheel slot 4)<br>8–8 Dank Salmon L008 (wheel slot 5)<br>9–9 Pale Amber Gold L009 (wheel slot 6)<br>10–10 Medium Yellow L010 (wheel slot 7)<br>11–11 Straw Tint L013 (wheel slot 8)<br>12–12 Deep Straw L015 (wheel slot 9)<br>13–13 Surprice Peach L017 (wheel slot 10)<br>14–14 Medium Amber L020 (wheel slot 11)<br>15–15 Dank Amber L022 (wheel slot 12)<br>16–16 Sunset Red L025 (wheel slot 13)<br>17–17 Bright Red 026 (wheel slot 14)<br>18–18 Medium Pink L036 (wheel slot 15)<br>19–19 Rose Purple L048 (wheel slot 16)<br>20–20 Lavender L058 (wheel slot 17)<br>21–21 Pale Blue L063 (wheel slot 18)<br>22–22 Sky Blue L068 (wheel slot 19)<br>23–23 Tokio Blue L071 (wheel slot 20)<br>24–24 Evening Blue L075 (wheel slot 21)<br>25–25 Lime Green L088 (wheel slot 22)<br>26–26 Moos Green L089 (wheel slot 23)<br>27–27 Dark Yellow Green L090 (wheel slot 24)<br>28–28 Yellow L101 (wheel slot 25)<br>29–29 Straw L103 (wheel slot 26)<br>30–30 Deep Amber L104 (wheel slot 27)<br>31–31 Orange L105 (wheel slot 28)<br>32–32 Primary Red L106 (wheel slot 29)<br>33–33 Light Rose L107 (wheel slot 30)<br>34–34 English Rose L108 (wheel slot 31)<br>35–35 Light Salmon L109 (wheel slot 32)<br>36–36 Middle Rose L110 (wheel slot 33)<br>37–37 Dark Pink L111 (wheel slot 34)<br>38–38 Magenta L113 (wheel slot 35)<br>39–39 Peacock Blue L115 (wheel slot 36)<br>40–40 Steel Blue L117 (wheel slot 37)<br>41–41 Light Blue L118 (wheel slot 38)<br>42–42 Dark Blue L119 (wheel slot 39)<br>43–43 LEE Green L121 (wheel slot 40)<br>44–44 Fern Green L122 (wheel slot 41)<br>45–45 Dark Green L124 (wheel slot 42)<br>46–46 Mauve L126 (wheel slot 43)<br>47–47 Smokey Pink L127 (wheel slot 44)<br>48–48 Brigh Pink L128 (wheel slot 45)<br>49–49 Marine Blue L131 (wheel slot 46)<br>50–50 Medium Blue L132 (wheel slot 47)<br>51–51 Golden Amber L134 (wheel slot 48)<br>52–52 Deep golden Amber L135 (wheel slot 49)<br>53–53 Special Lavender L137 (wheel slot 50)<br>54–54 Pale Green L138 (wheel slot 51)<br>55–55 Primary Green L139 (wheel slot 52)<br>56–56 Summer Blue L140 (wheel slot 53)<br>57–57 Bright blue L141 (wheel slot 54)<br>58–58 Pale Violet L142 (wheel slot 55)<br>59–59 Pale Navy Blue L143 (wheel slot 56)<br>60–60 No color Blue L144 (wheel slot 57)<br>61–61 Apricot L147 (wheel slot 58)<br>62–62 Bright Rose L148 (wheel slot 59)<br>63–63 Gold Tint L151 (wheel slot 60)<br>64–64 Pale Gold L152 (wheel slot 61)<br>65–65 Pale Salmon L153 (wheel slot 62)<br>66–66 Pale Rose L154 (wheel slot 63)<br>67–67 Chocolate L156 (wheel slot 64) |

### Mode2 - 27Ch 1 (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 27 | Dimmer | 0 | 0–254 Closed<br>255–255 Open |

## Mode3 - 55Ch 1

55 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Shutter / Strobe | 24 | 0–19 Closed<br>20–24 Open<br>25–63 Shutter1Strobe 2 · Str Fast 15–1.36 Hz<br>64–64 Shutter1Strobe 2 · Str Slow 1 Hz<br>65–69 Shutter1 3<br>70–83 StrobePulseOpen Max<br>84–84 StrobePulseOpen Min<br>85–89 open<br>90–103 StrobePulseClose Max<br>104–104 StrobePulseClose Min<br>105–109 Open<br>110–124 Shutter1StrobeRandom 8<br>125–129 open<br>130–149 Open<br>150–164 Shutter1StrobeRandomPulseClose 12<br>165–169 Open<br>170–183 Shutter Burst 14 strobe · Burst Min 1–18.6 Hz<br>184–184 Shutter Burst 14 strobe · Burst Max 20 Hz<br>185–189 Open<br>190–203 Rnd Burst 16 strobe · Rnd Burst Max 10–1.64 Hz<br>204–204 Rnd Burst 16 strobe · Rnd Burst Min 1 Hz<br>205–209 Open<br>210–223 StrobePulse Max<br>224–224 StrobePulse Min<br>225–229 Open<br>230–243 ShutterBurst 20 strobe · Burst Max 10–1.64 Hz<br>244–244 ShutterBurst 20 strobe · Burst Min 1 Hz<br>245–255 Open |
| 2 | Dimmer | 0 | 0–254 Closed<br>255–255 Open |
| 3 | Dimmer Fine | 0 | Fine byte of Dimmer |
| 4 | Pan | 128 | 0–127 Min<br>128–254 Home<br>255–255 Max |
| 5 | Pan Fine | 0 | Fine byte of Pan |
| 6 | Tilt | 127 | 0–126 Min<br>127–254 Home<br>255–255 Max |
| 7 | Tilt Fine | 255 | Fine byte of Tilt |
| 8 | Position MSpeed | 0 | 0–254 Fast<br>255–255 Slow |
| 9 | Zoom | 255 | 0–126 Wide<br>127–254 Normal<br>255–255 Narrow |

## Mode3 - 55Ch 1 (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **10** | Control1 | 0 | 0–9 No Function<br>10–14 Fixture Reset<br>60–64 Regulated FAN<br>65–69 Max FAN<br>70–74 Silent1 FAN<br>75–79 Silent2 FAN<br>80–89 No function<br>90–99 Calibrated Color<br>100–104 Raw Color<br>105–129 No function<br>130–134 1200HZ<br>135–139 2400HZ<br>140–144 4800HZ<br>145–149 10000HZ<br>150–154 No Function<br>155–164 Zoom Normal<br>165–169 Zoom Wide<br>170–174 No Function<br>175–179 W-DMX Reset<br>180–184 No Function<br>185–194 Normal<br>195–199 Smooth 1<br>200–204 Smooth 2<br>205–209 Smooth 3<br>210–214 Smooth 4<br>215–229 No Function<br>230–234 Pos reset<br>235–239 No Funktion<br>240–244 Zoom reset<br>245–249 No Function<br>250–255 Display ON |

## Mode3 - 55Ch 1 (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **11** | Color Wheel | 0 | 0–4 ColorMix Activ (wheel slot 1)<br>5–5 RosaPink L002 (wheel slot 2)<br>6–6 Medium Bastard Amber L004 (wheel slot 3)<br>7–7 Pale Yellow L007 (wheel slot 4)<br>8–8 Dank Salmon L008 (wheel slot 5)<br>9–9 Pale Amber Gold L009 (wheel slot 6)<br>10–10 Medium Yellow L010 (wheel slot 7)<br>11–11 Straw Tint L013 (wheel slot 8)<br>12–12 Deep Straw L015 (wheel slot 9)<br>13–13 Surprice Peach L017 (wheel slot 10)<br>14–14 Medium Amber L020 (wheel slot 11)<br>15–15 Dank Amber L022 (wheel slot 12)<br>16–16 Sunset Red L025 (wheel slot 13)<br>17–17 Bright Red 026 (wheel slot 14)<br>18–18 Medium Pink L036 (wheel slot 15)<br>19–19 Rose Purple L048 (wheel slot 16)<br>20–20 Lavender L058 (wheel slot 17)<br>21–21 Pale Blue L063 (wheel slot 18)<br>22–22 Sky Blue L068 (wheel slot 19)<br>23–23 Tokio Blue L071 (wheel slot 20)<br>24–24 Evening Blue L075 (wheel slot 21)<br>25–25 Lime Green L088 (wheel slot 22)<br>26–26 Moos Green L089 (wheel slot 23)<br>27–27 Dark Yellow Green L090 (wheel slot 24)<br>28–28 Yellow L101 (wheel slot 25)<br>29–29 Straw L103 (wheel slot 26)<br>30–30 Deep Amber L104 (wheel slot 27)<br>31–31 Orange L105 (wheel slot 28)<br>32–32 Primary Red L106 (wheel slot 29)<br>33–33 Light Rose L107 (wheel slot 30)<br>34–34 English Rose L108 (wheel slot 31)<br>35–35 Light Salmon L109 (wheel slot 32)<br>36–36 Middle Rose L110 (wheel slot 33)<br>37–37 Dark Pink L111 (wheel slot 34)<br>38–38 Magenta L113 (wheel slot 35)<br>39–39 Peacock Blue L115 (wheel slot 36)<br>40–40 Steel Blue L117 (wheel slot 37)<br>41–41 Light Blue L118 (wheel slot 38)<br>42–42 Dark Blue L119 (wheel slot 39)<br>43–43 LEE Green L121 (wheel slot 40)<br>44–44 Fern Green L122 (wheel slot 41)<br>45–45 Dark Green L124 (wheel slot 42)<br>46–46 Mauve L126 (wheel slot 43)<br>47–47 Smokey Pink L127 (wheel slot 44)<br>48–48 Brigh Pink L128 (wheel slot 45)<br>49–49 Marine Blue L131 (wheel slot 46)<br>50–50 Medium Blue L132 (wheel slot 47)<br>51–51 Golden Amber L134 (wheel slot 48)<br>52–52 Deep golden Amber L135 (wheel slot 49)<br>53–53 Special Lavender L137 (wheel slot 50)<br>54–54 Pale Green L138 (wheel slot 51)<br>55–55 Primary Green L139 (wheel slot 52)<br>56–56 Summer Blue L140 (wheel slot 53)<br>57–57 Bright blue L141 (wheel slot 54)<br>58–58 Pale Violet L142 (wheel slot 55)<br>59–59 Pale Navy Blue L143 (wheel slot 56)<br>60–60 No color Blue L144 (wheel slot 57)<br>61–61 Apricot L147 (wheel slot 58)<br>62–62 Bright Rose L148 (wheel slot 59)<br>63–63 Gold Tint L151 (wheel slot 60)<br>64–64 Pale Gold L152 (wheel slot 61)<br>65–65 Pale Salmon L153 (wheel slot 62)<br>66–66 Pale Rose L154 (wheel slot 63)<br>67–67 Chocolate L156 (wheel slot 64) |

## Mode3 - 55Ch 1 (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 12 | Red | 255 | |
| 13 | Red Fine | 255 | Fine byte of Red |
| 14 | Green | 255 | |
| 15 | Green Fine | 255 | Fine byte of Green |
| 16 | Blue | 255 | |
| 17 | Blue Fine | 255 | Fine byte of Blue |
| 18 | Color Add GY | 255 | |
| 19 | Color Add GY Fine | 255 | Fine byte of Color Add GY |
| 20 | Reserved 20 | 0 | |
| 21 | Reserved 21 | 0 | |
| 22 | Reserved 22 | 0 | |
| 23 | Reserved 23 | 0 | |
| 24 | Reserved 24 | 0 | |
| 25 | Reserved 25 | 0 | |
| 26 | Reserved 26 | 0 | |
| 27 | Reserved 27 | 0 | |
| 28 | Reserved 28 | 0 | |
| 29 | Reserved 29 | 0 | |
| 30 | Reserved 30 | 0 | |
| 31 | Reserved 31 | 0 | |
| 32 | Reserved 32 | 0 | |
| 33 | Reserved 33 | 0 | |
| 34 | Reserved 34 | 0 | |
| 35 | Reserved 35 | 0 | |
| 36 | Reserved 36 | 0 | |
| 37 | Reserved 37 | 0 | |
| 38 | Reserved 38 | 0 | |
| 39 | Reserved 39 | 0 | |
| 40 | Reserved 40 | 0 | |
| 41 | Reserved 41 | 0 | |
| 42 | Reserved 42 | 0 | |
| 43 | Reserved 43 | 0 | |
| 44 | Reserved 44 | 0 | |
| 45 | Reserved 45 | 0 | |
| 46 | Reserved 46 | 0 | |
| 47 | Reserved 47 | 0 | |
| 48 | C TC | 0 | 0–5 Open<br>6–254 10000K<br>255–255 2500K |
| 49 | Tint | 1 | 0–0 No Function<br>1–127 Minus Green<br>128–254 Neutral<br>255–255 Plus Green |

## Mode3 - 55Ch 1 (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **50** | Gobo | 0 | 0–4 Open (wheel slot 1)<br>5–9 Wheel Slot 1 (wheel slot 2)<br>10–14 Wheel Slot 2 (wheel slot 3)<br>15–19 Wheel Slot 3 (wheel slot 4)<br>20–24 Wheel Slot 4 (wheel slot 5)<br>25–29 Wheel Slot 5 (wheel slot 6)<br>30–34 Wheel Slot 6 (wheel slot 7)<br>35–39 Wheel Slot 7 (wheel slot 8)<br>40–44 Wheel Slot 8 (wheel slot 9)<br>45–49 Wheel Slot 9 (wheel slot 10)<br>50–54 Wheel Slot 10 (wheel slot 11)<br>55–59 Wheel Slot 11 (wheel slot 12)<br>60–64 Wheel Slot 12 (wheel slot 13)<br>65–69 Wheel Slot 13 (wheel slot 14)<br>70–74 Wheel Slot 14 (wheel slot 15)<br>75–79 Wheel Slot 15 (wheel slot 16)<br>80–84 Wheel Slot 16 (wheel slot 17)<br>85–89 Wheel Slot 17 (wheel slot 18)<br>90–94 Wheel Slot 18 (wheel slot 19)<br>95–99 Wheel Slot 19 (wheel slot 20)<br>100–104 Wheel Slot 20 (wheel slot 21)<br>105–109 Wheel Slot 21 (wheel slot 22)<br>110–114 Wheel Slot 22 (wheel slot 23)<br>115–119 Wheel Slot 23 (wheel slot 24)<br>120–124 Wheel Slot 24 (wheel slot 25)<br>125–129 Wheel Slot 25 (wheel slot 26)<br>130–134 Wheel Slot 26 (wheel slot 27)<br>135–139 Wheel Slot 27 (wheel slot 28)<br>140–144 Wheel Slot 28 (wheel slot 29)<br>145–149 Wheel Slot 29 (wheel slot 30)<br>150–154 Wheel Slot 30 (wheel slot 31)<br>155–159 Wheel Slot 31 (wheel slot 32)<br>160–164 Wheel Slot 32 (wheel slot 33)<br>165–169 Wheel Slot 33 (wheel slot 34)<br>170–174 Wheel Slot 34 (wheel slot 35)<br>175–179 Wheel Slot 35 (wheel slot 36)<br>180–184 Wheel Slot 36 (wheel slot 37)<br>185–189 Wheel Slot 37 (wheel slot 38)<br>190–194 Wheel Slot 38 (wheel slot 39)<br>195–199 Wheel Slot 39 (wheel slot 40)<br>200–204 Wheel Slot 40 (wheel slot 41)<br>205–209 Wheel Slot 41 (wheel slot 42)<br>210–214 Wheel Slot 42 (wheel slot 43)<br>215–219 Wheel Slot 43 (wheel slot 44)<br>220–224 Wheel Slot 44 (wheel slot 45)<br>225–229 Wheel Slot 45 (wheel slot 46)<br>230–234 Wheel Slot 46 (wheel slot 47)<br>235–239 Wheel Slot 47 (wheel slot 48)<br>240–244 Wheel Slot 48 (wheel slot 49)<br>245–249 Wheel Slot 49 (wheel slot 50)<br>250–254 Wheel Slot 50 (wheel slot 51)<br>255–255 Wheel Slot 51 (wheel slot 52) |

## Mode3 - 55Ch 1 (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **51** | Gobo 2 | 0 | 0–4 Open (wheel slot 1)<br>5–9 Wheel Slot 1 (wheel slot 2)<br>10–14 Wheel Slot 2 (wheel slot 3)<br>15–19 Wheel Slot 3 (wheel slot 4)<br>20–24 Wheel Slot 4 (wheel slot 5)<br>25–29 Wheel Slot 5 (wheel slot 6)<br>30–34 Wheel Slot 6 (wheel slot 7)<br>35–39 Wheel Slot 7 (wheel slot 8)<br>40–44 Wheel Slot 8 (wheel slot 9)<br>45–49 Wheel Slot 9 (wheel slot 10)<br>50–54 Wheel Slot 10 (wheel slot 11)<br>55–59 Wheel Slot 11 (wheel slot 12)<br>60–64 Wheel Slot 12 (wheel slot 13)<br>65–69 Wheel Slot 13 (wheel slot 14)<br>70–74 Wheel Slot 14 (wheel slot 15)<br>75–79 Wheel Slot 15 (wheel slot 16)<br>80–84 Wheel Slot 16 (wheel slot 17)<br>85–89 Wheel Slot 17 (wheel slot 18)<br>90–94 Wheel Slot 18 (wheel slot 19)<br>95–99 Wheel Slot 19 (wheel slot 20)<br>100–104 Wheel Slot 20 (wheel slot 21)<br>105–109 Wheel Slot 21 (wheel slot 22)<br>110–114 Wheel Slot 22 (wheel slot 23)<br>115–119 Wheel Slot 23 (wheel slot 24)<br>120–255 Wheel Slot 24 (wheel slot 25) |
| **52** | Gobo Rotation | 0 | 0–125 >>><br>126–126 ><br>127–128 Stop<br>129–254 <<br>255–255 <<< |
| **53** | Reserved 53 | 0 | |

## Mode3 - 55Ch 1 (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **54** | Color Wheel | 0 | 0–4 ColorMix Activ (wheel slot 1)<br>5–5 RosaPink L002 (wheel slot 2)<br>6–6 Medium Bastard Amber L004 (wheel slot 3)<br>7–7 Pale Yellow L007 (wheel slot 4)<br>8–8 Dank Salmon L008 (wheel slot 5)<br>9–9 Pale Amber Gold L009 (wheel slot 6)<br>10–10 Medium Yellow L010 (wheel slot 7)<br>11–11 Straw Tint L013 (wheel slot 8)<br>12–12 Deep Straw L015 (wheel slot 9)<br>13–13 Surprice Peach L017 (wheel slot 10)<br>14–14 Medium Amber L020 (wheel slot 11)<br>15–15 Dank Amber L022 (wheel slot 12)<br>16–16 Sunset Red L025 (wheel slot 13)<br>17–17 Bright Red 026 (wheel slot 14)<br>18–18 Medium Pink L036 (wheel slot 15)<br>19–19 Rose Purple L048 (wheel slot 16)<br>20–20 Lavender L058 (wheel slot 17)<br>21–21 Pale Blue L063 (wheel slot 18)<br>22–22 Sky Blue L068 (wheel slot 19)<br>23–23 Tokio Blue L071 (wheel slot 20)<br>24–24 Evening Blue L075 (wheel slot 21)<br>25–25 Lime Green L088 (wheel slot 22)<br>26–26 Moos Green L089 (wheel slot 23)<br>27–27 Dark Yellow Green L090 (wheel slot 24)<br>28–28 Yellow L101 (wheel slot 25)<br>29–29 Straw L103 (wheel slot 26)<br>30–30 Deep Amber L104 (wheel slot 27)<br>31–31 Orange L105 (wheel slot 28)<br>32–32 Primary Red L106 (wheel slot 29)<br>33–33 Light Rose L107 (wheel slot 30)<br>34–34 English Rose L108 (wheel slot 31)<br>35–35 Light Salmon L109 (wheel slot 32)<br>36–36 Middle Rose L110 (wheel slot 33)<br>37–37 Dark Pink L111 (wheel slot 34)<br>38–38 Magenta L113 (wheel slot 35)<br>39–39 Peacock Blue L115 (wheel slot 36)<br>40–40 Steel Blue L117 (wheel slot 37)<br>41–41 Light Blue L118 (wheel slot 38)<br>42–42 Dark Blue L119 (wheel slot 39)<br>43–43 LEE Green L121 (wheel slot 40)<br>44–44 Fern Green L122 (wheel slot 41)<br>45–45 Dark Green L124 (wheel slot 42)<br>46–46 Mauve L126 (wheel slot 43)<br>47–47 Smokey Pink L127 (wheel slot 44)<br>48–48 Brigh Pink L128 (wheel slot 45)<br>49–49 Marine Blue L131 (wheel slot 46)<br>50–50 Medium Blue L132 (wheel slot 47)<br>51–51 Golden Amber L134 (wheel slot 48)<br>52–52 Deep golden Amber L135 (wheel slot 49)<br>53–53 Special Lavender L137 (wheel slot 50)<br>54–54 Pale Green L138 (wheel slot 51)<br>55–55 Primary Green L139 (wheel slot 52)<br>56–56 Summer Blue L140 (wheel slot 53)<br>57–57 Bright blue L141 (wheel slot 54)<br>58–58 Pale Violet L142 (wheel slot 55)<br>59–59 Pale Navy Blue L143 (wheel slot 56)<br>60–60 No color Blue L144 (wheel slot 57)<br>61–61 Apricot L147 (wheel slot 58)<br>62–62 Bright Rose L148 (wheel slot 59)<br>63–63 Gold Tint L151 (wheel slot 60)<br>64–64 Pale Gold L152 (wheel slot 61)<br>65–65 Pale Salmon L153 (wheel slot 62)<br>66–66 Pale Rose L154 (wheel slot 63)<br>67–67 Chocolate L156 (wheel slot 64) |

## Mode3 - 55Ch 1 (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **55** | Dimmer | 0 | 0–254 Closed<br>255–255 Open |