CLXSQUAD

STROBE 1000 9CH



Manufacturer	**CLXSQUAD**
Type	**Strobe**
DMX modes	**3**
DMX footprint	**6, 9 channels**
Beam angle	**25°**
Size (W × H × D)	**480 × 150 × 275 mm**
GDTF fixture type	**1B15336C-87C1-4B4D-B7AE-0C…**

Controls

Extra LED colours · RGB colour mixing · Strobe · Dimmer · Gobos

Safety-relevant functions

Strobe

DMX modes

6 channels	6 ch
9CH mode A	9 ch
9CH mode B	9 ch

6 channels

6 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Shutter / Strobe	0	0–9 No function 10–255 Slow/fast
3	Red	0	
4	Green	0	
5	Blue	0	
6	White	0	

9CH mode A

9 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Shutter / Strobe	0	0–9 No function 10–255 Slow/fast
3	Red	0	
4	Green	0	
5	Blue	0	
6	Gobo	0	
7	Gobo1Select Spin	0	0–6 CH2-CH4 control 7–13 Pattern 1 14–20 Pattern 2 21–27 Pattern 3 28–34 Pattern 4 35–41 Pattern 5 42–48 Pattern 6 49–55 Pattern 7 56–62 Pattern 8 63–69 Pattern 9 70–76 Pattern 10 77–83 Pattern 11 84–90 Pattern 13 91–97 Pattern 14 98–104 Pattern 15 105–111 Pattern 16 112–118 Pattern 17 119–125 Pattern 18 126–132 Pattern 19 133–139 Pattern 20 140–146 Pattern 21 147–153 Pattern 22 154–160 Pattern 23 161–167 Pattern 24 168–174 Pattern 25 175–181 Pattern 26 182–188 Pattern 27 189–195 Pattern 28 196–202 Pattern 29 203–209 Pattern 30 210–216 Pattern 31 217–224 Pattern 32 225–231 Pattern 33 232–237 Pattern 34 238–244 Pattern 35 245–251 Self moving effect 252–255 Voice control

9CH mode A (continued)

Ch	Function	Default	DMX values
8	Gobo 2	0	0–6 CH5 control 7–13 Effect 1 14–20 Effect 2 21–27 Effect 3 28–34 Effect 4 35–41 Effect 5 42–48 Effect 6 49–55 Effect 7 56–62 Effect 8 63–69 Effect 9 70–76 Effect 10 77–83 Effect 11 84–90 Effect 12 91–97 Effect 13 98–104 Effect 14 105–111 Effect 15 112–118 Effect 16 119–125 Effect 17 126–132 Effect 18 133–139 Effect 19 140–146 Effect 20 147–153 Effect 21 154–160 Effect 22 161–167 Effect 23 168–174 Effect 24 175–181 Effect 25 182–188 Effect 26 189–195 Effect 27 196–202 Effect 28 203–209 Effect 29 210–216 Effect 30 217–223 Effect 31 224–230 Effect 32 231–255 Self walking effect
9	Gobo2Select Spin	0	

9CH mode B

9 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Red	0	
3	Green	0	
4	Blue	0	
5	Shutter / Strobe	0	0–9 No function 10–255 Slow/fast
6	Gobo	0	

9CH mode B (continued)

Ch	Function	Default	DMX values
7	Gobo1Select Spin	0	0–6 CH2-CH4 control 7–13 Pattern 1 14–20 Pattern 2 21–27 Pattern 3 28–34 Pattern 4 35–41 Pattern 5 42–48 Pattern 6 49–55 Pattern 7 56–62 Pattern 8 63–69 Pattern 9 70–76 Pattern 10 77–83 Pattern 11 84–90 Pattern 13 91–97 Pattern 14 98–104 Pattern 15 105–111 Pattern 16 112–118 Pattern 17 119–125 Pattern 18 126–132 Pattern 19 133–139 Pattern 20 140–146 Pattern 21 147–153 Pattern 22 154–160 Pattern 23 161–167 Pattern 24 168–174 Pattern 25 175–181 Pattern 26 182–188 Pattern 27 189–195 Pattern 28 196–202 Pattern 29 203–209 Pattern 30 210–216 Pattern 31 217–224 Pattern 32 225–231 Pattern 33 232–237 Pattern 34 238–244 Pattern 35 245–251 Self moving effect 252–255 Voice control

9CH mode B (continued)

Ch	Function	Default	DMX values
8	Gobo 2	0	0–6 CH5 control 7–13 Effect 1 14–20 Effect 2 21–27 Effect 3 28–34 Effect 4 35–41 Effect 5 42–48 Effect 6 49–55 Effect 7 56–62 Effect 8 63–69 Effect 9 70–76 Effect 10 77–83 Effect 11 84–90 Effect 12 91–97 Effect 13 98–104 Effect 14 105–111 Effect 15 112–118 Effect 16 119–125 Effect 17 126–132 Effect 18 133–139 Effect 19 140–146 Effect 20 147–153 Effect 21 154–160 Effect 22 161–167 Effect 23 168–174 Effect 24 175–181 Effect 25 182–188 Effect 26 189–195 Effect 27 196–202 Effect 28 203–209 Effect 29 210–216 Effect 30 217–223 Effect 31 224–230 Effect 32 231–255 Self walking effect
9	Gobo2Select Spin	0	