Cyclops Lighting

# Lede 100B



| | |
|---|---|
| Manufacturer | **Cyclops Lighting** |
| Type | **Moving head** |
| DMX modes | **1** |
| DMX footprint | **16 channels** |
| Beam angle | **3°** |
| Pan range | **270°** |
| Tilt range | **540°** |
| Size (W × H × D) | **41 × 10 × 41 mm** |
| GDTF fixture type | **1A32287B-F4CF-4000-CE20-20F…** |

## Controls

Focus · Frost · Prism · Prism rotation · Colour wheel · Dimmer · Pan and tilt · Gobos

## Safety-relevant functions

Fixture reset

## DMX modes

16 channels — 16 ch

## 16 channels

16 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Pan | 128 | |
| 2 | Pan Fine | 128 | Fine byte of Pan |
| 3 | Tilt | 128 | |
| 4 | Tilt Fine | 128 | Fine byte of Tilt |
| 5 | Pan Tilt Mode | 0 | |
| 6 | Shutter1Strobe | 0 | 0–3 Open<br>4–127 Pulse strobe 0 to100%<br>128–191 Fade Strobe 0 to 100%<br>192–255 Random Strobe 0 to 100% |
| 7 | Dimmer | 0 | |
| 8 | Color Wheel | 0 | 0–4 Open<br>5–63 Color 1<br>64–69 Color 1 + Open<br>70–75 Color 1 + 2<br>76–80 Color 2 + 3<br>81–86 Color 3 +4<br>87–92 Color 4 + 5<br>93–98 Color 5 + 6<br>99–103 Color 6 + 7<br>104–109 Color 7 + 8<br>110–115 Color 8 + 9<br>116–121 Color 9 + 10<br>122–127 Color 10 + Open<br>128–191 >>> Rainbow Fast to slow<br>192–255 Rainbow Slow to Fast <<< |
| 9 | Color Wheel 2 | 0 | |
| 10 | Gobo | 0 | 0–8 Open<br>9–127 Gobo 1<br>128–191 >>> Fast to slow<br>192–255 Slow to Fast <<< |
| 11 | Gobo1Select Shake | 255 | |
| 12 | Prism | 0 | 0–127 Open<br>128–255 Prism On |
| 13 | Prism Rotation | 0 | 0–127 Prism Index<br>128–190 >>> Prism Rotation<br>191–192 Stop<br>193–255 Prism Rotation <<< |
| 14 | Frost1 | 0 | 0–127 Frost OFF<br>128–255 Frost ON |
| 15 | Focus | 0 | |
| 16 | Control1 | 0 | |