DLW

DLW L1240C4 LC



Manufacturer	**DLW**
Type	**Moving head**
DMX modes	**3**
DMX footprint	**4, 13, 17 channels**
Beam angle	**4.5-40°**
Tilt range	**210°**
Size (W × H × D)	**1018 × 212 × 106 mm**
GDTF fixture type	**6CAB3E10-CEED-4098-BAD3-82…**

Controls

Zoom · Extra LED colours · RGB colour mixing · Colour temperature · Effect speed · Strobe · Dimmer · Pan and tilt · Movement speed

Safety-relevant functions

Fixture reset · Strobe · Built-in effect programmes

DMX modes

Pixel	4 ch
57Ch	13 ch
17Ch	17 ch

Pixel

4 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	White	0	

57Ch

13 channels

Ch	Function	Default	DMX values
1	Tilt	128	
2	Tilt Fine	0	Fine byte of Tilt
3	Dimmer	0	0–254 Closed 255–255 Open
4	Dimmer Fine	0	Fine byte of Dimmer
5	Shutter / Strobe	104	0–3 Closed 4–102 min Strobe 103–103 max Strobe 104–107 Open 108–206 min Pulse 207–207 max Pulse 208–212 Open 2 213–250 min Rnd 251–251 max Rnd 252–255 Open 3
6	Zoom	127	0–126 wide 127–254 normal 255–255 narrow
7	Reserved	0	
8	Control1	0	0–127 No function 128–255 Reset all
9	Position MSpeed	0	
10	Red	255	
11	Green	255	
12	Blue	255	
13	White	0	

17Ch

17 channels

Ch	Function	Default	DMX values
1	Tilt	128	
2	Tilt Fine	0	Fine byte of Tilt
3	Dimmer	0	0–254 Closed 255–255 Open
4	Shutter / Strobe	104	0–3 Closed 4–102 min Strobe 103–103 max Strobe 104–107 Open 108–206 min Pulse 207–207 max Pulse 208–212 Open 2 213–250 min Rnd 251–251 max Rnd 252–255 Open 3

17Ch (continued)

Ch	Function	Default	DMX values
5	Red	255	
6	Green	255	
7	Blue	255	
8	White	0	
9	Zoom	127	0–126 wide 127–254 normal 255–255 narrow
10	C TO	0	0–0 No function 1–27 2800K 28–55 3200K 56–83 3600K 84–111 4500K 112–139 5000K 140–167 5600K 168–195 6200K 196–223 6800K 224–251 7500K 252–255 8000K
11	Effect	0	0–0 No function 1–2 LED 1 3–4 LED 2 5–6 LED 3 7–8 LED 4 9–10 LED 5 11–12 LED 6 13–14 LED 7 15–16 LED 8 17–18 LED 9 19–20 LED 10 21–22 LED 11 23–24 LED 12 25–34 Effect 1 35–43 Effect 2 44–53 Effect 3 54–62 Effect 4 63–72 Effect 5 73–81 Effect 6 82–91 Effect 7 92–100 Effect 8 101–110 Effect 9 111–119 Effect 10 120–129 Effect 11 130–138 Effect 12 139–148 Effect 13 149–157 Effect 14 158–167 Effect 15 168–176 Effect 16 177–186 Effect 17 187–195 Effect 18 196–205 Effect 19 206–214 Effect 20 215–224 Effect 21 225–233 Effect 22 234–243 Effect 23 244–252 Effect 24 253–255 Effect 25
12	Foreground	0	
13	Bachground	0	

17Ch (continued)

Ch	Function	Default	DMX values
14	Effect Macro	0	0–0 No function 1–15 Macro 1 16–31 Macro 2 32–63 Macro 3 64–95 Macro 4 96–127 Macro 5 128–159 Macro 6 160–191 Macro 7 192–255 Macro 8
15	Effect Speed	0	
16	Control1	0	0–127 No function 128–255 Reset all
17	Position MSpeed	0	