DLW

DREAM 400C7 BRIGHT



Manufacturer	**DLW**
Type	**Effect light**
DMX modes	**6**
DMX footprint	**7, 9, 11, 14, 17, 22 channels**
Beam angle	**45°**
Heads / cells	**2**
Size (W × H × D)	**627 × 353 × 331 mm**
GDTF fixture type	**11E34427-69B9-4476-8248-721…**

Controls

Extra LED colours · Hue and saturation · RGB colour mixing · Colour temperature · Colour wheel · Effect speed · Strobe · Dimmer · Pixel control

Safety-relevant functions

Built-in effect programmes

DMX modes

HISC-7Ch	7 ch
PIXEL1-9Ch	9 ch
SSP-17Ch	11 ch
TOUR-14Ch	14 ch
PIXEL2-17Ch	17 ch
TOUR16-22Ch	22 ch

HISC-7Ch

7 channels

Ch	Function	Default	DMX values
1	H SBBrightness	100	
2	H SBHue	0	
3	H SBHue Fine	0	Fine byte of H SBHue
4	H SBSaturation	0	
5	C TO	0	0–10 Off 11–30 2700K 31–50 3000K 51–70 3200K 71–90 3500K 91–110 4000K 111–130 4200K 131–150 4500K 151–170 5600K 171–190 6000K 191–210 6500K 211–230 7200K 231–255 8000K
6	Shutter / Strobe	105	0–9 Open 10–98 min Strobe 99–99 max Strobe 100–109 Open 110–178 min Pulse 179–179 max Pulse 180–189 Open 2 190–254 min Random 255–255 max Random
7	Dimmer Mode	0	0–9 Dimmer Speed is set by the menu 10–49 Dimmer Speed fast 50–99 Dimmer Speed 1 100–149 Dimmer Speed 2 150–199 Dimmer Speed 3 200–255 Dimmer Speed 4(slow)

PIXEL1-9Ch

9 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open
2	Red	255	
3	Green	255	
4	Blue	255	

PIXEL1-9Ch (continued)

Ch	Function	Default	DMX values
5	Color Macro1	0	0–10 Off 11–20 L106 21–30 R05 31–40 L194 41–50 R54 51–60 L019 61–70 R08 71–80 R89 81–90 R86 91–100 L213 101–110 R377 111–120 R80 121–130 L202 131–140 L328 141–150 R3314 151–160 L101 161–170 L768 171–255 No function
6	Red	255	
7	Green	255	
8	Blue	255	
9	Color Macro2	0	0–10 Off 11–30 Macro 1 31–50 Macro 2 51–70 Macro 3 71–90 Macro 4 91–110 Macro 5 111–130 Macro 6 131–150 Macro 7 151–170 Macro 8 171–195 LED Full 196–200 2700K 201–205 3000K 206–210 3200K 211–215 3500K 216–220 4000K 221–225 4200K 226–230 4500K 231–235 5600K 236–240 6000K 241–245 6500K 246–250 7200K 251–255 8000K

SSP-17Ch

11 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open
2	Red	255	
3	Green	255	
4	Blue	255	
5	Color Add GY	0	
6	Color Add RY	0	
7	Color Add C	0	
8	Color Add BC	0	

SSP-17Ch (continued)

Ch	Function	Default	DMX values
9	Color Macro1	0	0–10 Off 11–20 L106 21–30 R05 31–40 L194 41–50 R54 51–60 L019 61–70 R08 71–80 R89 81–90 R86 91–100 L213 101–110 R377 111–120 R80 121–130 L202 131–140 L328 141–150 R3314 151–160 L101 161–170 L768 171–255 No function
10	Shutter / Strobe	105	0–9 Open 10–98 min Strobe 99–99 max Strobe 100–109 Open 110–178 min Pulse 179–179 max Pulse 180–189 Open 2 190–254 min Random 255–255 max Random
11	Dimmer Mode	0	0–9 Dimmer Speed is set by the menu 10–49 Dimmer Speed fast 50–99 Dimmer Speed 1 100–149 Dimmer Speed 2 150–199 Dimmer Speed 3 200–255 Dimmer Speed 4(slow)

TOUR-14Ch

14 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open
2	Red	255	
3	Green	255	
4	Blue	255	
5	Color Add GY	0	
6	Color Add RY	0	
7	Color Add C	0	
8	Color Add BC	0	

TOUR-14Ch (continued)

Ch	Function	Default	DMX values
9	Color Macro1	0	0–10 Off 11–20 L106 21–30 R05 31–40 L194 41–50 R54 51–60 L019 61–70 R08 71–80 R89 81–90 R86 91–100 L213 101–110 R377 111–120 R80 121–130 L202 131–140 L328 141–150 R3314 151–160 L101 161–170 L768 171–255 No function
10	Color Macro2	0	0–10 Off 11–30 Macro 1 31–50 Macro 2 51–70 Macro 3 71–90 Macro 4 91–110 Macro 5 111–130 Macro 6 131–150 Macro 7 151–170 Macro 8 171–195 LED Full 196–200 2700K 201–205 3000K 206–210 3200K 211–215 3500K 216–220 4000K 221–225 4200K 226–230 4500K 231–235 5600K 236–240 6000K 241–245 6500K 246–250 7200K 251–255 8000K
11	Shutter / Strobe	105	0–9 Open 10–98 min Strobe 99–99 max Strobe 100–109 Open 110–178 min Pulse 179–179 max Pulse 180–189 Open 2 190–254 min Random 255–255 max Random
12	Effect	0	0–9 No function 10–127 Automatic grasient 128–255 Automatic jump
13	Effect Speed	0	
14	Dimmer Mode	0	0–9 Dimmer Speed is set by the menu 10–49 Dimmer Speed fast 50–99 Dimmer Speed 1 100–149 Dimmer Speed 2 150–199 Dimmer Speed 3 200–255 Dimmer Speed 4(slow)

PIXEL2-17Ch

17 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open
2	Red	255	
3	Green	255	
4	Blue	255	
5	Color Add GY	0	
6	Color Add RY	0	
7	Color Add C	0	
8	Color Add BC	0	
9	Color Macro1	0	0–10 Off 11–20 L106 21–30 R05 31–40 L194 41–50 R54 51–60 L019 61–70 R08 71–80 R89 81–90 R86 91–100 L213 101–110 R377 111–120 R80 121–130 L202 131–140 L328 141–150 R3314 151–160 L101 161–170 L768 171–255 No function
10	Red	255	
11	Green	255	
12	Blue	255	
13	Color Add GY	0	
14	Color Add RY	0	
15	Color Add C	0	
16	Color Add BC	0	
17	Color Macro1	0	0–10 Off 11–20 L106 21–30 R05 31–40 L194 41–50 R54 51–60 L019 61–70 R08 71–80 R89 81–90 R86 91–100 L213 101–110 R377 111–120 R80 121–130 L202 131–140 L328 141–150 R3314 151–160 L101 161–170 L768 171–255 No function

TOUR16-22Ch

22 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open
2	Dimmer Fine	0	Fine byte of Dimmer
3	Red	255	
4	Red Fine	255	Fine byte of Red
5	Green	255	
6	Green Fine	255	Fine byte of Green
7	Blue	255	
8	Blue Fine	255	Fine byte of Blue
9	Color Add GY	0	
10	Color Add GY Fine	0	Fine byte of Color Add GY
11	Color Add RY	0	
12	Color Add RY Fine	0	Fine byte of Color Add RY
13	Color Add C	0	
14	Color Add C Fine	0	Fine byte of Color Add C
15	Color Add BC	0	
16	Color Add BC Fine	0	Fine byte of Color Add BC
17	Color Macro1	0	0–10 Off 11–20 L106 21–30 R05 31–40 L194 41–50 R54 51–60 L019 61–70 R08 71–80 R89 81–90 R86 91–100 L213 101–110 R377 111–120 R80 121–130 L202 131–140 L328 141–150 R3314 151–160 L101 161–170 L768 171–255 No function

TOUR16-22Ch (continued)

Ch	Function	Default	DMX values
18	Color Macro2	0	0–10 Off 11–30 Macro 1 31–50 Macro 2 51–70 Macro 3 71–90 Macro 4 91–110 Macro 5 111–130 Macro 6 131–150 Macro 7 151–170 Macro 8 171–195 LED Full 196–200 2700K 201–205 3000K 206–210 3200K 211–215 3500K 216–220 4000K 221–225 4200K 226–230 4500K 231–235 5600K 236–240 6000K 241–245 6500K 246–250 7200K 251–255 8000K
19	Shutter / Strobe	105	0–9 Open 10–98 min Strobe 99–99 max Strobe 100–109 Open 110–178 min Pulse 179–179 max Pulse 180–189 Open 2 190–254 min Random 255–255 max Random
20	Effect	0	0–9 No function 10–127 Automatic grasient 128–255 Automatic jump
21	Effect Speed	0	
22	Dimmer Mode	0	0–9 Dimmer Speed is set by the menu 10–49 Dimmer Speed fast 50–99 Dimmer Speed 1 100–149 Dimmer Speed 2 150–199 Dimmer Speed 3 200–255 Dimmer Speed 4(slow)