EK Lights

LitePanel T18



Manufacturer	**EK Lights**
Type	**Effect light**
DMX modes	**4**
DMX footprint	**3, 5, 9, 13 channels**
Beam angle	**15°**
Heads / cells	**3**
Size (W × H × D)	**395 × 130 × 45 mm**
GDTF fixture type	**0C6E2617-6360-4250-A4C3-974…**

Controls

RGB colour mixing · Colour wheel · Effect speed · Dimmer · Pixel control

Safety-relevant functions

Built-in effect programmes

DMX modes

3 Channel Mode	3 ch
5 Channel Mode	5 ch
9 Channel Mode	9 ch
13 Channel Mode	13 ch

3 Channel Mode

3 channels

Ch	Function	Default	DMX values
1	Red	0	
2	Green	0	
3	Blue	0	

5 Channel Mode

5 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open
2	Red	0	
3	Green	0	
4	Blue	0	
5	Strobe Mode Shutter	0	0–10 Open 11–254 Strobe Slow 255–255 Strobe Fast

9 Channel Mode

9 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open
2	Red	0	
3	Green	0	
4	Blue	0	
5	Strobe Mode Shutter	0	0–10 Open 11–254 Strobe Slow 255–255 Strobe Fast
6	Color Macro1	11	0–10 No Function 11–30 R 100% G 0-100% B 0% 31–50 R 100-0% G 100% B 0% 51–70 R 0% G 100% B 0-100% 71–90 R 0% G 100-0% B 100% 91–110 R 0-100% G 0% B 100% 111–130 R 100% G 0% B 100-0% 131–150 R 100% G 0-100% B 0-100% 151–170 R 100-0% G 100-0% B 100% 171–200 R 100% G 100% B 100% 201–205 Color Temperature 1 206–210 Color Temperature 2 211–215 Color Temperature 3 216–220 Color Temperature 4 221–225 Color Temperature 5 226–230 Color Temperature 6 231–235 Color Temperature 7 236–240 Color Temperature 8 241–245 Color Temperature 9 246–250 Color Temperature 10 251–255 Color Temperature 11

9 Channel Mode (continued)

Ch	Function	Default	DMX values
7	Effect	11	0–10 No Function 11–28 Chase 1 29–45 Chase 2 46–62 Chase 3 63–79 Chase 4 80–96 Chase 5 97–113 Chase 6 114–130 Chase 7 131–147 Chase 8 148–164 Chase 9 165–181 Chase 10 182–198 Chase 11 199–215 Chase 12 216–232 Chase 13 233–250 Chase 14 251–255 Sound Show
8	Effect Speed	0	0–254 Slow 255–255 Fast
9	Dimmer Mode	0	0–51 Set from Menu 52–101 Dimmer Mode Off 102–152 Dimmer Mode 1 153–203 Dimmer Mode 2 204–255 Dimmer Mode 3

13 Channel Mode

13 channels

Ch	Function	Default	DMX values
1	Red	0	
2	Green	0	
3	Blue	0	
4	Red	0	
5	Green	0	
6	Blue	0	
7	Red	0	
8	Green	0	
9	Blue	0	
10	Effect	0	0–10 No Function 11–28 Chase 1 29–45 Chase 2 46–62 Chase 3 63–79 Chase 4 80–96 Chase 5 97–113 Chase 6 114–130 Chase 7 131–147 Chase 8 148–164 Chase 9 165–181 Chase 10 182–198 Chase 11 199–215 Chase 12 216–232 Chase 13 233–250 Chase 14 251–255 Sound Show
11	Effect Speed	0	0–254 Slow 255–255 Fast
12	Dimmer	0	0–254 Closed 255–255 Open

13 Channel Mode (continued)

Ch	Function	Default	DMX values
13	Strobe Mode Shutter	0	0–10 Open 11–254 Slow 255–255 Fast