ETEC

ETEC Spot Beam E200



Manufacturer	**ETEC**
Type	**Profile spot**
DMX modes	**1**
DMX footprint	**18 channels**
Beam angle	**9-14°**
Pan range	**540°**
Tilt range	**270°**
Size (W × H × D)	**240 × 450 × 220 mm**
GDTF fixture type	**3D8A1335-DA8A-4B83-B5F5-51…**

Controls

Prism · Zoom · Colour wheel · Effect speed · Strobe · Dimmer · Movement speed · Gobos

Safety-relevant functions

Fixture reset · Strobe

DMX modes

Mode K	18 ch

Mode K

18 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Pan Fine	0	Fine byte of Pan
3	Tilt	128	
4	Tilt Fine	0	Fine byte of Tilt
5	Position MSpeed	0	
6	Dimmer	0	
7	Shutter / Strobe	255	0–4 Closed 5–250 Strobe S-F 251–255 Open
8	Color Wheel	0	0–4 White (wheel slot 1) 5–13 White to Red (wheel slot 2) 14–22 Red (wheel slot 3) 23–31 Red Orange (wheel slot 4) 32–40 Orange (wheel slot 5) 41–49 Orange Green (wheel slot 6) 50–58 Green (wheel slot 7) 59–67 Green Blue (wheel slot 8) 68–76 Blue (wheel slot 9) 77–85 Blue Yellow (wheel slot 10) 86–94 Yellow (wheel slot 11) 95–103 Yellow Cyan (wheel slot 12) 104–112 Cyan (wheel slot 13) 113–121 Cyan L:avender (wheel slot 14) 122–130 Lavender (wheel slot 15) 131–139 Lavender White (wheel slot 16) 140–195 CW Slow to fast (wheel slot 17) 196–199 Stop (wheel slot 18) 200–255 CCW Slow to Fast (wheel slot 19)
9	Gobo	0	0–5 Open (wheel slot 1) 6–14 Wheel Open (wheel slot 2) 15–23 Wheel Slot 1 (wheel slot 3) 24–32 Wheel Slot 2 (wheel slot 4) 33–41 Wheel Slot 3 (wheel slot 5) 42–50 Wheel Slot 4 (wheel slot 6) 51–59 Wheel Slot 5 (wheel slot 7) 60–68 Wheel Slot 6 (wheel slot 8) 69–77 Wheel Slot 7 (wheel slot 9) 78–84 Wheel Shake Offen (wheel slot 10) 85–91 Wheel Shake 1 (wheel slot 11) 92–98 Wheel Shake 2 (wheel slot 12) 99–105 Wheel Shake 3 (wheel slot 13) 106–112 Wheel Shake 4 (wheel slot 14) 113–119 Wheel Shake 5 (wheel slot 15) 120–126 Wheel Shake 6 (wheel slot 16) 127–133 Wheel Shake 7 (wheel slot 17) 134–194 CW Fast to Slow (wheel slot 18) 195–255 CCW Slow to Fast (wheel slot 19)

Mode K (continued)

Ch	Function	Default	DMX values
10	Gobo 2	0	0–7 Open (wheel slot 1) 8–19 Wheel Slot 1 (wheel slot 2) 20–31 Wheel Slot 2 (wheel slot 3) 32–43 Wheel Slot 3 (wheel slot 4) 44–55 Wheel Slot 4 (wheel slot 5) 56–67 Wheel Slot 5 (wheel slot 6) 68–79 Wheel Slot 6 (wheel slot 7) 80–88 Wheel Shake 1 (wheel slot 8) 89–97 Wheel Shake 2 (wheel slot 9) 98–106 Wheel Shake 3 (wheel slot 10) 107–115 Wheel Shake 4 (wheel slot 11) 116–124 Wheel Shake 5 (wheel slot 12) 125–133 Wheel Shake 6 (wheel slot 13) 134–194 CW F-S (wheel slot 14) 195–255 CCW S-F (wheel slot 15)
11	Gobo2Select Spin	0	0–9 Stop 10–129 CW Fsst to Slow 130–134 Stop 135–255 CCW Slow to Fast
12	Playmode	0	0–7 No Function 8–32 AutoPlay 1 33–58 AutoPlay 2 59–84 AutoPlay 3 85–110 AutoPlay 4 111–136 AutoPlay 5 137–162 AutoPlay 6 163–188 AutoPlay 7 189–214 AutoPlay 8 215–240 AutoPlay 9 241–255 Sonud Control
13	Prism	0	0–15 Open 16–255 Prism
14	Prism1Select Spin	0	0–5 Stop 6–129 CW Fast to Slow 130–134 Stop 135–255 CCW Slow to Fast
15	Zoom	0	0–127 Open 14 Degree 128–255 Zoomed 9 Degree
16	No Feature	0	
17	Effect Speed	0	0–7 No Function 8–32 Pan Tilt Auto Run 1 33–58 Pan Tilt Auto Run 2 59–84 Pan Tilt Auto Run 3 85–110 Pan Tilt Auto Run 4 111–136 Pan Tilt Auto Run 5 137–162 Pan Tilt Auto Run 6 163–188 Pan Tilt Auto Run 7 189–214 Pan Tilt Auto Run 8 215–240 Pan Tilt Auto Run 9 241–255 Pan Tile Sound Control
18	Fixture Global Reset	0	0–249 No Function 250–255 Reset