Eurolite

# LED IP PIX Strobe FROST



| | |
|---|---|
| Manufacturer | **Eurolite** |
| Type | **Strobe** |
| DMX modes | **8** |
| DMX footprint | **7, 11, 18, 25, 26, 32, 33, 35 channels** |
| Beam angle | **25°** |
| Heads / cells | **12** |
| Size (W × H × D) | **380 × 117 × 40 mm** |
| GDTF fixture type | **240612E6-84E6-4781-A65C-CF…** |

## Controls

Frost · Extra LED colours · Colour temperature · Colour wheel · Strobe · Dimmer · Pixel control

## Safety-relevant functions

Strobe

## DMX modes

| | |
|---|---|
| 7Ch | 7 ch |
| 11Ch | 11 ch |
| 19Ch | 18 ch |
| 25Ch 1 | 25 ch |
| 26Ch | 26 ch |
| 32Ch | 32 ch |
| 33Ch | 33 ch |
| 35Ch | 35 ch |

## 7Ch

7 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Red | 255 | |
| 2 | Green | 255 | |
| 3 | Blue | 255 | |
| 4 | Color Add WW | 0 | |
| 5 | Color Add CW | 0 | |
| 6 | Shutter / Strobe | 0 | 0–7 open<br>8–255 Shutter1Strobe 2 |
| 7 | Frost1 | 0 | |

## 11Ch

11 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Red | 255 | |
| 2 | Green | 255 | |
| 3 | Blue | 255 | |
| 4 | Color Add WW | 0 | |
| 5 | Color Add CW | 0 | |
| 6 | Shutter / Strobe | 0 | 0–7 open<br>8–255 Shutter1Strobe 2 |
| 7 | Color Macro1 | 0 | 0–7 No function<br>8–47 Program 1<br>48–67 Program 2<br>68–87 Program 3<br>88–107 Program 4<br>108–127 Program 5<br>128–147 Program 6<br>148–167 Program 7<br>168–187 Program 8<br>188–207 Program 9<br>208–227 Program 10<br>228–247 Program 11<br>248–255 Program 12 |
| 8 | Color Macro1Rate | 0 | |

### 11Ch (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **9** | Color Macro2 | 0 | 0–7 No function<br>8–15 Program 1<br>16–23 Program 2<br>24–31 Program 3<br>32–39 Program 4<br>40–47 Program 5<br>48–55 Program 6<br>56–63 Program 7<br>64–71 Program 8<br>72–87 Program 9<br>88–95 Program 10<br>96–103 Program 11<br>104–111 Program 12<br>112–119 Program 13<br>120–127 Program 14<br>128–135 Program 15<br>136–143 Program 16<br>144–151 Program 17<br>152–159 Program 18<br>160–167 Program 19<br>168–175 Program 20<br>176–183 Program 21<br>184–191 Program 22<br>192–199 Program 23<br>200–207 Program 24<br>208–215 Program 25<br>216–223 Program 26<br>224–231 Program 27<br>232–239 Program 28<br>240–247 Program 29<br>248–255 Program 30 |
| **10** | Color Macro2Rate | 0 | |
| **11** | Frost1 | 0 | |

## 19Ch

18 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **1** | Dimmer | 0 | |
| **2** | Red | 255 | |
| **3** | Green | 255 | |
| **4** | Blue | 255 | |
| **5** | Color Add WW | 255 | |
| **6** | Color Add CW | 255 | |
| **7** | C TO | 0 | |
| **8** | Color Macro1 | 0 | 0–7 No function<br>8–47 Program 1<br>48–67 Program 2<br>68–87 Program 3<br>88–107 Program 4<br>108–127 Program 5<br>128–147 Program 6<br>148–167 Program 7<br>168–187 Program 8<br>188–207 Program 9<br>208–227 Program 10<br>228–247 Program 11<br>248–255 Program 12 |

### 19Ch (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **9** | Color Macro1Rate | 0 | |
| **10** | Shutter / Strobe | 0 | 0–7 open<br>8–255 Shutter1Strobe 2 |
| **11** | Shutter / Strobe 2 | 0 | 0–127 open<br>128–139 Shutter2StrobePulseOpen<br>140–209 Shutter2StrobePulseClose 3<br>210–255 Shutter2StrobeRandom 4 |
| **12** | Color Macro2 | 0 | 0–7 No function<br>8–15 Program 1<br>16–23 Program 2<br>24–31 Program 3<br>32–39 Program 4<br>40–47 Program 5<br>48–55 Program 6<br>56–63 Program 7<br>64–71 Program 8<br>72–87 Program 9<br>88–95 Program 10<br>96–103 Program 11<br>104–111 Program 12<br>112–119 Program 13<br>120–127 Program 14<br>128–135 Program 15<br>136–143 Program 16<br>144–151 Program 17<br>152–159 Program 18<br>160–167 Program 19<br>168–175 Program 20<br>176–183 Program 21<br>184–191 Program 22<br>192–199 Program 23<br>200–207 Program 24<br>208–215 Program 25<br>216–223 Program 26<br>224–231 Program 27<br>232–239 Program 28<br>240–247 Program 29<br>248–255 Program 30 |
| **13** | Color Macro2Rate | 0 | |
| **14** | Shutter / Strobe | 0 | 0–7 open<br>8–255 Shutter1Strobe 2 |
| **15** | Red | 0 | |
| **16** | Green | 0 | |
| **17** | Blue | 0 | |
| **18** | Frost1 | 0 | |

## 25Ch 1

25 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **1** | Red | 255 | |
| **2** | Green | 255 | |
| **3** | Blue | 255 | |
| **4** | Color Add WW | 0 | |
| **5** | Color Add CW | 0 | |
| **6** | Red | 255 | |

## 25Ch 1 (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **7** | Green | 255 | |
| **8** | Blue | 255 | |
| **9** | Color Add WW | 0 | |
| **10** | Color Add CW | 0 | |
| **11** | Red | 255 | |
| **12** | Green | 255 | |
| **13** | Blue | 255 | |
| **14** | Color Add WW | 0 | |
| **15** | Color Add CW | 0 | |
| **16** | Red | 255 | |
| **17** | Green | 255 | |
| **18** | Blue | 255 | |
| **19** | Color Add WW | 0 | |
| **20** | Color Add CW | 0 | |
| **21** | Shutter / Strobe | 0 | 0–7 open<br>8–255 Shutter1Strobe 2 |
| **22** | Color Macro1 | 0 | 0–7 No function<br>8–47 Program 1<br>48–67 Program 2<br>68–87 Program 3<br>88–107 Program 4<br>108–127 Program 5<br>128–147 Program 6<br>148–167 Program 7<br>168–187 Program 8<br>188–207 Program 9<br>208–227 Program 10<br>228–247 Program 11<br>248–255 Program 12 |

### 25Ch 1 (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **23** | Color Macro2 | 0 | 0–7 No function<br>8–15 Program 1<br>16–23 Program 2<br>24–31 Program 3<br>32–39 Program 4<br>40–47 Program 5<br>48–55 Program 6<br>56–63 Program 7<br>64–71 Program 8<br>72–87 Program 9<br>88–95 Program 10<br>96–103 Program 11<br>104–111 Program 12<br>112–119 Program 13<br>120–127 Program 14<br>128–135 Program 15<br>136–143 Program 16<br>144–151 Program 17<br>152–159 Program 18<br>160–167 Program 19<br>168–175 Program 20<br>176–183 Program 21<br>184–191 Program 22<br>192–199 Program 23<br>200–207 Program 24<br>208–215 Program 25<br>216–223 Program 26<br>224–231 Program 27<br>232–239 Program 28<br>240–247 Program 29<br>248–255 Program 30 |
| **24** | Color Macro1Rate | 0 | |
| **25** | Frost1 | 0 | |

## 26Ch

26 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **1** | Red | 255 | |
| **2** | Green | 255 | |
| **3** | Blue | 255 | |
| **4** | Color Add WW | 0 | |
| **5** | Color Add CW | 0 | |
| **6** | Red | 255 | |
| **7** | Green | 255 | |
| **8** | Blue | 255 | |
| **9** | Color Add WW | 0 | |
| **10** | Color Add CW | 0 | |
| **11** | Red | 255 | |
| **12** | Green | 255 | |
| **13** | Blue | 255 | |
| **14** | Color Add WW | 0 | |
| **15** | Color Add CW | 0 | |
| **16** | Red | 255 | |
| **17** | Green | 255 | |

### 26Ch (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **18** | Blue | 255 | |
| **19** | Color Add WW | 0 | |
| **20** | Color Add CW | 0 | |
| **21** | Shutter / Strobe | 0 | 0–7 open<br>8–255 Shutter1Strobe 2 |
| **22** | Color Macro1 | 0 | 0–7 No function<br>8–47 Program 1<br>48–67 Program 2<br>68–87 Program 3<br>88–107 Program 4<br>108–127 Program 5<br>128–147 Program 6<br>148–167 Program 7<br>168–187 Program 8<br>188–207 Program 9<br>208–227 Program 10<br>228–247 Program 11<br>248–255 Program 12 |
| **23** | Color Macro1Rate | 0 | |
| **24** | Color Macro2 | 0 | 0–7 No function<br>8–15 Program 1<br>16–23 Program 2<br>24–31 Program 3<br>32–39 Program 4<br>40–47 Program 5<br>48–55 Program 6<br>56–63 Program 7<br>64–71 Program 8<br>72–87 Program 9<br>88–95 Program 10<br>96–103 Program 11<br>104–111 Program 12<br>112–119 Program 13<br>120–127 Program 14<br>128–135 Program 15<br>136–143 Program 16<br>144–151 Program 17<br>152–159 Program 18<br>160–167 Program 19<br>168–175 Program 20<br>176–183 Program 21<br>184–191 Program 22<br>192–199 Program 23<br>200–207 Program 24<br>208–215 Program 25<br>216–223 Program 26<br>224–231 Program 27<br>232–239 Program 28<br>240–247 Program 29<br>248–255 Program 30 |
| **25** | Color Macro2Rate | 0 | |
| **26** | Frost1 | 0 | |

## 32Ch

32 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **1** | Color Add WW | 0 | |
| **2** | Color Add WW | 0 | |

### 32Ch (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 3 | Color Add WW | 0 | |
| 4 | Color Add WW | 0 | |
| 5 | Color Add CW | 0 | |
| 6 | Color Add CW | 0 | |
| 7 | Color Add CW | 0 | |
| 8 | Color Add CW | 0 | |
| 9 | Red | 255 | |
| 10 | Green | 255 | |
| 11 | Blue | 255 | |
| 12 | Red | 255 | |
| 13 | Green | 255 | |
| 14 | Blue | 255 | |
| 15 | Red | 255 | |
| 16 | Green | 255 | |
| 17 | Blue | 255 | |
| 18 | Red | 255 | |
| 19 | Green | 255 | |
| 20 | Blue | 255 | |
| 21 | Red | 255 | |
| 22 | Green | 255 | |
| 23 | Blue | 255 | |
| 24 | Red | 255 | |
| 25 | Green | 255 | |
| 26 | Blue | 255 | |
| 27 | Red | 255 | |
| 28 | Green | 255 | |
| 29 | Blue | 255 | |
| 30 | Red | 255 | |
| 31 | Green | 255 | |
| 32 | Blue | 255 | |

## 33Ch

33 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Color Add WW | 0 | |
| 2 | Color Add WW | 0 | |
| 3 | Color Add WW | 0 | |
| 4 | Color Add WW | 0 | |
| 5 | Color Add CW | 0 | |
| 6 | Color Add CW | 0 | |
| 7 | Color Add CW | 0 | |
| 8 | Color Add CW | 0 | |
| 9 | Red | 255 | |
| 10 | Green | 255 | |
| 11 | Blue | 255 | |

### 33Ch (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 12 | Red | 255 | |
| 13 | Green | 255 | |
| 14 | Blue | 255 | |
| 15 | Red | 255 | |
| 16 | Green | 255 | |
| 17 | Blue | 255 | |
| 18 | Red | 255 | |
| 19 | Green | 255 | |
| 20 | Blue | 255 | |
| 21 | Red | 255 | |
| 22 | Green | 255 | |
| 23 | Blue | 255 | |
| 24 | Red | 255 | |
| 25 | Green | 255 | |
| 26 | Blue | 255 | |
| 27 | Red | 255 | |
| 28 | Green | 255 | |
| 29 | Blue | 255 | |
| 30 | Red | 255 | |
| 31 | Green | 255 | |
| 32 | Blue | 255 | |
| 33 | Frost1 | 0 | |

## 35Ch

35 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Color Add WW | 0 | |
| 2 | Color Add WW | 0 | |
| 3 | Color Add WW | 0 | |
| 4 | Color Add WW | 0 | |
| 5 | Color Add CW | 0 | |
| 6 | Color Add CW | 0 | |
| 7 | Color Add CW | 0 | |
| 8 | Color Add CW | 0 | |
| 9 | Shutter / Strobe | 0 | 0–7 open<br>8–255 Shutter1Strobe 2 |
| 10 | Red | 255 | |
| 11 | Green | 255 | |
| 12 | Blue | 255 | |
| 13 | Red | 255 | |
| 14 | Green | 255 | |
| 15 | Blue | 255 | |
| 16 | Red | 255 | |
| 17 | Green | 255 | |
| 18 | Blue | 255 | |
| 19 | Red | 255 | |

## 35Ch (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **20** | Green | 255 | |
| **21** | Blue | 255 | |
| **22** | Red | 255 | |
| **23** | Green | 255 | |
| **24** | Blue | 255 | |
| **25** | Red | 255 | |
| **26** | Green | 255 | |
| **27** | Blue | 255 | |
| **28** | Red | 255 | |
| **29** | Green | 255 | |
| **30** | Blue | 255 | |
| **31** | Red | 255 | |
| **32** | Green | 255 | |
| **33** | Blue | 255 | |
| **34** | Shutter / Strobe | 0 | 0–7 open<br>8–255 Shutter1Strobe 2 |
| **35** | Frost1 | 0 | |