Eurolite

LED Mega Strobe 768 Bar



Manufacturer	**Eurolite**
Type	**Strobe**
DMX modes	**7**
DMX footprint	**7, 13, 18, 21, 113, 257 channels**
Beam angle	**60°**
Size (W × H × D)	**1000 × 130 × 85 mm**
GDTF fixture type	**F124E286-41E5-4027-B0F2-6D4…**

Controls

Frost · Extra LED colours · RGB colour mixing · Colour wheel · Strobe · Dimmer · Pixel control

DMX modes

7 Channel	7 ch
125 Channel	13 ch
269 Channel	13 ch
18 Channel	18 ch
21 Channel	21 ch
113 Channel	113 ch
257 Channel	257 ch

7 Channel

7 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 closed 255–255 open
2	Shutter / Strobe	0	0–5 Open 6–6 min Strobe 7–249 Strobe3 · Slow > Fast 0.58–19.9 Hz 250–250 max Strobe 251–255 Open
3	Red	255	
4	Green	255	
5	Blue	255	
6	White	0	
7	Frost1	0	0–100 Frost 101–255 No Frost

125 Channel

13 channels

Ch	Function	Default	DMX values
1	Dimmer	255	0–254 closed 255–255 open
2	Strobe Duration	0	
3	Shutter / Strobe	0	0–4 Open 5–5 Min Strobe 6–254 StrobeFrequency 1 · Slow > Fast 0.777–19.9 Hz 255–255 Max Strobe
4	Strobe Mode Effect	0	0–5 Strobe 6–42 Ramp Up 43–85 Ramp Down 86–128 Sin 129–171 Bursts 172–214 Bursts Slow 215–255 Bursts Fast
5	Shutter / Strobe	0	0–5 Open 6–6 min Strobe 7–249 Strobe3 · Slow > Fast 0.58–19.9 Hz 250–250 max Strobe 251–255 Open

125 Channel (continued)

Ch	Function	Default	DMX values
6	Pattern Selection	0	0–4 Open 5–9 FX 1 10–15 FX 2 16–20 FX 3 21–26 FX 4 27–31 FX 5 32–37 FX 6 38–43 FX 7 44–48 FX 8 49–54 FX 9 55–59 FX 10 60–65 FX 11 66–70 FX 12 71–76 FX 13 77–82 FX 14 83–87 FX 15 88–93 FX 16 94–98 FX 17 99–104 FX 18 105–109 FX 19 110–115 FX 20 116–121 FX 21 122–126 FX 22 127–132 FX 23 133–137 FX 24 138–143 FX 25 144–149 FX 26 150–154 FX 27 155–160 FX 28 161–165 FX 29 166–171 FX 30 172–176 FX 31 177–182 FX 32 183–188 FX 33 189–193 FX 34 194–199 FX 35 200–204 FX 36 205–210 FX 37 211–215 FX 38 216–221 FX 39 222–227 FX 40 228–232 FX 41 233–238 FX 42 239–243 FX 43 244–249 FX 44 250–254 FX 45 255–255 FX 46
7	Pattern Rotation	0	0–0 Min 1–254 Slow > Fast 255–255 Max
8	Pattern Selection	0	
9	Pattern Rotation	0	0–0 Min 1–254 Slow > Fast 255–255 Max

125 Channel (continued)

Ch	Function	Default	DMX values
10	Pattern Color1	0	0–9 ColorMix 10–17 Red (wheel slot 2) 18–25 Green (wheel slot 3) 26–33 Blue (wheel slot 4) 34–49 Venon Green (wheel slot 5) 50–65 Magenta (wheel slot 6) 66–81 See Green (wheel slot 7) 82–89 Lavend (wheel slot 8) 90–97 Yellow (wheel slot 9) 98–105 Cyan (wheel slot 10) 106–113 Lavend (wheel slot 11) 114–121 Amber (wheel slot 12) 122–128 Magenta (wheel slot 13) 129–160 FX 1 Slow to Fast (wheel slot 1) 161–192 FX 2 Slow to Fast (wheel slot 1) 193–224 FX 3 Slow to Fast (wheel slot 1) 225–255 FX 4 Slow to Fast (wheel slot 1)
11	Pattern Color2	0	0–9 Black (wheel slot 1) 10–25 Red (wheel slot 2) 26–41 Green (wheel slot 3) 42–57 Blue (wheel slot 4) 58–89 Venon Green (wheel slot 5) 90–121 Magenta (wheel slot 6) 122–153 See Green (wheel slot 7) 154–169 Lavend (wheel slot 8) 170–185 Yellow (wheel slot 9) 186–201 Cyan (wheel slot 10) 202–217 Lavend (wheel slot 11) 218–233 Amber (wheel slot 12) 234–249 Magenta (wheel slot 13) 250–255 Cyan (wheel slot 14)
12	Pattern Direction	0	0–127 Normal 128–255 Inverted
13	Frost1	0	0–100 Frost 101–255 No Frost

269 Channel

13 channels

Ch	Function	Default	DMX values
1	Dimmer	255	0–254 closed 255–255 open
2	Strobe Duration	0	
3	Shutter / Strobe	0	0–4 Open 5–5 Min Strobe 6–254 StrobeFrequency 1 · Slow > Fast 0.777–19.9 Hz 255–255 Max Strobe
4	Strobe Mode Effect	0	0–5 Strobe 6–42 Ramp Up 43–85 Ramp Down 86–128 Sin 129–171 Bursts 172–214 Bursts Slow 215–255 Bursts Fast
5	Shutter / Strobe	0	0–5 Open 6–6 min Strobe 7–249 Strobe3 · Slow > Fast 0.58–19.9 Hz 250–250 max Strobe 251–255 Open

269 Channel (continued)

Ch	Function	Default	DMX values
6	Pattern Selection	0	0–4 Open 5–9 FX 1 10–15 FX 2 16–20 FX 3 21–26 FX 4 27–31 FX 5 32–37 FX 6 38–43 FX 7 44–48 FX 8 49–54 FX 9 55–59 FX 10 60–65 FX 11 66–70 FX 12 71–76 FX 13 77–82 FX 14 83–87 FX 15 88–93 FX 16 94–98 FX 17 99–104 FX 18 105–109 FX 19 110–115 FX 20 116–121 FX 21 122–126 FX 22 127–132 FX 23 133–137 FX 24 138–143 FX 25 144–149 FX 26 150–154 FX 27 155–160 FX 28 161–165 FX 29 166–171 FX 30 172–176 FX 31 177–182 FX 32 183–188 FX 33 189–193 FX 34 194–199 FX 35 200–204 FX 36 205–210 FX 37 211–215 FX 38 216–221 FX 39 222–227 FX 40 228–232 FX 41 233–238 FX 42 239–243 FX 43 244–249 FX 44 250–254 FX 45 255–255 FX 46
7	Pattern Rotation	0	0–0 Min 1–254 Slow > Fast 255–255 Max
8	Pattern Selection	0	
9	Pattern Rotation	0	0–0 Min 1–254 Slow > Fast 255–255 Max

269 Channel (continued)

Ch	Function	Default	DMX values
10	Pattern Color1	0	0–9 ColorMix 10–17 Red (wheel slot 2) 18–25 Green (wheel slot 3) 26–33 Blue (wheel slot 4) 34–49 Venon Green (wheel slot 5) 50–65 Magenta (wheel slot 6) 66–81 See Green (wheel slot 7) 82–89 Lavend (wheel slot 8) 90–97 Yellow (wheel slot 9) 98–105 Cyan (wheel slot 10) 106–113 Lavend (wheel slot 11) 114–121 Amber (wheel slot 12) 122–128 Magenta (wheel slot 13) 129–160 FX 1 Slow to Fast (wheel slot 1) 161–192 FX 2 Slow to Fast (wheel slot 1) 193–224 FX 3 Slow to Fast (wheel slot 1) 225–255 FX 4 Slow to Fast (wheel slot 1)
11	Pattern Color2	0	0–9 Black (wheel slot 1) 10–25 Red (wheel slot 2) 26–41 Green (wheel slot 3) 42–57 Blue (wheel slot 4) 58–89 Venon Green (wheel slot 5) 90–121 Magenta (wheel slot 6) 122–153 See Green (wheel slot 7) 154–169 Lavend (wheel slot 8) 170–185 Yellow (wheel slot 9) 186–201 Cyan (wheel slot 10) 202–217 Lavend (wheel slot 11) 218–233 Amber (wheel slot 12) 234–249 Magenta (wheel slot 13) 250–255 Cyan (wheel slot 14)
12	Pattern Direction	0	0–127 Normal 128–255 Inverted
13	Frost1	0	0–100 Frost 101–255 No Frost

18 Channel

18 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 closed 255–255 open
2	Reserved 2	0	
3	Red	255	
4	Green	255	
5	Blue	255	
6	Dimmer	0	0–254 closed 255–255 open
7	Strobe Duration	0	
8	Shutter / Strobe	0	0–4 Open 5–5 Min Strobe 6–254 StrobeFrequency 1 · Slow > Fast 0.777–19.9 Hz 255–255 Max Strobe

18 Channel (continued)

Ch	Function	Default	DMX values
9	Strobe Mode Effect	0	0–5 Strobe 6–42 Ramp Up 43–85 Ramp Down 86–128 Sin 129–171 Bursts 172–214 Bursts Slow 215–255 Bursts Fast
10	Shutter / Strobe	0	0–5 Open 6–6 min Strobe 7–249 Strobe3 · Slow > Fast 0.58–19.9 Hz 250–250 max Strobe 251–255 Open
11	Pattern Selection	0	0–4 Open 5–9 FX 1 10–15 FX 2 16–20 FX 3 21–26 FX 4 27–31 FX 5 32–37 FX 6 38–43 FX 7 44–48 FX 8 49–54 FX 9 55–59 FX 10 60–65 FX 11 66–70 FX 12 71–76 FX 13 77–82 FX 14 83–87 FX 15 88–93 FX 16 94–98 FX 17 99–104 FX 18 105–109 FX 19 110–115 FX 20 116–121 FX 21 122–126 FX 22 127–132 FX 23 133–137 FX 24 138–143 FX 25 144–149 FX 26 150–154 FX 27 155–160 FX 28 161–165 FX 29 166–171 FX 30 172–176 FX 31 177–182 FX 32 183–188 FX 33 189–193 FX 34 194–199 FX 35 200–204 FX 36 205–210 FX 37 211–215 FX 38 216–221 FX 39 222–227 FX 40 228–232 FX 41 233–238 FX 42 239–243 FX 43 244–249 FX 44 250–254 FX 45 255–255 FX 46
12	Pattern Rotation	0	0–0 Min 1–254 Slow > Fast 255–255 Max

18 Channel (continued)

Ch	Function	Default	DMX values
13	Pattern Selection	0	
14	Pattern Rotation	0	0–0 Min 1–254 Slow > Fast 255–255 Max
15	Pattern Color1	0	0–9 ColorMix 10–17 Red (wheel slot 2) 18–25 Green (wheel slot 3) 26–33 Blue (wheel slot 4) 34–49 Venon Green (wheel slot 5) 50–65 Magenta (wheel slot 6) 66–81 See Green (wheel slot 7) 82–89 Lavend (wheel slot 8) 90–97 Yellow (wheel slot 9) 98–105 Cyan (wheel slot 10) 106–113 Lavend (wheel slot 11) 114–121 Amber (wheel slot 12) 122–128 Magenta (wheel slot 13) 129–160 FX 1 Slow to Fast (wheel slot 1) 161–192 FX 2 Slow to Fast (wheel slot 1) 193–224 FX 3 Slow to Fast (wheel slot 1) 225–255 FX 4 Slow to Fast (wheel slot 1)
16	Pattern Color2	0	0–9 Black (wheel slot 1) 10–25 Red (wheel slot 2) 26–41 Green (wheel slot 3) 42–57 Blue (wheel slot 4) 58–89 Venon Green (wheel slot 5) 90–121 Magenta (wheel slot 6) 122–153 See Green (wheel slot 7) 154–169 Lavend (wheel slot 8) 170–185 Yellow (wheel slot 9) 186–201 Cyan (wheel slot 10) 202–217 Lavend (wheel slot 11) 218–233 Amber (wheel slot 12) 234–249 Magenta (wheel slot 13) 250–255 Cyan (wheel slot 14)
17	Pattern Direction	0	0–127 Normal 128–255 Inverted
18	Frost1	0	0–100 Frost 101–255 No Frost

21 Channel

21 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 closed 255–255 open
2	Dimmer Fine	0	Fine byte of Dimmer
3	Reserved 3	0	
4	Red	255	
5	Green	255	
6	Blue	255	
7	Shutter / Strobe	0	0–5 Open 6–6 min Strobe 7–249 Strobe3 · Slow > Fast 0.58–19.9 Hz 250–250 max Strobe 251–255 Open
8	Pattern Selection	0	

21 Channel (continued)

Ch	Function	Default	DMX values
9	Pattern Rotation	0	0–0 Min 1–254 Slow > Fast 255–255 Max
10	Pattern Color1	0	0–9 ColorMix 10–17 Red (wheel slot 2) 18–25 Green (wheel slot 3) 26–33 Blue (wheel slot 4) 34–49 Venon Green (wheel slot 5) 50–65 Magenta (wheel slot 6) 66–81 See Green (wheel slot 7) 82–89 Lavend (wheel slot 8) 90–97 Yellow (wheel slot 9) 98–105 Cyan (wheel slot 10) 106–113 Lavend (wheel slot 11) 114–121 Amber (wheel slot 12) 122–128 Magenta (wheel slot 13) 129–160 FX 1 Slow to Fast (wheel slot 1) 161–192 FX 2 Slow to Fast (wheel slot 1) 193–224 FX 3 Slow to Fast (wheel slot 1) 225–255 FX 4 Slow to Fast (wheel slot 1)
11	Pattern Color2	0	0–9 Black (wheel slot 1) 10–25 Red (wheel slot 2) 26–41 Green (wheel slot 3) 42–57 Blue (wheel slot 4) 58–89 Venon Green (wheel slot 5) 90–121 Magenta (wheel slot 6) 122–153 See Green (wheel slot 7) 154–169 Lavend (wheel slot 8) 170–185 Yellow (wheel slot 9) 186–201 Cyan (wheel slot 10) 202–217 Lavend (wheel slot 11) 218–233 Amber (wheel slot 12) 234–249 Magenta (wheel slot 13) 250–255 Cyan (wheel slot 14)
12	Pattern Color2Dim	0	0–254 closed 255–255 open
13	Pattern Direction	0	0–127 Normal 128–255 Inverted
14	Dimmer	0	0–254 closed 255–255 open
15	Strobe Duration	0	
16	Shutter / Strobe	0	0–4 Open 5–5 Min Strobe 6–254 StrobeFrequency 1 · Slow > Fast 0.777–19.9 Hz 255–255 Max Strobe
17	Strobe Mode Effect	0	0–5 Strobe 6–42 Ramp Up 43–85 Ramp Down 86–128 Sin 129–171 Bursts 172–214 Bursts Slow 215–255 Bursts Fast

21 Channel (continued)

Ch	Function	Default	DMX values
18	Pattern Selection	0	0–4 Open 5–9 FX 1 10–15 FX 2 16–20 FX 3 21–26 FX 4 27–31 FX 5 32–37 FX 6 38–43 FX 7 44–48 FX 8 49–54 FX 9 55–59 FX 10 60–65 FX 11 66–70 FX 12 71–76 FX 13 77–82 FX 14 83–87 FX 15 88–93 FX 16 94–98 FX 17 99–104 FX 18 105–109 FX 19 110–115 FX 20 116–121 FX 21 122–126 FX 22 127–132 FX 23 133–137 FX 24 138–143 FX 25 144–149 FX 26 150–154 FX 27 155–160 FX 28 161–165 FX 29 166–171 FX 30 172–176 FX 31 177–182 FX 32 183–188 FX 33 189–193 FX 34 194–199 FX 35 200–204 FX 36 205–210 FX 37 211–215 FX 38 216–221 FX 39 222–227 FX 40 228–232 FX 41 233–238 FX 42 239–243 FX 43 244–249 FX 44 250–254 FX 45 255–255 FX 46
19	Pattern Rotation	0	0–0 Min 1–254 Slow > Fast 255–255 Max
20	Pattern Direction	0	0–127 Normal 128–255 Inverted
21	Frost1	0	0–100 Frost 101–255 No Frost

113 Channel

113 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	

113 Channel (continued)

Ch	Function	Default	DMX values
3	Blue	255	
4	Reserved 4	0	
5	Reserved 5	0	
6	Reserved 6	0	
7	Reserved 7	0	
8	Reserved 8	0	
9	Reserved 9	0	
10	Reserved 10	0	
11	Reserved 11	0	
12	Reserved 12	0	
13	Reserved 13	0	
14	Reserved 14	0	
15	Reserved 15	0	
16	Reserved 16	0	
17	Reserved 17	0	
18	Reserved 18	0	
19	Reserved 19	0	
20	Reserved 20	0	
21	Reserved 21	0	
22	Reserved 22	0	
23	Reserved 23	0	
24	Reserved 24	0	
25	Reserved 25	0	
26	Reserved 26	0	
27	Reserved 27	0	
28	Reserved 28	0	
29	Reserved 29	0	
30	Reserved 30	0	
31	Reserved 31	0	
32	Reserved 32	0	
33	Reserved 33	0	
34	Reserved 34	0	
35	Reserved 35	0	
36	Reserved 36	0	
37	Reserved 37	0	
38	Reserved 38	0	
39	Reserved 39	0	
40	Reserved 40	0	
41	Reserved 41	0	
42	Reserved 42	0	
43	Reserved 43	0	
44	Reserved 44	0	
45	Reserved 45	0	
46	Reserved 46	0	
47	Reserved 47	0	

113 Channel (continued)

Ch	Function	Default	DMX values
48	Reserved 48	0	
49	Reserved 49	0	
50	Reserved 50	0	
51	Reserved 51	0	
52	Reserved 52	0	
53	Reserved 53	0	
54	Reserved 54	0	
55	Reserved 55	0	
56	Reserved 56	0	
57	Reserved 57	0	
58	Reserved 58	0	
59	Reserved 59	0	
60	Reserved 60	0	
61	Reserved 61	0	
62	Reserved 62	0	
63	Reserved 63	0	
64	Reserved 64	0	
65	Reserved 65	0	
66	Reserved 66	0	
67	Reserved 67	0	
68	Reserved 68	0	
69	Reserved 69	0	
70	Reserved 70	0	
71	Reserved 71	0	
72	Reserved 72	0	
73	Reserved 73	0	
74	Reserved 74	0	
75	Reserved 75	0	
76	Reserved 76	0	
77	Reserved 77	0	
78	Reserved 78	0	
79	Reserved 79	0	
80	Reserved 80	0	
81	Reserved 81	0	
82	Reserved 82	0	
83	Reserved 83	0	
84	Reserved 84	0	
85	Reserved 85	0	
86	Reserved 86	0	
87	Reserved 87	0	
88	Reserved 88	0	
89	Reserved 89	0	
90	Reserved 90	0	
91	Reserved 91	0	
92	Reserved 92	0	

113 Channel (continued)

Ch	Function	Default	DMX values
93	Reserved 93	0	
94	Reserved 94	0	
95	Reserved 95	0	
96	Reserved 96	0	
97	Reserved 97	0	
98	Reserved 98	0	
99	Reserved 99	0	
100	Reserved 100	0	
101	Reserved 101	0	
102	Reserved 102	0	
103	Reserved 103	0	
104	Reserved 104	0	
105	Reserved 105	0	
106	Reserved 106	0	
107	Reserved 107	0	
108	Reserved 108	0	
109	Reserved 109	0	
110	Reserved 110	0	
111	Reserved 111	0	
112	Reserved 112	0	
113	Frost1	0	

257 Channel

257 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	Reserved 4	0	
5	Reserved 5	0	
6	Reserved 6	0	
7	Reserved 7	0	
8	Reserved 8	0	
9	Reserved 9	0	
10	Reserved 10	0	
11	Reserved 11	0	
12	Reserved 12	0	
13	Reserved 13	0	
14	Reserved 14	0	
15	Reserved 15	0	
16	Reserved 16	0	
17	Reserved 17	0	
18	Reserved 18	0	
19	Reserved 19	0	
20	Reserved 20	0	

257 Channel (continued)

Ch	Function	Default	DMX values
21	Reserved 21	0	
22	Reserved 22	0	
23	Reserved 23	0	
24	Reserved 24	0	
25	Reserved 25	0	
26	Reserved 26	0	
27	Reserved 27	0	
28	Reserved 28	0	
29	Reserved 29	0	
30	Reserved 30	0	
31	Reserved 31	0	
32	Reserved 32	0	
33	Reserved 33	0	
34	Reserved 34	0	
35	Reserved 35	0	
36	Reserved 36	0	
37	Reserved 37	0	
38	Reserved 38	0	
39	Reserved 39	0	
40	Reserved 40	0	
41	Reserved 41	0	
42	Reserved 42	0	
43	Reserved 43	0	
44	Reserved 44	0	
45	Reserved 45	0	
46	Reserved 46	0	
47	Reserved 47	0	
48	Reserved 48	0	
49	Reserved 49	0	
50	Reserved 50	0	
51	Reserved 51	0	
52	Reserved 52	0	
53	Reserved 53	0	
54	Reserved 54	0	
55	Reserved 55	0	
56	Reserved 56	0	
57	Reserved 57	0	
58	Reserved 58	0	
59	Reserved 59	0	
60	Reserved 60	0	
61	Reserved 61	0	
62	Reserved 62	0	
63	Reserved 63	0	
64	Reserved 64	0	
65	Reserved 65	0	

257 Channel (continued)

Ch	Function	Default	DMX values
66	Reserved 66	0	
67	Reserved 67	0	
68	Reserved 68	0	
69	Reserved 69	0	
70	Reserved 70	0	
71	Reserved 71	0	
72	Reserved 72	0	
73	Reserved 73	0	
74	Reserved 74	0	
75	Reserved 75	0	
76	Reserved 76	0	
77	Reserved 77	0	
78	Reserved 78	0	
79	Reserved 79	0	
80	Reserved 80	0	
81	Reserved 81	0	
82	Reserved 82	0	
83	Reserved 83	0	
84	Reserved 84	0	
85	Reserved 85	0	
86	Reserved 86	0	
87	Reserved 87	0	
88	Reserved 88	0	
89	Reserved 89	0	
90	Reserved 90	0	
91	Reserved 91	0	
92	Reserved 92	0	
93	Reserved 93	0	
94	Reserved 94	0	
95	Reserved 95	0	
96	Reserved 96	0	
97	Reserved 97	0	
98	Reserved 98	0	
99	Reserved 99	0	
100	Reserved 100	0	
101	Reserved 101	0	
102	Reserved 102	0	
103	Reserved 103	0	
104	Reserved 104	0	
105	Reserved 105	0	
106	Reserved 106	0	
107	Reserved 107	0	
108	Reserved 108	0	
109	Reserved 109	0	
110	Reserved 110	0	

257 Channel (continued)

Ch	Function	Default	DMX values
111	Reserved 111	0	
112	Reserved 112	0	
113	Reserved 113	0	
114	Reserved 114	0	
115	Reserved 115	0	
116	Reserved 116	0	
117	Reserved 117	0	
118	Reserved 118	0	
119	Reserved 119	0	
120	Reserved 120	0	
121	Reserved 121	0	
122	Reserved 122	0	
123	Reserved 123	0	
124	Reserved 124	0	
125	Reserved 125	0	
126	Reserved 126	0	
127	Reserved 127	0	
128	Reserved 128	0	
129	Reserved 129	0	
130	Reserved 130	0	
131	Reserved 131	0	
132	Reserved 132	0	
133	Reserved 133	0	
134	Reserved 134	0	
135	Reserved 135	0	
136	Reserved 136	0	
137	Reserved 137	0	
138	Reserved 138	0	
139	Reserved 139	0	
140	Reserved 140	0	
141	Reserved 141	0	
142	Reserved 142	0	
143	Reserved 143	0	
144	Reserved 144	0	
145	Reserved 145	0	
146	Reserved 146	0	
147	Reserved 147	0	
148	Reserved 148	0	
149	Reserved 149	0	
150	Reserved 150	0	
151	Reserved 151	0	
152	Reserved 152	0	
153	Reserved 153	0	
154	Reserved 154	0	
155	Reserved 155	0	

257 Channel (continued)

Ch	Function	Default	DMX values
156	Reserved 156	0	
157	Reserved 157	0	
158	Reserved 158	0	
159	Reserved 159	0	
160	Reserved 160	0	
161	Reserved 161	0	
162	Reserved 162	0	
163	Reserved 163	0	
164	Reserved 164	0	
165	Reserved 165	0	
166	Reserved 166	0	
167	Reserved 167	0	
168	Reserved 168	0	
169	Reserved 169	0	
170	Reserved 170	0	
171	Reserved 171	0	
172	Reserved 172	0	
173	Reserved 173	0	
174	Reserved 174	0	
175	Reserved 175	0	
176	Reserved 176	0	
177	Reserved 177	0	
178	Reserved 178	0	
179	Reserved 179	0	
180	Reserved 180	0	
181	Reserved 181	0	
182	Reserved 182	0	
183	Reserved 183	0	
184	Reserved 184	0	
185	Reserved 185	0	
186	Reserved 186	0	
187	Reserved 187	0	
188	Reserved 188	0	
189	Reserved 189	0	
190	Reserved 190	0	
191	Reserved 191	0	
192	Reserved 192	0	
193	Reserved 193	0	
194	Reserved 194	0	
195	Reserved 195	0	
196	Reserved 196	0	
197	Reserved 197	0	
198	Reserved 198	0	
199	Reserved 199	0	
200	Reserved 200	0	

257 Channel (continued)

Ch	Function	Default	DMX values
201	Reserved 201	0	
202	Reserved 202	0	
203	Reserved 203	0	
204	Reserved 204	0	
205	Reserved 205	0	
206	Reserved 206	0	
207	Reserved 207	0	
208	Reserved 208	0	
209	Reserved 209	0	
210	Reserved 210	0	
211	Reserved 211	0	
212	Reserved 212	0	
213	Reserved 213	0	
214	Reserved 214	0	
215	Reserved 215	0	
216	Reserved 216	0	
217	Reserved 217	0	
218	Reserved 218	0	
219	Reserved 219	0	
220	Reserved 220	0	
221	Reserved 221	0	
222	Reserved 222	0	
223	Reserved 223	0	
224	Reserved 224	0	
225	Reserved 225	0	
226	Reserved 226	0	
227	Reserved 227	0	
228	Reserved 228	0	
229	Reserved 229	0	
230	Reserved 230	0	
231	Reserved 231	0	
232	Reserved 232	0	
233	Reserved 233	0	
234	Reserved 234	0	
235	Reserved 235	0	
236	Reserved 236	0	
237	Reserved 237	0	
238	Reserved 238	0	
239	Reserved 239	0	
240	Reserved 240	0	
241	Reserved 241	0	
242	Reserved 242	0	
243	Reserved 243	0	
244	Reserved 244	0	
245	Reserved 245	0	

257 Channel (continued)

Ch	Function	Default	DMX values
246	Reserved 246	0	
247	Reserved 247	0	
248	Reserved 248	0	
249	Reserved 249	0	
250	Reserved 250	0	
251	Reserved 251	0	
252	Reserved 252	0	
253	Reserved 253	0	
254	Reserved 254	0	
255	Reserved 255	0	
256	Reserved 256	0	
257	Frost1	0	