Eurolite

LED Mega Strobe 812 Panel



Manufacturer	**Eurolite**
Type	**Strobe**
DMX modes	**1**
DMX footprint	**21 channels**
Beam angle	**95-123°**
Size (W × H × D)	**407 × 263 × 153 mm**
GDTF fixture type	**8B1408B1-EF3C-4AE4-820A-C8…**

Controls

Extra LED colours · Colour wheel · Effect speed · Dimmer · Pixel control

Safety-relevant functions

Built-in effect programmes

DMX modes

20Ch Mode — 21 ch

20Ch Mode

21 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–0 Min 1–254 Min > Max 255–255 Max
2	Dimmer Fine	0	Fine byte of Dimmer
3	Dimmer	0	
4	Yellow Mode	0	
5	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
6	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
7	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
8	Strobe Rate	0	
9	Color Macro1	0	0–0 Open 1–2 White 2700K - CTC (wheel slot 1) 3–4 White 3200K - CTC (wheel slot 2) 5–6 White 4200K - CTC (wheel slot 3) 7–8 White 5600K - CTC (wheel slot 4) 9–10 White 8000K - CTC (wheel slot 5) 11–11 Blue (wheel slot 6) 12–48 +Green (wheel slot 7) 49–49 Cyan (wheel slot 8) 50–86 -Blue (wheel slot 9) 87–89 Green (wheel slot 10) 90–124 +Red (wheel slot 11) 125–126 Yellow (wheel slot 12) 127–162 -Green (wheel slot 13) 163–163 Red (wheel slot 14) 164–200 +Blue (wheel slot 15) 201–201 Magenta (wheel slot 16) 202–238 -Red (wheel slot 17) 239–239 Blue (wheel slot 6) 240–240 Fast 241–246 Fast > Slow 247–247 Slow 248–248 Fast 249–254 Fast > Slow 255–255 Slow
10	Speed CM1	0	
11	Color Change CH8	0	
12	Background Macros	0	
13	Dimmer2	0	0–0 Min 1–254 Min > Max 255–255 Max
14	Running Direction	0	
15	White	0	
16	Strobe Rate	0	
17	Strobe Duration	0	

20Ch Mode (continued)

Ch	Function	Default	DMX values
18	Effect	0	0–5 Open 6–6 Slow 7–41 Slow > Fast 42–42 Fast 43–43 Slow 44–84 Slow > Fast 85–85 Fast 86–86 Slow 87–127 Slow > Fast 128–128 Fast 129–129 Slow 130–170 Slow > Fast 171–171 Fast 172–172 Slow 173–213 Slow > Fast 214–214 Fast 215–215 Slow 216–254 Slow > Fast 255–255 Fast

20Ch Mode (continued)

Ch	Function	Default	DMX values
19	Effect 2	0	0–2 Open 3–3 Plate Pattern 1 - Effect 4–4 Plate Pattern 2 - Effect 5–5 Plate Pattern 3 - Effect 6–6 Plate Pattern 4 - Effect 7–7 Plate Pattern 5 - Effect 8–8 Plate Pattern 6 - Effect 9–9 Plate Pattern 7 - Effect 10–10 Plate Pattern 8 - Effect 11–11 Plate Pattern 9 - Effect 12–12 Plate Pattern 10 - Effect 13–13 Plate Pattern 11 - Effect 14–14 Plate Pattern 12 - Effect 15–15 Plate Pattern 13 - Effect 16–16 Plate Pattern 14 - Effect 17–17 Plate Pattern 15 - Effect 18–18 Plate Pattern 16 - Effect 19–19 Plate Pattern 17 - Effect 20–20 Plate Pattern 18 - Effect 21–21 Plate Pattern 19 - Effect 22–22 Plate Pattern 20 - Effect 23–23 Plate Pattern 21 - Effect 24–24 Plate Pattern 22 - Effect 25–25 Plate Pattern 23 - Effect 26–26 Plate Pattern 24 - Effect 27–27 Plate Pattern 25 - Effect 28–28 Plate Pattern 26 - Effect 29–29 Plate Pattern 27 - Effect 30–30 Plate Pattern 28 - Effect 31–31 Plate Pattern 29 - Effect 32–32 Plate Pattern 30 - Effect 33–33 Plate Pattern 31 - Effect 34–34 Plate Pattern 32 - Effect 35–35 Plate Pattern 33 - Effect 36–36 Plate Pattern 34 - Effect 37–37 Plate Pattern 35 - Effect 38–38 Plate Pattern 36 - Effect 39–39 Plate Pattern 37 - Effect 40–40 Plate Pattern 38 - Effect 41–41 Plate Pattern 39 - Effect 42–42 Plate Pattern 40 - Effect 43–43 Plate Pattern 41 - Effect 44–44 Plate Pattern 42 - Effect 45–45 Plate Pattern 43 - Effect 46–46 Plate Pattern 44 - Effect 47–47 Plate Pattern 45 - Effect 48–48 Plate Pattern 46 - Effect 49–49 Plate Pattern 47 - Effect 50–50 Plate Pattern 48 - Effect 51–51 Plate Pattern 49 - Effect 52–52 Plate Pattern 50 - Effect 53–53 Plate Pattern 51 - Effect 54–54 Plate Pattern 52 - Effect 55–55 Plate Pattern 53 - Effect 56–56 Plate Pattern 54 - Effect 57–57 Plate Pattern 55 - Effect 58–58 Plate Pattern 56 - Effect 59–59 Plate Pattern 57 - Effect 60–60 Plate Pattern 58 - Effect 61–61 Plate Pattern 59 - Effect 62–62 Plate Pattern 60 - Effect 63–63 Plate Pattern 61 - Effect 64–64 Plate Pattern 62 - Effect 65–65 Plate Pattern 63 - Effect

20Ch Mode (continued)

Ch	Function	Default	DMX values
20	Effect Speed 2	0	0–5 No Function 6–124 Fast > Slow 125–130 Stop 131–249 Slow > Fast 250–255 No Function
21	Effects2Fade	0	0–2 Snap From Pixel > Pixel 3–3 Min 4–254 Min > Max 255–255 Max