Eurolite

LED TMH-S30



Manufacturer	**Eurolite**
Type	**Moving head**
DMX modes	**1**
DMX footprint	**12 channels**
Beam angle	**8°**
Pan range	**540°**
Tilt range	**180°**
Size (W × H × D)	**97 × 150 × 128 mm**
GDTF fixture type	**65E97B76-521C-4842-B0B4-87…**

Controls

Colour wheel · Strobe · Dimmer · Movement speed · Gobos · Gobo rotation

Safety-relevant functions

Fixture reset · Strobe

DMX modes

12 Channel — 12 ch

12 Channel

12 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Pan Fine	0	Fine byte of Pan
3	Tilt	128	
4	Tilt Fine	0	Fine byte of Tilt
5	Position MSpeed	0	0–0 speed max 1–254 speed 255–255 speed min
6	Color Wheel	0	0–4 Open (wheel slot 1) 5–9 Open / Red (wheel slot 1) 10–14 Red (wheel slot 2) 15–19 Red / Green (wheel slot 2) 20–24 Green (wheel slot 3) 25–29 Green / Blue (wheel slot 3) 30–34 Blue (wheel slot 4) 35–39 Blue / Yellow (wheel slot 4) 40–44 Yellow (wheel slot 5) 45–49 Yellow / Cyan (wheel slot 5) 50–54 Cyan (wheel slot 6) 55–59 Cyan / Orange (wheel slot 6) 60–64 Orange (wheel slot 7) 65–69 Orange / Magenta (wheel slot 7) 70–74 Magenta (wheel slot 8) 75–79 Magenta / White (wheel slot 8) 80–80 <<< max 81–166 <<< 167–169 Stop 170–254 >>> 255–255 >>> max
7	Gobo	0	0–9 Open (wheel slot 1) 10–19 Gobo 1 (wheel slot 2) 20–29 Gobo 2 (wheel slot 3) 30–39 Gobo 3 (wheel slot 4) 40–49 Gobo 4 (wheel slot 5) 50–59 Gobo 5 (wheel slot 6) 60–69 Gobo 6 (wheel slot 7) 70–79 Gobo 7 (wheel slot 8) 80–89 Gobo 1 Shake (wheel slot 2) 90–99 Gobo 2 Shake (wheel slot 3) 100–109 Gobo 3 Shake (wheel slot 4) 110–119 Gobo 4 Shake (wheel slot 5) 120–129 Gobo 5 Shake (wheel slot 6) 130–139 Gobo 6 Shake (wheel slot 7) 140–149 Gobo 7 Shake (wheel slot 8) 150–150 <<< max 151–201 <<< 202–202 <<< min 203–203 >>> min 204–254 >>> 255–255 >>> max
8	Gobo Rotation	0	0–4 >>> Stop 5–5 >>> min 6–125 >>> 126–126 >>> max 127–129 <<< Stop 130–130 <<< min 131–254 <<< 255–255 <<< max

12 Channel (continued)

Ch	Function	Default	DMX values
9	Shutter / Strobe	0	0–9 open 10–10 strobe min 11–248 strobe 249–249 strobe max 250–255 open
10	Dimmer	0	0–254 Closed 255–255 Open
11	Control1	0	0–59 No function 60–159 Internal program 160–255 Sound program
12	Control2	0	0–20 No function 21–100 PAN movement 101–200 TILT movement 201–249 PAN/TILT movement 250–255 Reset