Fine Art

FINE 380 BSW



Manufacturer	**Fine Art**
Type	**Moving head**
DMX modes	**3**
DMX footprint	**20, 24, 27 channels**
Beam angle	**25°**
Pan range	**540°**
Tilt range	**252°**
Size (W × H × D)	**211 × 360 × 220 mm**
GDTF fixture type	**88CD3BF0-AD40-4549-87F6-0A…**

Controls

Focus · Frost · Prism · Prism rotation · Zoom · Colour wheel · Strobe · Dimmer · Pan and tilt · Movement speed · Gobos · Gobo rotation

Safety-relevant functions

Lamp on and off · Fixture reset

DMX modes

STND	20 ch
16BT	24 ch
EXTN	27 ch

STND

20 channels

Ch	Function	Default	DMX values
1	Color Wheel	0	0–9 Open (wheel slot 1) 10–20 pink (wheel slot 2) 21–31 Dark Blue (wheel slot 3) 32–41 Yellow (wheel slot 4) 42–52 Magenta (wheel slot 5) 53–64 red (wheel slot 6) 65–75 Light Green (wheel slot 7) 76–86 amber (wheel slot 8) 87–97 bule (wheel slot 9) 98–109 Orange (wheel slot 10) 110–119 cto (wheel slot 11) 120–127 uv (wheel slot 12) 128–190 CW 191–192 Stop 193–255 CCW
2	Shutter / Strobe	104	0–3 Closed 4–102 Strobe · min 1–7.93 Hz 103–103 Strobe · Max 8 Hz 104–107 Open1 108–206 Shutter1StrobePulse · min 1–7.93 Hz 207–207 Shutter1StrobePulse · max 8 Hz 208–212 Open2 213–250 StrobeRandom · Slow 1–7.82 Hz 251–251 StrobeRandom · Fast 8 Hz 252–255 Open3
3	Dimmer	0	0–254 Closed 255–255 Open
4	Dimmer Fine	0	Fine byte of Dimmer
5	Gobo	0	0–10 Open (wheel slot 1) 11–15 Gobo1 (wheel slot 2) 16–20 Gobo2 (wheel slot 3) 21–25 Gobo3 (wheel slot 4) 26–30 Gobo4 (wheel slot 5) 31–36 Gobo5 (wheel slot 6) 37–41 Gobo6 (wheel slot 7) 42–46 Gobo7 (wheel slot 8) 47–51 Gobo8 (wheel slot 9) 52–56 Gobo9 (wheel slot 10) 57–61 Gobo10 (wheel slot 11) 62–66 Gobo11 (wheel slot 12) 67–71 Wheel Slot 13 (wheel slot 13) 72–72 max CW 73–115 CW 116–158 CCW 159–159 max CCW 160–166 Gobo2 (wheel slot 3) 167–172 Gobo3 (wheel slot 4) 173–179 Gobo4 (wheel slot 5) 180–185 Gobo5 (wheel slot 6) 186–191 Gobo6 (wheel slot 7) 192–198 Gobo7 (wheel slot 8) 199–204 Gobo8 (wheel slot 9) 205–211 Gobo9 (wheel slot 10) 212–217 Gobo10 (wheel slot 11) 218–223 Gobo11 (wheel slot 12) 224–230 Gobo12 (wheel slot 13) 231–236 Gobo13 (wheel slot 14) 237–243 Gobo14 (wheel slot 15) 244–249 Gobo15 (wheel slot 16) 250–255 Gobo16 (wheel slot 17)

STND (continued)

Ch	Function	Default	DMX values
6	Gobo 2	0	0–7 Open (wheel slot 1) 8–15 Gobo1 (wheel slot 2) 16–23 Gobo2 (wheel slot 3) 24–31 Gobo3 (wheel slot 4) 32–39 Gobo4 (wheel slot 5) 40–47 Gobo5 (wheel slot 6) 48–55 Gobo6 (wheel slot 7) 56–63 Gobo7 (wheel slot 8) 64–71 Gobo8 (wheel slot 9) 72–72 max CW 73–115 CW 116–158 CCW 159–159 max CCW 160–166 Gobo2 (wheel slot 3) 167–172 Gobo3 (wheel slot 4) 173–179 Gobo4 (wheel slot 5) 180–185 Gobo5 (wheel slot 6) 186–191 Gobo6 (wheel slot 7) 192–198 Gobo7 (wheel slot 8) 199–204 Gobo8 (wheel slot 9) 205–211 Gobo9 (wheel slot 10) 212–217 Gobo10 (wheel slot 11) 218–223 Gobo11 (wheel slot 12) 224–230 Gobo12 (wheel slot 13) 231–236 Gobo13 (wheel slot 14) 237–243 Gobo14 (wheel slot 15) 244–249 Gobo15 (wheel slot 16) 250–255 Gobo16 (wheel slot 17)
7	Gobo Rotation	0	
8	Prism	0	0–127 White (wheel slot 1) 128–255 6 color prism (wheel slot 2)
9	Prism	0	0–127 Open (wheel slot 1) 128–255 prism (wheel slot 3)
10	Prism Rotation	0	0–127 0-540 128–190 CW 191–192 Stop 193–255 CCW
11	Frost1	0	
12	Focus	0	0–127 Far 128–255 Near
13	Zoom	0	
14	Pan	128	
15	Pan Fine	0	Fine byte of Pan
16	Tilt	128	
17	Tilt Fine	0	Fine byte of Tilt
18	Function	0	0–127 SPOT/WASH mode 128–255 BEAM MODE
19	Fixture Global Reset	0	0–25 unseless 26–76 Effects Reset 77–127 Pan/Tilt Reset 128–255 Complete Reset
20	Lamp Control	0	0–25 Unused Range 26–100 Lamp off 101–179 Half 180–255 Lamp On

16BT

24 channels

Ch	Function	Default	DMX values
1	Color Wheel	0	0–9 Open (wheel slot 1) 10–20 pink (wheel slot 2) 21–31 Dark Blue (wheel slot 3) 32–41 Yellow (wheel slot 4) 42–52 Magenta (wheel slot 5) 53–64 red (wheel slot 6) 65–75 Light Green (wheel slot 7) 76–86 amber (wheel slot 8) 87–97 bule (wheel slot 9) 98–109 Orange (wheel slot 10) 110–119 cto (wheel slot 11) 120–127 uv (wheel slot 12) 128–190 CW 191–192 Stop 193–255 CCW
2	Shutter / Strobe	104	0–3 Closed 4–102 Strobe · min 1–7.93 Hz 103–103 Strobe · Max 8 Hz 104–107 Open1 108–206 Shutter1StrobePulse · min 1–7.93 Hz 207–207 Shutter1StrobePulse · max 8 Hz 208–212 Open2 213–250 StrobeRandom · Slow 1–7.82 Hz 251–251 StrobeRandom · Fast 8 Hz 252–255 Open3
3	Dimmer	0	0–254 Closed 255–255 Open
4	Dimmer Fine	0	Fine byte of Dimmer
5	Gobo	0	0–10 Open (wheel slot 1) 11–15 Gobo1 (wheel slot 2) 16–20 Gobo2 (wheel slot 3) 21–25 Gobo3 (wheel slot 4) 26–30 Gobo4 (wheel slot 5) 31–36 Gobo5 (wheel slot 6) 37–41 Gobo6 (wheel slot 7) 42–46 Gobo7 (wheel slot 8) 47–51 Gobo8 (wheel slot 9) 52–56 Gobo9 (wheel slot 10) 57–61 Gobo10 (wheel slot 11) 62–66 Gobo11 (wheel slot 12) 67–71 Wheel Slot 13 (wheel slot 13) 72–72 max CW 73–115 CW 116–158 CCW 159–159 max CCW 160–166 Gobo2 (wheel slot 3) 167–172 Gobo3 (wheel slot 4) 173–179 Gobo4 (wheel slot 5) 180–185 Gobo5 (wheel slot 6) 186–191 Gobo6 (wheel slot 7) 192–198 Gobo7 (wheel slot 8) 199–204 Gobo8 (wheel slot 9) 205–211 Gobo9 (wheel slot 10) 212–217 Gobo10 (wheel slot 11) 218–223 Gobo11 (wheel slot 12) 224–230 Gobo12 (wheel slot 13) 231–236 Gobo13 (wheel slot 14) 237–243 Gobo14 (wheel slot 15) 244–249 Gobo15 (wheel slot 16) 250–255 Gobo16 (wheel slot 17)

16BT (continued)

Ch	Function	Default	DMX values
6	Gobo 2	0	0–7 Open (wheel slot 1) 8–15 Gobo1 (wheel slot 2) 16–23 Gobo2 (wheel slot 3) 24–31 Gobo3 (wheel slot 4) 32–39 Gobo4 (wheel slot 5) 40–47 Gobo5 (wheel slot 6) 48–55 Gobo6 (wheel slot 7) 56–63 Gobo7 (wheel slot 8) 64–71 Gobo8 (wheel slot 9) 72–72 max CW 73–115 CW 116–158 CCW 159–159 max CCW 160–166 Gobo2 (wheel slot 3) 167–172 Gobo3 (wheel slot 4) 173–179 Gobo4 (wheel slot 5) 180–185 Gobo5 (wheel slot 6) 186–191 Gobo6 (wheel slot 7) 192–198 Gobo7 (wheel slot 8) 199–204 Gobo8 (wheel slot 9) 205–211 Gobo9 (wheel slot 10) 212–217 Gobo10 (wheel slot 11) 218–223 Gobo11 (wheel slot 12) 224–230 Gobo12 (wheel slot 13) 231–236 Gobo13 (wheel slot 14) 237–243 Gobo14 (wheel slot 15) 244–249 Gobo15 (wheel slot 16) 250–255 Gobo16 (wheel slot 17)
7	Gobo Rotation	0	
8	Prism	0	0–127 White (wheel slot 1) 128–255 6 color prism (wheel slot 2)
9	Prism	0	0–127 Open (wheel slot 1) 128–255 prism (wheel slot 3)
10	Prism Rotation	0	0–127 0-540 128–190 CW 191–192 Stop 193–255 CCW
11	Frost1	0	
12	Focus	0	0–127 Far 128–255 Near
13	Zoom	0	
14	Pan	128	
15	Pan Fine	128	Fine byte of Pan
16	Tilt	128	
17	Tilt Fine	128	Fine byte of Tilt
18	Function	0	0–127 SPOT/WASH mode 128–255 BEAM MODE
19	Fixture Global Reset	0	0–25 unseless 26–76 Effects Reset 77–127 Pan/Tilt Reset 128–255 Complete Reset
20	Lamp Control	0	0–25 Unused Range 26–100 Lamp off 101–179 Half 180–255 Lamp On
21	Position MSpeed	0	
22	Color Wheel Select MSpeed	0	

16BT (continued)

Ch	Function	Default	DMX values
23	Focus MSpeed	0	
24	Global MSpeed	0	

EXTN

27 channels

Ch	Function	Default	DMX values
1	Color Wheel	0	0–9 Open (wheel slot 1) 10–20 pink (wheel slot 2) 21–31 Dark Blue (wheel slot 3) 32–41 Yellow (wheel slot 4) 42–52 Magenta (wheel slot 5) 53–64 red (wheel slot 6) 65–75 Light Green (wheel slot 7) 76–86 amber (wheel slot 8) 87–97 bule (wheel slot 9) 98–109 Orange (wheel slot 10) 110–119 cto (wheel slot 11) 120–127 uv (wheel slot 12) 128–190 CW 191–192 Stop 193–255 CCW
2	Shutter / Strobe	104	0–3 Closed 4–102 Strobe · min 1–7.93 Hz 103–103 Strobe · Max 8 Hz 104–107 Open1 108–206 Shutter1StrobePulse · min 1–7.93 Hz 207–207 Shutter1StrobePulse · max 8 Hz 208–212 Open2 213–250 StrobeRandom · Slow 1–7.82 Hz 251–251 StrobeRandom · Fast 8 Hz 252–255 Open3
3	Dimmer	0	0–254 Closed 255–255 Open
4	Dimmer Fine	0	Fine byte of Dimmer

EXTN (continued)

Ch	Function	Default	DMX values
5	Gobo	0	0–10 Open (wheel slot 1) 11–15 Gobo1 (wheel slot 2) 16–20 Gobo2 (wheel slot 3) 21–25 Gobo3 (wheel slot 4) 26–30 Gobo4 (wheel slot 5) 31–36 Gobo5 (wheel slot 6) 37–41 Gobo6 (wheel slot 7) 42–46 Gobo7 (wheel slot 8) 47–51 Gobo8 (wheel slot 9) 52–56 Gobo9 (wheel slot 10) 57–61 Gobo10 (wheel slot 11) 62–66 Gobo11 (wheel slot 12) 67–71 Wheel Slot 13 (wheel slot 13) 72–72 max CW 73–115 CW 116–158 CCW 159–159 max CCW 160–166 Gobo2 (wheel slot 3) 167–172 Gobo3 (wheel slot 4) 173–179 Gobo4 (wheel slot 5) 180–185 Gobo5 (wheel slot 6) 186–191 Gobo6 (wheel slot 7) 192–198 Gobo7 (wheel slot 8) 199–204 Gobo8 (wheel slot 9) 205–211 Gobo9 (wheel slot 10) 212–217 Gobo10 (wheel slot 11) 218–223 Gobo11 (wheel slot 12) 224–230 Gobo12 (wheel slot 13) 231–236 Gobo13 (wheel slot 14) 237–243 Gobo14 (wheel slot 15) 244–249 Gobo15 (wheel slot 16) 250–255 Gobo16 (wheel slot 17)
6	Gobo 2	0	0–7 Open (wheel slot 1) 8–15 Gobo1 (wheel slot 2) 16–23 Gobo2 (wheel slot 3) 24–31 Gobo3 (wheel slot 4) 32–39 Gobo4 (wheel slot 5) 40–47 Gobo5 (wheel slot 6) 48–55 Gobo6 (wheel slot 7) 56–63 Gobo7 (wheel slot 8) 64–71 Gobo8 (wheel slot 9) 72–72 max CW 73–115 CW 116–158 CCW 159–159 max CCW 160–166 Gobo2 (wheel slot 3) 167–172 Gobo3 (wheel slot 4) 173–179 Gobo4 (wheel slot 5) 180–185 Gobo5 (wheel slot 6) 186–191 Gobo6 (wheel slot 7) 192–198 Gobo7 (wheel slot 8) 199–204 Gobo8 (wheel slot 9) 205–211 Gobo9 (wheel slot 10) 212–217 Gobo10 (wheel slot 11) 218–223 Gobo11 (wheel slot 12) 224–230 Gobo12 (wheel slot 13) 231–236 Gobo13 (wheel slot 14) 237–243 Gobo14 (wheel slot 15) 244–249 Gobo15 (wheel slot 16) 250–255 Gobo16 (wheel slot 17)
7	Gobo Rotation	0	

EXTN (continued)

Ch	Function	Default	DMX values
8	Prism	0	0–127 White (wheel slot 1) 128–255 6 color prism (wheel slot 2)
9	Prism	0	0–127 Open (wheel slot 1) 128–255 prism (wheel slot 3)
10	Prism Rotation	0	0–127 0-540 128–190 CW 191–192 Stop 193–255 CCW
11	Frost1	0	
12	Frost1 Fine	0	Fine byte of Frost1
13	Focus	0	0–127 Far 128–255 Near
14	Focus Fine	0	Fine byte of Focus
15	Zoom	0	
16	Zoom Fine	0	Fine byte of Zoom
17	Pan	128	
18	Pan Fine	0	Fine byte of Pan
19	Tilt	128	
20	Tilt Fine	0	Fine byte of Tilt
21	Function	0	0–127 SPOT/WASH mode 128–255 BEAM MODE
22	Fixture Global Reset	0	0–25 unseless 26–76 Effects Reset 77–127 Pan/Tilt Reset 128–255 Complete Reset
23	Lamp Control	0	0–25 Unused Range 26–100 Lamp off 101–179 Half 180–255 Lamp On
24	Position MSpeed	0	
25	Color Wheel Select MSpeed	0	
26	Focus MSpeed	0	
27	Global MSpeed	0	