Flash

LED MOVING HEAD 200W 3in1



Manufacturer	**Flash**
Type	**Moving head**
DMX modes	**1**
DMX footprint	**18 channels**
Beam angle	**25°**
Pan range	**540°**
Tilt range	**220°**
Size (W × H × D)	**240 × 450 × 220 mm**
GDTF fixture type	**ACA5C434-8028-4572-AAF6-F5…**

Controls

Focus · Frost · Prism · Prism rotation · Zoom · Colour wheel · Strobe · Dimmer · Movement speed · Gobos · Gobo rotation

Safety-relevant functions

Fixture reset · Strobe

DMX modes

18 ch

18 ch

18 ch

18 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Pan Fine	0	Fine byte of Pan
3	Tilt	128	
4	Tilt Fine	0	Fine byte of Tilt
5	Position MSpeed	0	0–254 Fast P/T 255–255 Slow P/T
6	Dimmer	0	0–254 Closed 255–255 Open
7	Shutter / Strobe	255	0–3 Open 4–99 Strobe 100–149 Strobe pulse 150–199 Strobe ramp in 200–249 Strobe Random 250–255 Open 1
8	Color Wheel	0	0–9 Open (wheel slot 1) 10–19 Red (wheel slot 2) 20–29 Yellow (wheel slot 3) 30–39 Blue (wheel slot 4) 40–49 Green (wheel slot 5) 50–59 Orange (wheel slot 6) 60–69 Cyan (wheel slot 7) 70–79 Pink (wheel slot 8) 80–100 Magenta (wheel slot 9) 101–199 Color1 2 200–254 << 255–255 >>>
9	Gobo	0	0–4 Open (wheel slot 1) 5–9 Gobo 1 (wheel slot 2) 10–14 Gobo 2 (wheel slot 3) 15–19 Gobo 3 (wheel slot 4) 20–24 Gobo 4 (wheel slot 5) 25–29 Gobo 5 (wheel slot 6) 30–34 Gobo 6 (wheel slot 7) 35–39 Gobo 7 (wheel slot 8) 40–44 Gobo 8 (wheel slot 9) 45–49 Gobo 9 (wheel slot 10) 50–54 Gobo 10 (wheel slot 11) 55–64 Gobo 1 (wheel slot 2) 65–74 Gobo 2 (wheel slot 3) 75–84 Gobo 3 (wheel slot 4) 85–94 Gobo 4 (wheel slot 5) 95–104 Gobo 5 (wheel slot 6) 105–114 Gobo 6 (wheel slot 7) 115–124 Gobo 7 (wheel slot 8) 125–134 Gobo 8 (wheel slot 9) 135–144 Gobo 9 (wheel slot 10) 145–154 Gobo 10 (wheel slot 11) 155–202 <<< 203–254 >< 255–255 >>>

18 ch (continued)

Ch	Function	Default	DMX values
10	Gobo 2	0	0–9 Open (wheel slot 1) 10–19 Gobo 1 (wheel slot 2) 20–29 Gobo 2 (wheel slot 3) 30–39 Gobo 3 (wheel slot 4) 40–49 Gobo 4 (wheel slot 5) 50–59 Gobo 5 (wheel slot 6) 60–69 Gobo 6 (wheel slot 7) 70–79 Gobo 7 (wheel slot 8) 80–89 Open (wheel slot 1) 90–99 Gobo 1 (wheel slot 2) 100–109 Gobo 2 (wheel slot 3) 110–119 Gobo 3 (wheel slot 4) 120–129 Gobo 4 (wheel slot 5) 130–139 Gobo 5 (wheel slot 6) 140–149 Gobo 6 (wheel slot 7) 150–159 Gobo 7 (wheel slot 8) 160–205 << 206–254 > 255–255 >>>
11	Gobo Rotation 2	0	0–127 Gobo2Pos 1 128–191 < 192–194 << 195–254 >>> 255–255 >
12	Prism	0	0–127 No prism 128–255 Prism
13	Prism Rotation	0	0–127 Prism1Pos 1 128–191 < 192–194 << 195–254 >>> 255–255 >
14	Frost1	0	0–127 No frost 128–255 Frost
15	Zoom	128	0–254 Narrow 255–255 Wide
16	Focus	128	
17	Control2	0	0–50 No function 51–100 System 101–150 Auto 1 151–200 Auto 2 201–255 Sound control
18	Control1	0	0–250 No function 251–255 Reset