Flash

# LED Moving Head 200W 3in1 - BEAM-SPOT-WASH



| | |
|---|---|
| Manufacturer | **Flash** |
| Type | **Moving head** |
| DMX modes | **1** |
| DMX footprint | **18 channels** |
| Beam angle | **7-21°** |
| Pan range | **540°** |
| Tilt range | **220°** |
| Size (W × H × D) | **240 × 450 × 220 mm** |
| GDTF fixture type | **3AECD892-27CE-41AB-94DC-3…** |

## Controls

Focus · Frost · Prism · Prism rotation · Zoom · Colour wheel · Dimmer · Movement speed · Gobos · Gobo rotation

## Safety-relevant functions

Fixture reset

## DMX modes

18ch 18 ch

## 18ch

18 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Pan | 128 | |
| 2 | Pan Fine | 0 | Fine byte of Pan |
| 3 | Tilt | 128 | |
| 4 | Tilt Fine | 0 | Fine byte of Tilt |
| 5 | Position MSpeed | 0 | |
| 6 | Dimmer | 0 | 0–254 Closed<br>255–255 Open |
| 7 | Shutter / Strobe | 0 | 0–3 Open<br>4–99 Shutter1Strobe 2<br>100–149 Shutter1StrobePulseClose 3<br>150–199 Shutter1StrobePulseOpen 4<br>200–249 Shutter1StrobeRandom 5<br>250–255 Shutter1 6 |
| 8 | Color Wheel | 0 | 0–9 Open (wheel slot 1)<br>10–19 Red (wheel slot 2)<br>20–29 Yellow (wheel slot 3)<br>30–39 Blue (wheel slot 4)<br>40–49 Green (wheel slot 5)<br>50–59 Orange (wheel slot 6)<br>60–69 Cyan (wheel slot 7)<br>70–79 Pink (wheel slot 8)<br>80–99 Magenta (wheel slot 9)<br>100–199 Color1WheelIndex 2<br>200–229 spin <<br>230–255 spin > |
| 9 | Gobo | 0 | 0–4 Open (wheel slot 1)<br>5–9 Gobo 1 (wheel slot 2)<br>10–14 Gobo 2 (wheel slot 3)<br>15–19 Gobo 3 (wheel slot 4)<br>20–24 Gobo 4 (wheel slot 5)<br>25–29 Gobo 5 (wheel slot 6)<br>30–34 Gobo 6 (wheel slot 7)<br>35–39 Gobo 7 (wheel slot 8)<br>40–44 Gobo 8 (wheel slot 9)<br>45–49 Gobo 9 (wheel slot 10)<br>50–54 Gobo 10 (wheel slot 11)<br>55–154 Gobo1WheelShake 2<br>155–202 spin <<br>203–206 spin ><<br>207–255 spin > |
| 10 | Gobo 2 | 0 | 0–9 Open (wheel slot 1)<br>10–19 Gobo 1 (wheel slot 2)<br>20–29 Gobo 2 (wheel slot 3)<br>30–39 Gobo 3 (wheel slot 4)<br>40–49 Gobo 4 (wheel slot 5)<br>50–59 Gobo 5 (wheel slot 6)<br>60–69 Gobo 6 (wheel slot 7)<br>70–79 Gobo 7 (wheel slot 8)<br>80–159 Gobo2WheelIndex 2<br>160–205 spin <<br>206–210 spin ><<br>211–255 spin > |
| 11 | Gobo Rotation 2 | 0 | 0–127 Gobo2Pos 1<br>128–192 rot <<br>193–255 rot > |
| 12 | Prism | 0 | 0–127 Open (wheel slot 1)<br>128–255 Prism (wheel slot 2) |

## 18ch (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **13** | Prism Rotation | 0 | 0–127 Prism1Pos 1<br>128–193 rot <<br>194–255 rot > |
| **14** | Frost1 | 0 | 0–127 Open<br>128–255 Frost |
| **15** | Focus | 128 | |
| **16** | Zoom | 128 | |
| **17** | Control1 | 0 | 0–50 No function<br>51–100 System<br>101–150 Auto 1<br>151–200 Auto 2<br>201–255 Sound control |
| **18** | Control2 | 0 | 0–250 No function<br>251–255 Reset |