Flash

MH-BEAM LED 1915 ZOOM v2203



Manufacturer	**Flash**
Type	**Moving head**
DMX modes	**2**
DMX footprint	**16, 24 channels**
Beam angle	**8-63°**
Pan range	**450°**
Tilt range	**300°**
Heads / cells	**3**
Size (W × H × D)	**274 × 161 × 273 mm**
GDTF fixture type	**F4DEC1A8-6186-495B-AF8B-17…**

Controls

Zoom · Extra LED colours · RGB colour mixing · Colour wheel · Strobe · Dimmer · Pixel control · Pan and tilt · Movement speed

Safety-relevant functions

Fixture reset

DMX modes

16ch	16 ch
24ch	24 ch

16ch

16 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Tilt	128	
3	Position MSpeed	0	0–0 Standard mode 1–1 Max speed time 2–255 Speed/Time max to min
4	Dimmer	0	0–254 Closed (wheel slot -2147483648) 255–255 Open (wheel slot -2147483648)
5	Red	255	
6	Green	255	
7	Blue	255	
8	White	255	
9	Shutter / Strobe	255	0–31 Shutter closed 32–59 StrobeZone 3 · Slow to fast - Slow 0.303–17.6 Hz 60–63 StrobeZone 3 · Slow to fast - Fast 18.3–20.2 Hz 64–91 StrobeAllZones 1 · Slow to fast - Slow 0.303–17.6 Hz 92–95 StrobeAllZones 1 · Slow to fast - Fast 18.3–20.2 Hz 96–111 StrobeEffects · Zone + Rainbow effects slow to fast ... 112–127 StrobeEffects · Zone + Rainbow effects fast to slow... 128–140 Shutter1StrobePulseOpen · Slow to fast - Slow 0.1... 141–143 Shutter1StrobePulseOpen · Slow to fast - Fast 0.45... 144–155 Shutter1StrobePulseClose · Fast to slow - Slow 0.5... 156–159 Shutter1StrobePulseClose · Fast to slow - Fast 0.20... 160–175 Random zone effect slow to fast 176–191 Random zone + strobe effect slow to fast 192–223 Random strobe slow to fast (all zones) 224–239 Random strobe slow to fast (random LEDs) 240–255 Shutter open
10	Zoom	128	0–254 narrow 255–255 wide
11	Color Macro1	0	
12	Color Macro1Rate	0	
13	Pan Fine	128	Fine byte of Pan
14	Tilt Fine	128	Fine byte of Tilt
15	Control1	0	0–250 No function 251–255 Total reset
16	Dummy	0	

24ch

24 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Tilt	128	
3	Position MSpeed	0	0–0 Standard mode 1–254 Max speed time 255–255 Min speed time
4	Dimmer	0	0–254 Closed 255–255 Open
5	Red	255	
6	Green	255	
7	Blue	255	
8	White	255	
9	Red	255	

24ch (continued)

Ch	Function	Default	DMX values
10	Green	255	
11	Blue	255	
12	White	255	
13	Red	255	
14	Green	255	
15	Blue	255	
16	White	255	
17	Shutter / Strobe	255	0–31 Shutter closed 32–59 StrobeZone 3 · Slow to fast - Slow 0.303–17.6 Hz 60–63 StrobeZone 3 · Slow to fast - Fast 18.3–20.2 Hz 64–91 StrobeAllZones 1 · Slow to fast - Slow 0.303–17.6 Hz 92–95 StrobeAllZones 1 · Slow to fast - Fast 18.3–20.2 Hz 96–111 StrobeEffects · Zone + Rainbow effects slow to fast ... 112–127 StrobeEffects · Zone + Rainbow effects fast to slow... 128–140 Shutter1StrobePulseOpen · Slow to fast - Slow 0.1... 141–143 Shutter1StrobePulseOpen · Slow to fast - Fast 0.45... 144–155 Shutter1StrobePulseClose · Fast to slow - Slow 0.5... 156–159 Shutter1StrobePulseClose · Fast to slow - Fast 0.20... 160–175 Random zone effect slow to fast 176–191 Random zone + strobe effect slow to fast 192–223 Random strobe slow to fast (all zones) 224–239 Random strobe slow to fast (random LEDs) 240–255 Shutter open
18	Zoom	128	0–254 narrow 255–255 wide
19	Color Macro1	0	
20	Color Macro1Rate	0	
21	Pan Fine	0	Fine byte of Pan
22	Tilt Fine	0	Fine byte of Tilt
23	Control1	0	0–250 No function 251–255 Total reset
24	Dummy	0	