Flash

MH-SPOT LED 200 3W1



Manufacturer	**Flash**
Type	**Moving head**
DMX modes	**1**
DMX footprint	**18 channels**
Beam angle	**7-21°**
Pan range	**540°**
Tilt range	**220°**
Size (W × H × D)	**240 × 450 × 220 mm**
GDTF fixture type	**4EDF1052-99CF-44DA-9561-0B…**

Controls

Focus · Frost · Prism · Prism rotation · Zoom · Colour wheel · Dimmer · Movement speed · Gobos · Gobo rotation

Safety-relevant functions

Fixture reset

DMX modes

18ch 18 ch

18ch

18 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Pan Fine	0	Fine byte of Pan
3	Tilt	128	
4	Tilt Fine	0	Fine byte of Tilt
5	Position MSpeed	0	
6	Dimmer	0	0–254 Closed 255–255 Open
7	Shutter / Strobe	0	0–3 Open 4–99 Shutter1Strobe 2 100–149 Shutter1StrobePulseClose 3 150–199 Shutter1StrobePulseOpen 4 200–249 Shutter1StrobeRandom 5 250–255 Shutter1 6
8	Color Wheel	0	0–9 Open (wheel slot 1) 10–19 Red (wheel slot 2) 20–29 Yellow (wheel slot 3) 30–39 Blue (wheel slot 4) 40–49 Green (wheel slot 5) 50–59 Orange (wheel slot 6) 60–69 Cyan (wheel slot 7) 70–79 Pink (wheel slot 8) 80–99 Magenta (wheel slot 9) 100–199 Color1WheelIndex 2 200–229 spin < 230–255 spin >
9	Gobo	0	0–4 Open (wheel slot 1) 5–9 Gobo 1 (wheel slot 2) 10–14 Gobo 2 (wheel slot 3) 15–19 Gobo 3 (wheel slot 4) 20–24 Gobo 4 (wheel slot 5) 25–29 Gobo 5 (wheel slot 6) 30–34 Gobo 6 (wheel slot 7) 35–39 Gobo 7 (wheel slot 8) 40–44 Gobo 8 (wheel slot 9) 45–49 Gobo 9 (wheel slot 10) 50–54 Gobo 10 (wheel slot 11) 55–154 Gobo1WheelShake 2 155–202 spin < 203–206 spin >< 207–255 spin >
10	Gobo 2	0	0–9 Open (wheel slot 1) 10–19 Gobo 1 (wheel slot 2) 20–29 Gobo 2 (wheel slot 3) 30–39 Gobo 3 (wheel slot 4) 40–49 Gobo 4 (wheel slot 5) 50–59 Gobo 5 (wheel slot 6) 60–69 Gobo 6 (wheel slot 7) 70–79 Gobo 7 (wheel slot 8) 80–159 Gobo2WheelIndex 2 160–205 spin < 206–210 spin >< 211–255 spin >
11	Gobo Rotation 2	0	0–127 Gobo2Pos 1 128–192 rot < 193–255 rot >
12	Prism	0	0–127 Open (wheel slot 1) 128–255 Prism (wheel slot 2)

18ch (continued)

Ch	Function	Default	DMX values
13	Prism Rotation	0	0–127 Prism1Pos 1 128–193 rot < 194–255 rot >
14	Frost1	0	0–127 Open 128–255 Frost
15	Focus	128	
16	Zoom	128	
17	Control1	0	0–50 No function 51–100 System 101–150 Auto 1 151–200 Auto 2 201–255 Sound control
18	Control2	0	0–250 No function 251–255 Reset