Fun_known

LEDZOOM 368



Manufacturer	**Fun_known**
Type	**Moving head**
DMX modes	**1**
DMX footprint	**14 channels**
Beam angle	**15-60°**
Pan range	**540°**
Tilt range	**270°**
Size (W × H × D)	**220 × 85 × 220 mm**
GDTF fixture type	**4134BF8D-5F6F-4752-8BB2-AF…**

Controls

Zoom · Extra LED colours · RGB colour mixing · Colour wheel · Strobe · Dimmer · Pan and tilt · Movement speed

Safety-relevant functions

Fixture reset

DMX modes

Mode 1	14 ch

Mode 1

14 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Pan Fine	0	Fine byte of Pan
3	Tilt	128	
4	Tilt Fine	0	Fine byte of Tilt
5	Dimmer	0	0–254 Closed 255–255 Open
6	Shutter / Strobe	0	0–6 Open 7–64 Strobe · Slow 0.303–19.9 Hz 65–65 Strobe · Fast 20.2 Hz 66–69 Open 1 70–127 Pulse Strob · Slow 0.126–0.497 Hz 128–128 Pulse Strob · Fast 0.504 Hz 129–132 Open 2 133–190 Pulse Fade Out · Slow 0.2–0.79 Hz 191–191 Pulse Fade Out · Fast 0.8 Hz 192–195 Open 3 196–254 Strobe Randome · Slow 0.5–9.84 Hz 255–255 Strobe Randome · Fast 10 Hz
7	Red	0	
8	Green	0	
9	Blue	0	
10	White	0	
11	Zoom	0	0–254 Narrow 255–255 Wide
12	Position MSpeed	0	
13	Color Macro1	0	
14	Fixture Global Reset	0	125–249 Reset after 3s 250–255 Auto