
Kadence

Sharpy 18R



Manufacturer	**Kadence**
Type	**Moving head**
DMX modes	**1**
DMX footprint	**18 channels**
Beam angle	**36°**
Pan range	**540°**
Tilt range	**270°**
Size (W × H × D)	**278 × 455 × 256 mm**
GDTF fixture type	**C92A7732-8E12-4F13-9E9D-5E…**

Controls

Focus · Frost · Prism · Prism rotation · Colour temperature · Colour wheel · Strobe · Dimmer · Movement speed · Gobos

Safety-relevant functions

Fixture reset · Service functions

DMX modes

18 Channel Mode	18 ch

18 Channel Mode

18 channels

Ch	Function	Default	DMX values
1	Color Wheel	0	0–23 Open (wheel slot 1) 24–46 White/UV (wheel slot 1) 47–69 UV (wheel slot 2) 70–92 UV/Lavander (wheel slot 2) 93–115 Lavander (wheel slot 3) 116–139 Lavander/CTO 3200 (wheel slot 3) 140–162 CTO 3200 K (wheel slot 4) 163–185 CTO 3200K/ CTO 2500K (wheel slot 4) 186–208 CTO 2500 (wheel slot 5) 209–231 CTO 2500K/ Blue Wood (wheel slot 5) 232–255 Blue Wood (wheel slot 6)
2	Shutter / Strobe	255	0–3 Closed 4–102 LInear Strobe Slow to Fast · 1Hz 1–11.9 Hz 103–103 LInear Strobe Slow to Fast · 25Hz 12 Hz 104–107 Open 108–206 Linear Pulse Fast to Slow · Fast 1–8.92 Hz 207–207 Linear Pulse Fast to Slow · Slow 9 Hz 208–212 Open 213–225 Random Strobe low to Fast · Fast 1–4.47 Hz 226–238 Random Strobe low to Fast · Med 4.76–8.24 Hz 239–251 Random Strobe low to Fast · Slow 8.53–12 Hz 252–255 Open
3	Dimmer	0	0–254 Close 255–255 Open

18 Channel Mode (continued)

Ch	Function	Default	DMX values
4	Gobo	0	0–3 OPEN (wheel slot 1) 4–7 GOBO 1 (wheel slot 2) 8–11 GOBO 2 (wheel slot 3) 12–14 GOBO 3 (wheel slot 4) 15–18 GOBO 4 (wheel slot 5) 19–22 GOBO 5 (wheel slot 6) 23–26 GOBO 6 (wheel slot 7) 27–29 GOBO 7 (wheel slot 8) 30–33 Gobo 8 (wheel slot 9) 34–37 Gobo 9 (wheel slot 10) 38–41 Gobo 10 (wheel slot 11) 42–44 Gobo 11 (wheel slot 12) 45–48 Gobo 12 (wheel slot 13) 49–52 Gobo 13 (wheel slot 14) 53–56 Gobo 14 (wheel slot 15) 57–59 Gobo 15 (wheel slot 16) 60–63 Gobo 16 (wheel slot 17) 64–67 Gobo 17 (wheel slot 18) 68–71 Gobo 18 (wheel slot 19) 72–92 <<< 93–112 << 113–113 < 114–117 Stop 118–138 > 139–158 >> 159–159 >>> 160–165 GOBO 1 (wheel slot 2) 166–170 GOBO 2 (wheel slot 3) 171–175 GOBO 3 (wheel slot 4) 176–181 GOBO 4 (wheel slot 5) 182–186 GOBO 5 (wheel slot 6) 187–191 GOBO 6 (wheel slot 7) 192–196 Gobo 7 (wheel slot 8) 197–202 Gobo 8 (wheel slot 9) 203–207 Gobo 9 (wheel slot 10) 208–212 Gobo 10 (wheel slot 11) 213–218 Gobo 11 (wheel slot 12) 219–223 Gobo 12 (wheel slot 13) 224–228 Gobo 13 (wheel slot 14) 229–233 Gobo 14 (wheel slot 15) 234–239 Gobo 15 (wheel slot 16) 240–244 Gobo 16 (wheel slot 17) 245–249 Gobo 17 (wheel slot 18) 250–255 Gobo 18 (wheel slot 19)
5	Prism	0	0–127 Open (wheel slot 1) 128–255 Prism 4 facet (wheel slot 2)
6	Prism Rotation	0	0–21 CW 0 TO 90 22–42 CW 90 to 180 43–63 CW 180 to 270 64–84 CW 270 to 360 85–105 CW 360 to 450 106–127 CW 450 to 540 128–190 CW 191–254 Stop 255–255 CCW
7	C TO	0	
8	Frost1	0	0–254 Open (wheel slot 1) 255–255 Frost (wheel slot 2)
9	Focus	127	
10	Pan	128	

18 Channel Mode (continued)

Ch	Function	Default	DMX values
11	Pan Fine	0	Fine byte of Pan
12	Tilt	128	
13	Tilt Fine	0	Fine byte of Tilt
14	Position MSpeed	0	
15	Function	0	0–110 Unused Range 1 111–120 Standard CMY Speed 121–130 Fast CMY Speed 131–140 Dimmer Curve 1 141–150 Dimmer Curve 2 151–160 Display OFF 161–170 Display ON 171–255 Unused Range
16	Fixture Global Reset	0	0–25 Unused Range 26–76 Effect Reset 77–127 Pan / Tilt Reset 128–255 Fixture Reset
17	Prism	0	0–127 Open (wheel slot 1) 128–255 Prism 8 Facet (wheel slot 2)
18	Prism Rotation	0	0–127 CW 0 TO 90 128–191 Forward Rotation 192–255 Reverse Rotation