Lightmaxx

Platinum mini Exeo V4



Manufacturer	**Lightmaxx**
Type	**Moving head**
DMX modes	**1**
DMX footprint	**13 channels**
Beam angle	**25°**
Pan range	**1°**
Tilt range	**1°**
Size (W × H × D)	**240 × 450 × 220 mm**
GDTF fixture type	**235F1BE8-B050-4895-94E7-B14…**

Controls

Focus · Prism · Colour wheel · Strobe · Dimmer · Pan and tilt · Gobo rotation

Safety-relevant functions

Strobe

DMX modes

13 Kanal — 13 ch

13 Kanal

13 channels

Ch	Function	Default	DMX values
1	Pan	0	
2	Tilt	0	
3	Dimmer	0	
4	Color1Wheel Index	0	0–13 White (wheel slot 1) 14–27 Yellow (wheel slot 2) 28–41 Pink (wheel slot 3) 42–55 Green (wheel slot 4) 56–69 Magenta (wheel slot 5) 70–83 Blue (wheel slot 6) 84–97 Light Yellow (wheel slot 7) 98–111 Deep Straw (wheel slot 8) 112–127 Pink (wheel slot 3) 128–191 Rainbow (wheel slot 9) 192–255 Rainbow reverse (wheel slot 10)
5	Gobo1Wheel Index	0	0–9 Open (wheel slot 1) 10–19 Lines (wheel slot 2) 20–29 Dots (wheel slot 3) 30–39 Star (wheel slot 4) 40–49 Swirl (wheel slot 5) 50–59 Grid (wheel slot 6) 60–69 Spiral (wheel slot 7) 70–79 Abstract (wheel slot 8) 80–99 Lines Shake (wheel slot 2) 100–119 Dots Shake (wheel slot 3) 120–139 Star Shake (wheel slot 4) 140–159 Swirl Shake (wheel slot 5) 160–179 Grid Shake (wheel slot 6) 180–199 Spiral Shake (wheel slot 7) 200–219 Abstract Shake (wheel slot 8) 220–255 Rotation (wheel slot 9)
6	Gobo Rotation	0	0–127 No 128–191 Foreward 192–255 BAckwards
7	Shutter / Strobe	0	0–9 Closed 10–19 Open 20–127 Strobe 1 128–137 Open 138–201 Strobe 2 202–255 Open
8	Dimmer	0	
9	Focus	0	
10	Prism	0	0–3 Open (wheel slot 1) 4–127 close (Prism Start) (wheel slot 2) 128–255 PrismROT (wheel slot 3)
11	Color Macro1	0	
12	Pan Fine	0	Fine byte of Pan
13	Tilt Fine	0	Fine byte of Tilt