Lightsense

CI-031



Manufacturer	**Lightsense**
Type	**Profile spot**
DMX modes	**1**
DMX footprint	**36 channels**
Beam angle	**25°**
Pan range	**540°**
Tilt range	**220°**
Size (W × H × D)	**240 × 450 × 220 mm**
GDTF fixture type	**D6025EF0-4641-48F6-B228-F91…**

Controls

Focus · Frost · Iris · Prism · Prism rotation · Zoom · Extra LED colours · Colour temperature · Colour wheel · Effect speed · Dimmer · Gobos

Safety-relevant functions

Fixture reset · Strobe

DMX modes

CI-031	36 ch

CI-031

36 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Pan Fine	0	Fine byte of Pan
3	Tilt	128	
4	Tilt Fine	0	Fine byte of Tilt
5	Effect Speed	0	
6	Strobe Duration	0	0–251 Strobe Slow to fast 252–255 Open
7	Dimmer	255	0–254 Closed 255–255 Open
8	Color RGBCyan	0	
9	Color RGBMagenta	0	
10	Color RGBYellow	0	
11	C TO	0	
12	Color Wheel	0	0–127 White (wheel slot 1) 128–137 Color1 (wheel slot 2) 138–146 Color2 (wheel slot 3) 147–155 Color3 (wheel slot 4) 156–164 Color4 (wheel slot 5) 165–173 Color5 (wheel slot 6) 174–182 Color6 (wheel slot 7) 183–191 Color7 (wheel slot 8) 192–222 Water fast to slow forward 223–224 Stop 225–255 Water fast to slow reverse
13	C TOFine	0	
14	Gobo	0	0–9 Gobo Open (wheel slot 1) 10–19 Gobo1 (wheel slot 2) 20–29 Gobo2 (wheel slot 3) 30–39 Gobo3 (wheel slot 4) 40–49 Gobo4 (wheel slot 5) 50–59 Gobo5 (wheel slot 6) 60–69 Gobo6 (wheel slot 7) 70–79 Gobo7 (wheel slot 8) 80–89 Gobo8 (wheel slot 9) 90–99 Shake gobo1 100–109 Shake gobo2 110–119 Shake gobo3 120–129 Shake gobo4 130–139 Shake gobo5 140–149 Shake gobo6 150–159 Shake gobo7 160–169 Shake gobo8 170–212 Water from fast to slow forward 213–215 Stop 216–255 Water from fast to slow reverse
15	Gobo Glass	0	0–9 White 10–69 gobo glass1-6 70–129 Shake gobo glass1-6 130–190 Water from fast to slow forward 191–192 Stop 193–255 Water from fast to slow reverse
16	Gobo Glass Rotate	0	0–127 Open 128–190 Water from fast to slow forward 191–192 Stop 193–255 Water from fast to slow revrse

CI-031 (continued)

Ch	Function	Default	DMX values
17	Animation Of Plate	0	0–10 Open 11–255 The linear inserting
18	Animation Spiral	0	0–2 Stop 3–128 Water from fast to slow forward 129–255 Water from fast to slow revrse
19	Focus	0	
20	Focus Fine	0	
21	Zoom	0	
22	Prism	0	0–63 Open (wheel slot 1) 64–127 Prism1 (wheel slot 2) 128–191 Prism2 (wheel slot 3) 192–255 Prism3 (wheel slot 4)
23	Prism Rotation	0	0–127 Angle switching 128–187 Water from fast to slow forward 188–195 Stop 196–255 Water from fast to slow reverse
24	Prism Rotation	0	0–127 Angle switching 128–187 Water from fast to slow forward 188–195 Stop 196–255 Water from fast to slow reverse
25	Frost1	0	0–127 No 128–255 Automization
26	Shutter / Strobe	0	
27	Shutter / Strobe 2	0	
28	Shutter / Strobe 3	0	
29	Shutter / Strobe 4	0	
30	Shutter / Strobe 5	0	
31	Shutter / Strobe 6	0	
32	Shutter / Strobe 7	0	
33	Shutter / Strobe 8	0	
34	Shutter Rotate	0	
35	Iris	0	0–127 From big to small 128–255 Open
36	Reset	0	0–209 No 210–215 Reset pan/tilt (6s) 216–235 Reset motor (6s) 236–255 Reset all (6s)