Lightsense

JW-250B



Manufacturer	**Lightsense**
Type	**Moving head**
DMX modes	**1**
DMX footprint	**16 channels**
Beam angle	**25°**
Pan range	**540°**
Tilt range	**220°**
Size (W × H × D)	**240 × 450 × 220 mm**
GDTF fixture type	**CF82B99B-AFF6-4131-A366-AF…**

Controls

Focus · Frost · Prism · Prism rotation · Zoom · Colour wheel · Effect speed · Dimmer · Gobos · Gobo rotation

Safety-relevant functions

Fixture reset

DMX modes

Default	16 ch

Default

16 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Tilt	128	
3	Effect Speed	0	
4	Dimmer	0	0–254 Closed 255–255 Open
5	Strobe Duration	0	0–7 Strobe turn on 8–250 Strobe slow to fast 251–255 Strobe turn on
6	Color Wheel	0	0–15 Color white 16–31 Color1 32–47 Color2 48–63 Color3 64–79 Color4 80–95 Color5 96–111 Color6 112–127 Color7 128–191 CW from slow to fast 192–255 CCW from slow to fast
7	Color1Wheel Index	0	0–10 No function 11–209 Color fine tuning 210–255 Color shake
8	Gobo	0	0–6 Open 7–13 Gobo1 14–20 Gobo2 21–27 Gobo3 28–34 Gobo4 35–41 Gobo5 42–48 Gobo6 49–55 Gobo7 56–63 Gobo8 64–70 Gobo8 shake 71–77 Gobo7 shake 78–84 Gobo6 shake 85–91 Gobo5 shake 92–98 Gobo4 shake 99–105 Gobo3 shake 106–112 Gobo2 shake 113–119 Gobo1 shake 120–127 Open 128–191 Gobo rotate CW 192–255 Gobo rotate CCW
9	Gobo Rotation	0	0–15 Open 16–31 Gobo rotate1 32–47 Gobo rotate2 48–63 Gobo rotate3 64–79 Gobo rotate4 80–95 Gobo rotate5 96–111 Gobo rotate6 112–127 Gobo rotate7 128–191 Gobo rotate CW 192–255 Gobo rotate CCW
10	Gobo1Select Effects	0	0–15 Open 16–95 Gobo fine 0-250 96–135 Gobo rotating 0-90 136–155 Gobo rotating 0-250 156–175 Gobo rotating 0-360 176–215 Gobo self-rotating CW 216–255 Gobo self-rotating CCW
11	Focus	0	

Default (continued)

Ch	Function	Default	DMX values
12	Zoom	0	
13	Prism	0	0–63 Prism open 64–255 Prism in
14	Prism Rotation	0	0–15 Open 16–95 Prism fine 0-250 96–135 Prism rotating 0-90 136–155 Prism rotating 0-250 156–175 Prism rotating 0-360 176–215 Prism self-rotating CW 216–255 Prism self-rotating CCW
15	Frost1	0	0–63 Open 64–255 Frost effect
16	Playmode	0	0–7 No action 8–131 Auto mode program 132–249 Sound mode 250–253 Reset 254–255 No action