OGSON fixtures

ADJ Vizi Spot 5R



Manufacturer	**OGSON fixtures**
Type	**Moving head**
DMX modes	**2**
DMX footprint	**11, 13 channels**
Beam angle	**25°**
Pan range	**540°**
Tilt range	**220°**
Size (W × H × D)	**240 × 450 × 220 mm**
GDTF fixture type	**EDD0E674-8E04-4130-9743-79…**

Controls

Focus · Prism · Colour wheel · Dimmer · Movement speed · Gobos · Gobo rotation

Safety-relevant functions

Fixture reset

DMX modes

11 ch
13 ch

11 ch
13 ch

11 ch

11 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Tilt	128	
3	Dimmer	0	0–254 Closed 255–255 Open
4	Color Wheel	0	0–13 Open (wheel slot 1) 14–27 Color 1 (wheel slot 2) 28–42 Color 2 (wheel slot 3) 43–55 Color 3 (wheel slot 4) 56–69 Color 4 (wheel slot 5) 70–83 Color 5 (wheel slot 6) 84–97 Color 6 (wheel slot 7) 98–111 Color 7 (wheel slot 8) 112–127 Color 8 (wheel slot 9) 128–189 spin < 190–193 spin >< 194–255 spin >
5	Gobo	0	0–9 Open (wheel slot 1) 10–19 Gobo 1 (wheel slot 2) 20–29 Gobo 2 (wheel slot 3) 30–39 Gobo 3 (wheel slot 4) 40–49 Gobo 4 (wheel slot 5) 50–59 Gobo 5 (wheel slot 6) 60–69 Gobo 6 (wheel slot 7) 70–79 Gobo 7 (wheel slot 8) 80–89 Gobo 8 (wheel slot 9) 90–255 Gobo1WheelShake 2
6	Gobo Rotation	0	0–127 Gobo1Pos 1 128–189 rot < 190–193 rot >< 194–255 rot >
7	Prism	0	0–3 Open (wheel slot 1) 4–63 Prism rot < 64–68 Prism rot >< 69–127 Prism rot > 128–255 Effects1 2
8	Focus	0	
9	Shutter / Strobe	255	0–63 Shutter1 1 64–95 Shutter1Strobe 2 96–127 Open 2 128–159 Shutter1StrobePulse 4 160–191 Open 1 192–223 Shutter1StrobeRandom 6 224–255 Open
10	Position MSpeed	0	
11	Control1	0	0–39 Control1 1 40–79 LampControl 2 80–99 FixtureGlobalReset 3 100–255 Effects1 4

13 ch

13 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Pan Fine	128	Fine byte of Pan
3	Tilt	128	
4	Tilt Fine	128	Fine byte of Tilt

13 ch (continued)

Ch	Function	Default	DMX values
5	Color Wheel	0	0–13 Open (wheel slot 1) 14–27 Color 1 (wheel slot 2) 28–42 Color 2 (wheel slot 3) 43–55 Color 3 (wheel slot 4) 56–69 Color 4 (wheel slot 5) 70–83 Color 5 (wheel slot 6) 84–97 Color 6 (wheel slot 7) 98–111 Color 7 (wheel slot 8) 112–127 Color 8 (wheel slot 9) 128–189 spin < 190–193 spin >< 194–255 spin >
6	Gobo	0	0–9 Open (wheel slot 1) 10–19 Gobo 1 (wheel slot 2) 20–29 Gobo 2 (wheel slot 3) 30–39 Gobo 3 (wheel slot 4) 40–49 Gobo 4 (wheel slot 5) 50–59 Gobo 5 (wheel slot 6) 60–69 Gobo 6 (wheel slot 7) 70–79 Gobo 7 (wheel slot 8) 80–89 Gobo 8 (wheel slot 9) 90–255 Gobo1WheelShake 2
7	Gobo Rotation	0	0–127 Gobo1Pos 1 128–189 rot < 190–193 rot >< 194–255 rot >
8	Prism	0	0–3 Open (wheel slot 1) 4–63 Prism rot < 64–68 Prism rot >< 69–127 Prism rot > 128–255 Effects1 2
9	Focus	0	
10	Shutter / Strobe	255	0–63 Shutter1 1 64–95 Shutter1Strobe 2 96–127 Open 2 128–159 Shutter1StrobePulse 4 160–191 Open 1 192–223 Shutter1StrobeRandom 6 224–255 Open
11	Dimmer	0	0–254 Closed 255–255 Open
12	Position MSpeed	0	
13	Control1	0	0–39 Control1 1 40–79 LampControl 2 80–99 FixtureGlobalReset 3 100–255 Effects1 4