OGSON fixtures

Fractal Mini Led Gogo Spot 60 W prism



Manufacturer	**OGSON fixtures**
Type	**Moving head**
DMX modes	**2**
DMX footprint	**9, 11 channels**
Beam angle	**25°**
Pan range	**540°**
Tilt range	**220°**
Size (W × H × D)	**240 × 450 × 220 mm**
GDTF fixture type	**CCD50B8E-04AD-4E65-AB8D-F…**

Controls

Colour wheel · Dimmer · Movement speed · Gobos

Safety-relevant functions

Fixture reset · Built-in effect programmes

DMX modes

9 ch
11 ch

9 ch
11 ch

9 ch

9 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Tilt	128	
3	Color Wheel	0	0–13 Open (wheel slot 1) 14–27 Color 1 (wheel slot 2) 28–42 Color 2 (wheel slot 3) 43–55 Color 3 (wheel slot 4) 56–69 Color 4 (wheel slot 5) 70–83 Color 5 (wheel slot 6) 84–97 Color 6 (wheel slot 7) 98–111 Color 7 (wheel slot 8) 112–139 Color 8 (wheel slot 9) 140–255 Color1WheelSpin 2
4	Gobo	0	0–9 Open (wheel slot 1) 10–19 Gobo 1 (wheel slot 2) 20–29 Gobo 2 (wheel slot 3) 30–39 Gobo 3 (wheel slot 4) 40–49 Gobo 4 (wheel slot 5) 50–63 Gobo 5 (wheel slot 6) 64–127 Gobo1WheelShake 2 128–255 Gobo1WheelSpin 3
5	Shutter / Strobe	255	0–63 Shutter1 1 64–95 Shutter1Strobe 2 96–127 Open 2 128–159 Shutter1StrobePulse 4 160–191 Open 1 192–223 Shutter1StrobeRandom 6 224–255 Open
6	Dimmer	0	0–254 Closed 255–255 Open
7	Position MSpeed	0	
8	Effect	0	
9	Control1	0	0–249 Control1 1 250–255 FixtureGlobalReset 3

11 ch

11 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Pan Fine	128	Fine byte of Pan
3	Tilt	128	
4	Tilt Fine	128	Fine byte of Tilt
5	Color Wheel	0	0–13 Open (wheel slot 1) 14–27 Color 1 (wheel slot 2) 28–42 Color 2 (wheel slot 3) 43–55 Color 3 (wheel slot 4) 56–69 Color 4 (wheel slot 5) 70–83 Color 5 (wheel slot 6) 84–97 Color 6 (wheel slot 7) 98–111 Color 7 (wheel slot 8) 112–139 Color 8 (wheel slot 9) 140–255 Color1WheelSpin 2

11 ch (continued)

Ch	Function	Default	DMX values
6	Gobo	0	0–9 Open (wheel slot 1) 10–19 Gobo 1 (wheel slot 2) 20–29 Gobo 2 (wheel slot 3) 30–39 Gobo 3 (wheel slot 4) 40–49 Gobo 4 (wheel slot 5) 50–63 Gobo 5 (wheel slot 6) 64–127 Gobo1WheelShake 2 128–255 Gobo1WheelSpin 3
7	Shutter / Strobe	255	0–63 Shutter1 1 64–95 Shutter1Strobe 2 96–127 Open 2 128–159 Shutter1StrobePulse 4 160–191 Open 1 192–223 Shutter1StrobeRandom 6 224–255 Open
8	Dimmer	0	0–254 Closed 255–255 Open
9	Position MSpeed	0	
10	Effect	0	
11	Control1	0	0–249 Control1 1 250–255 FixtureGlobalReset 3