OXO Light

# FUNSTRIP 180 LH



| | |
|---|---|
| Manufacturer | **OXO Light** |
| Type | **Effect light** |
| DMX modes | **10** |
| DMX footprint | **1, 2, 4, 5, 10, 15, 20, 25 channels** |
| Beam angle | **10°** |
| Size (W × H × D) | **1082 × 100 × 120 mm** |
| GDTF fixture type | **03B864AA-C690-46CA-BEBA-31…** |

## Controls

Effect speed · Dimmer

## Safety-relevant functions

Strobe · Built-in effect programmes

## DMX modes

| | |
|---|---|
| Mode 1/8bits | 1 ch |
| Mode 2/16bits | 2 ch |
| Mode 2/8bits 1 | 2 ch |
| Mode 4/16bits | 4 ch |
| Mode 5/8bits | 5 ch |
| Mode 10/16bits | 10 ch |
| Mode 10/8bits | 10 ch |
| Mode 15/8bits | 15 ch |
| Mode 20/16bits | 20 ch |
| Mode 25/16bits | 25 ch |

## Mode 1/8bits

1 channel

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Dimmer | 0 | |

## Mode 2/16bits

2 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Dimmer | 0 | |
| 2 | Dimmer Fine | 0 | Fine byte of Dimmer |

## Mode 2/8bits 1

2 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Dimmer | 0 | |
| 2 | Dimmer | 0 | |

## Mode 4/16bits

4 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Dimmer | 0 | |
| 2 | Dimmer Fine | 0 | Fine byte of Dimmer |
| 3 | Dimmer | 0 | |
| 4 | Dimmer Fine | 0 | Fine byte of Dimmer |

## Mode 5/8bits

5 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Dimmer | 0 | |
| 2 | Dimmer | 0 | |
| 3 | Dimmer | 0 | |
| 4 | Dimmer | 0 | |
| 5 | Dimmer | 0 | |

## Mode 10/16bits

10 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Dimmer | 0 | |
| 2 | Dimmer Fine | 0 | Fine byte of Dimmer |
| 3 | Dimmer | 0 | |
| 4 | Dimmer Fine | 0 | Fine byte of Dimmer |
| 5 | Dimmer | 0 | |
| 6 | Dimmer Fine | 0 | Fine byte of Dimmer |
| 7 | Dimmer | 0 | |
| 8 | Dimmer Fine | 0 | Fine byte of Dimmer |
| 9 | Dimmer | 0 | |
| 10 | Dimmer Fine | 0 | Fine byte of Dimmer |

## Mode 10/8bits

10 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Dimmer | 0 | |
| 2 | Dimmer | 0 | |
| 3 | Dimmer | 0 | |
| 4 | Dimmer | 0 | |
| 5 | Dimmer | 0 | |
| 6 | Dimmer | 0 | |
| 7 | Dimmer | 0 | |
| 8 | Dimmer | 0 | |
| 9 | Dimmer | 0 | |
| 10 | Dimmer | 0 | |

## Mode 15/8bits

15 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Dimmer | 255 | |
| 2 | Dimmer | 255 | |
| 3 | Dimmer | 255 | |
| 4 | Dimmer | 255 | |
| 5 | Dimmer | 255 | |
| 6 | Dimmer | 255 | |
| 7 | Dimmer | 255 | |
| 8 | Dimmer | 255 | |
| 9 | Dimmer | 255 | |
| 10 | Dimmer | 255 | |
| 11 | Effect | 0 | 0–7 Prog OFF<br>8–15 Prog FULL ON<br>16–23 Prog 1<br>24–31 Prog 2<br>32–39 Prog 3<br>40–47 Prog 4<br>48–55 Prog 5<br>56–63 Prog 6<br>64–71 Prog 7<br>72–79 Prog 8<br>80–87 Prog 9<br>88–95 Prog 10<br>96–103 Prog 11<br>104–111 Prog 12<br>112–119 Prog 13<br>120–127 Prog 14<br>128–135 Prog 15<br>136–143 Prog 16<br>144–255 Prog Auto |
| 12 | Effect Speed | 200 | |
| 13 | Effects1Fade | 255 | |
| 14 | Effects1Pos | 150 | 0–51 STOP EFFECT<br>52–127 PAUSE EFFECT<br>128–191 FORWARD EFFECT<br>192–255 BACKWARD EFFECT |
| 15 | Shutter / Strobe | 0 | |

## Mode 20/16bits

20 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Dimmer | 0 | |
| 2 | Dimmer Fine | 0 | Fine byte of Dimmer |
| 3 | Dimmer | 0 | |
| 4 | Dimmer Fine | 0 | Fine byte of Dimmer |
| 5 | Dimmer | 0 | |
| 6 | Dimmer Fine | 0 | Fine byte of Dimmer |
| 7 | Dimmer | 0 | |
| 8 | Dimmer Fine | 0 | Fine byte of Dimmer |
| 9 | Dimmer | 0 | |
| 10 | Dimmer Fine | 0 | Fine byte of Dimmer |
| 11 | Dimmer | 0 | |
| 12 | Dimmer Fine | 0 | Fine byte of Dimmer |
| 13 | Dimmer | 0 | |
| 14 | Dimmer Fine | 0 | Fine byte of Dimmer |
| 15 | Dimmer | 0 | |
| 16 | Dimmer Fine | 0 | Fine byte of Dimmer |
| 17 | Dimmer | 0 | |
| 18 | Dimmer Fine | 0 | Fine byte of Dimmer |
| 19 | Dimmer | 0 | |
| 20 | Dimmer Fine | 0 | Fine byte of Dimmer |

## Mode 25/16bits

25 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Dimmer | 0 | |
| 2 | Dimmer Fine | 255 | Fine byte of Dimmer |
| 3 | Dimmer | 0 | |
| 4 | Dimmer Fine | 255 | Fine byte of Dimmer |
| 5 | Dimmer | 0 | |
| 6 | Dimmer Fine | 255 | Fine byte of Dimmer |
| 7 | Dimmer | 0 | |
| 8 | Dimmer Fine | 255 | Fine byte of Dimmer |
| 9 | Dimmer | 0 | |
| 10 | Dimmer Fine | 255 | Fine byte of Dimmer |
| 11 | Dimmer | 0 | |
| 12 | Dimmer Fine | 255 | Fine byte of Dimmer |
| 13 | Dimmer | 0 | |
| 14 | Dimmer Fine | 255 | Fine byte of Dimmer |
| 15 | Dimmer | 0 | |
| 16 | Dimmer Fine | 255 | Fine byte of Dimmer |
| 17 | Dimmer | 0 | |
| 18 | Dimmer Fine | 255 | Fine byte of Dimmer |
| 19 | Dimmer | 0 | |
| 20 | Dimmer Fine | 255 | Fine byte of Dimmer |

## Mode 25/16bits (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **21** | Effect | 0 | 0–7 Prog OFF<br>8–15 Prog FULL ON<br>16–23 Prog 1<br>24–31 Prog 2<br>32–39 Prog 3<br>40–47 Prog 4<br>48–55 Prog 5<br>56–63 Prog 6<br>64–71 Prog 7<br>72–79 Prog 8<br>80–87 Prog 9<br>88–95 Prog 10<br>96–103 Prog 11<br>104–111 Prog 12<br>112–119 Prog 13<br>120–127 Prog 14<br>128–135 Prog 15<br>136–143 Prog 16<br>144–255 Prog Auto |
| **22** | Effect Speed | 200 | |
| **23** | Effects1Fade | 255 | |
| **24** | Effects1Pos | 150 | 0–51 STOP EFFECT<br>52–127 PAUSE EFFECT<br>128–191 FORWARD EFFECT<br>192–255 BACKWARD EFFECT |
| **25** | Shutter / Strobe | 0 | |