Prolights

Lumipix12QTour



Manufacturer	**Prolights**
Type	**Blinder**
DMX modes	**6**
DMX footprint	**5, 7, 8, 9, 11, 49 channels**
Beam angle	**22.6°**
Tilt range	**320°**
Size (W × H × D)	**994 × 112 × 70 mm**
GDTF fixture type	**650C2934-69C8-46F1-AD9C-7D…**

Controls

Extra LED colours · RGB colour mixing · Colour temperature · Effect speed · Strobe · Dimmer

Safety-relevant functions

Built-in effect programmes

DMX modes

5ch	5 ch
7ch	7 ch
8ch	8 ch
9ch	9 ch
11ch	11 ch
49ch	49 ch

5ch

5 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	White	255	
5	Dimmer Mode	0	0–10 AsFromMenu 11–45 OFF 46–80 Mode 1s 81–115 Mode 2s 116–150 Mode 3s 151–185 Mode 5s 186–220 Mode 10s 221–255 Mode 20s

7ch

7 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	White	255	
5	Dimmer	0	0–254 Closed 255–255 Open
6	Shutter / Strobe	10	10–10 Open 11–255 Strobe · Slow2Fast 0.9–15 Hz
7	Dimmer Mode	0	0–10 AsFromMenu 11–45 OFF 46–80 Mode 1s 81–115 Mode 2s 116–150 Mode 3s 151–185 Mode 5s 186–220 Mode 10s 221–255 Mode 20s

8ch

8 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	White	255	
5	Dimmer	0	0–254 Closed 255–255 Open
6	Dimmer Fine	0	Fine byte of Dimmer
7	Shutter / Strobe	10	10–10 Open 11–255 Strobe · Slow2Fast 0.9–15 Hz
8	Dimmer Mode	0	0–10 AsFromMenu 11–45 OFF 46–80 Mode 1s 81–115 Mode 2s 116–150 Mode 3s 151–185 Mode 5s 186–220 Mode 10s 221–255 Mode 20s

9ch

9 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	White	255	
5	Shutter / Strobe	10	10–10 Open 11–255 Strobe · Slow2Fast 0.9–15 Hz
6	Effect	0	0–10 NoFeature 11–30 Effect1 31–50 Effect2 51–70 Effect3 71–90 Effect4 91–110 Effect5 111–130 Effect6 131–150 Effect7 151–170 Effect8 171–190 Effect9 191–210 Effect10 211–250 Effect12 251–255 Effect13
7	Effect Speed	0	0–254 Slow 255–255 Fast
8	Dimmer	0	0–254 Closed 255–255 Open
9	Dimmer Mode	0	0–10 AsFromMenu 11–45 OFF 46–80 Mode 1s 81–115 Mode 2s 116–150 Mode 3s 151–185 Mode 5s 186–220 Mode 10s 221–255 Mode 20s

11ch

11 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	White	255	
5	Dimmer	0	0–254 Closed 255–255 Open
6	Dimmer Fine	0	Fine byte of Dimmer
7	Shutter / Strobe	10	10–10 Open 11–255 Strobe · Slow2Fast 0.9–15 Hz
8	Dimmer Mode	0	0–10 AsFromMenu 11–45 OFF 46–80 Mode 1s 81–115 Mode 2s 116–150 Mode 3s 151–185 Mode 5s 186–220 Mode 10s 221–255 Mode 20s
9	C TC	113	0–254 2800K 255–255 10000K

11ch (continued)

Ch	Function	Default	DMX values
10	Tint	127	0–1 Neutral 2–3 FullMinus 4–126 MinusGreen 127–128 Neutral 129–253 PlusGreen 254–255 FullPlus
11	C TCRGB	255	0–254 CCT 255–255 RGBW

49ch

49 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	White	255	
5	Reserved 5	0	
6	Reserved 6	0	
7	Reserved 7	0	
8	Reserved 8	0	
9	Reserved 9	0	
10	Reserved 10	0	
11	Reserved 11	0	
12	Reserved 12	0	
13	Reserved 13	0	
14	Reserved 14	0	
15	Reserved 15	0	
16	Reserved 16	0	
17	Reserved 17	0	
18	Reserved 18	0	
19	Reserved 19	0	
20	Reserved 20	0	
21	Reserved 21	0	
22	Reserved 22	0	
23	Reserved 23	0	
24	Reserved 24	0	
25	Reserved 25	0	
26	Reserved 26	0	
27	Reserved 27	0	
28	Reserved 28	0	
29	Reserved 29	0	
30	Reserved 30	0	
31	Reserved 31	0	
32	Reserved 32	0	
33	Reserved 33	0	
34	Reserved 34	0	
35	Reserved 35	0	

49ch (continued)

Ch	Function	Default	DMX values
36	Reserved 36	0	
37	Reserved 37	0	
38	Reserved 38	0	
39	Reserved 39	0	
40	Reserved 40	0	
41	Reserved 41	0	
42	Reserved 42	0	
43	Reserved 43	0	
44	Reserved 44	0	
45	Reserved 45	0	
46	Reserved 46	0	
47	Reserved 47	0	
48	Reserved 48	0	
49	Dimmer Mode	0	0–10 AsFromMenu 11–45 OFF 46–80 Mode 1s 81–115 Mode 2s 116–150 Mode 3s 151–185 Mode 5s 186–220 Mode 10s 221–255 Mode 20s