Prolights

# MosaicoFX100FC_LWGVW



| | |
|---|---|
| Manufacturer | **Prolights** |
| Type | **PAR** |
| DMX modes | **1** |
| DMX footprint | **13 channels** |
| Beam angle | **35.2°** |
| Size (W × H × D) | **241 × 193 × 45 mm** |
| GDTF fixture type | **C60137E8-C917-48F6-81EC-0A0…** |

## Controls

Extra LED colours · RGB colour mixing · Colour wheel · Strobe · Dimmer

## Safety-relevant functions

Fixture reset · Strobe

## DMX modes

Standard_8ch — 13 ch

## Standard_8ch

13 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Dimmer | 0 | 0–254 Closed<br>255–255 Open |
| 2 | Dimmer Fine | 0 | Fine byte of Dimmer |
| 3 | Shutter / Strobe | 255 | 0–1 Shutter_Open<br>2–61 Strobe_Slow<br>62–62 Strobe_Fast<br>63–64 Shutter_Open<br>65–124 StrobePulseIN_Slow<br>125–125 StrobePulseIN_Fast<br>126–127 Shutter_Close<br>128–187 StrobePulseOUT_Slow<br>188–188 StrobePulseOUT_Fast<br>189–190 Shutter_Open<br>191–250 RandomStrobe_Slow<br>251–251 RandomStrobe_Fast<br>252–255 Shutter_Open |
| 4 | Red | 255 | |
| 5 | Green | 255 | |
| 6 | Blue | 255 | |
| 7 | White | 255 | |
| 8 | Color Macro1 | 0 | |
| 9 | Animation System1Pos | 0 | 0–126 0 degrees<br>127–127 360<br>128–189 CW Spin Fast<br>190–190 CW Spin Slow<br>191–192 Stop<br>193–254 CCW Spin Slow<br>255–255 CCW Spin Fast |
| 10 | Animation System1Pos Fine | 0 | Fine byte of Animation System1Pos |
| 11 | Animation System2Pos | 0 | 0–126 0<br>127–127 360<br>128–189 CW Spin Fast<br>190–190 CW Spin Slow<br>191–192 Stop<br>193–254 CCW Spin Slow<br>255–255 CCW Spin Fast |
| 12 | Animation System2Pos Fine | 0 | Fine byte of Animation System2Pos |

## Standard_8ch (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **13** | Control1 | 0 | 0–1 NoFeature<br>2–3 Linear<br>4–5 S-Curve<br>6–7 Square Law<br>8–9 Inverse Square Law<br>10–11 Auto<br>12–13 Fast<br>14–15 Medium<br>16–17 Slow<br>18–19 600Hz<br>20–21 1200Hz<br>22–23 2000Hz<br>24–25 4000Hz<br>26–27 6000Hz<br>28–29 25KHz<br>30–31 DMX FAULT HOLD<br>32–33 DMX FAULT BLACKOUT<br>34–35 DMX FAULT STAND ALONE<br>36–37 STAND ALONE MASTER DMX<br>38–39 STAND ALONE MASTER NO DMX<br>40–41 STAND ALONE SLAVE<br>42–43 Dummy 7<br>44–45 STAND ALONE FIXED COLORS<br>46–47 STAND ALONE WHITE PRESETS<br>48–49 STAND ALONE COLOR MACROS<br>50–51 STAND ALONE MANUAL COLORS<br>52–53 Invert Rotation OFF<br>54–55 Invert Rotation ON<br>56–57 FanMode AUTO<br>58–59 FanMode HIGH<br>60–61 FanMode SILENT<br>62–63 FanMode OFF<br>64–65 Key Lock OFF<br>66–67 Key Lock ON<br>68–251 Dummy 11<br>252–253 Reset All Control Channel<br>254–255 Dummy 13 |