PRstage

BSW 400 CMY



Manufacturer	**PRstage**
Type	**Moving head**
DMX modes	**1**
DMX footprint	**24 channels**
Beam angle	**2-53°**
Pan range	**540°**
Tilt range	**270°**
Size (W × H × D)	**240 × 373 × 220 mm**
GDTF fixture type	**1AC4374D-57FA-48D2-8BCA-A…**

Controls

Focus · Frost · Prism · Prism rotation · Zoom · CMY colour mixing · Colour temperature · Colour wheel · Dimmer · Pan and tilt · Movement speed · Gobos · Gobo rotation

Safety-relevant functions

Fixture reset

DMX modes

Mode 1	24 ch

Mode 1

24 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Pan Fine	128	Fine byte of Pan
3	Tilt	128	
4	Tilt Fine	128	Fine byte of Tilt
5	Position MSpeed	0	0–254 Fast 255–255 Slow
6	Cyan	0	
7	Magenta	0	
8	Yellow	0	
9	C TO	0	
10	Color Effects1	0	
11	Color Wheel	0	0–9 Open (wheel slot 1) 10–19 White-Red (wheel slot 2) 20–29 Red (wheel slot 3) 30–39 Red-Blue (wheel slot 4) 40–49 Blue (wheel slot 5) 50–59 Blue-Green (wheel slot 6) 60–69 Green (wheel slot 7) 70–79 Green-Deep Amber (wheel slot 8) 80–89 Deep Amber (wheel slot 9) 90–99 Deep Amber-Hot Filter (wheel slot 10) 100–109 Hot Filter (wheel slot 11) 110–119 Hot Filter -VS Violet (wheel slot 12) 120–129 VS-Violet (wheel slot 13) 130–200 CCW Rotation 201–255 CW Rotation
12	Gobo	0	0–4 Open (wheel slot 1) 5–9 Gobo 1 (wheel slot 2) 10–14 Gobo 2 (wheel slot 3) 15–19 Gobo 3 (wheel slot 4) 20–24 Gobo 4 (wheel slot 5) 25–29 Gobo 5 (wheel slot 6) 30–34 Gobo (wheel slot 7) 35–39 Gobo 7 (wheel slot 8) 40–44 Gobo 8 (wheel slot 9) 45–49 Gobo 9 (wheel slot 10) 50–54 Gobo 10 (wheel slot 11) 55–59 Open 60–64 Shake Gobo 1 (wheel slot 2) 65–69 Shake Gobo 2 (wheel slot 2) 70–74 Shake Gobo 3 (wheel slot 3) 75–79 Shake Gobo 4 (wheel slot 4) 80–84 Shake Gobo 5 (wheel slot 5) 85–89 Shake Gobo 6 (wheel slot 6) 90–94 Shake Gobo 7 (wheel slot 7) 95–99 Shake Gobo 8 (wheel slot 8) 100–104 Shake Gobo 9 (wheel slot 9) 105–109 Shake Gobo 10 (wheel slot 10) 110–200 CW Spin Gobo 1 201–255 CCW Spin Gobo 1

Mode 1 (continued)

Ch	Function	Default	DMX values
13	Gobo 2	0	0–9 Open (wheel slot 1) 10–19 Gobo 1 (wheel slot 2) 20–29 Gobo 2 (wheel slot 3) 30–39 Gobo 3 (wheel slot 4) 40–49 Gobo 4 (wheel slot 5) 50–59 Gobo 5 (wheel slot 6) 60–69 Gobo 6 (wheel slot 7) 70–79 Gobo 7 (wheel slot 8) 80–89 Shake Gobo 1 (wheel slot 1) 90–99 Shake Gobo 2 (wheel slot 2) 100–109 Shake Gobo 3 (wheel slot 3) 110–119 Shake Gobo 4 (wheel slot 4) 120–129 Shake Gobo 5 (wheel slot 5) 130–139 Shake Gobo 6 (wheel slot 6) 140–149 Shake Gobo 7 (wheel slot 7) 150–200 CW Spin Gobo 2 201–255 CCW Spin Gobo 2
14	Gobo Rotation	0	0–127 Index 128–191 CW Rotate 192–255 CCW Rotate
15	Prism	0	0–127 Open (wheel slot 1) 128–255 Prism (wheel slot 2)
16	Prism Rotation	0	0–127 Prism Index Cource 128–191 CCW Rotation 192–255 CW Rotation
17	Frost1	0	0–127 Open (wheel slot 1) 128–255 Frost (wheel slot 2)
18	Zoom	0	
19	Zoom Fine	0	Fine byte of Zoom
20	Focus	0	
21	Focus Fine	0	Fine byte of Focus
22	Dimmer	0	0–254 Closed 255–255 Open
23	Shutter1Strobe	0	0–3 Open 4–103 Strob 104–107 Open 108–207 Pulse 208–212 Open 213–251 Empty Channel Set 252–255 Open
24	Control1	0	0–209 No Features 210–255 Reset