Sagitter

AQUFLEZ7Z



Manufacturer	**Sagitter**
Type	**Effect light**
DMX modes	**5**
DMX footprint	**4, 5, 7, 13, 17 channels**
Beam angle	**25°**
Size (W × H × D)	**250 × 220 × 45 mm**
GDTF fixture type	**CD7B806E-8022-40D9-868E-75…**

Controls

Zoom · Extra LED colours · Hue and saturation · RGB colour mixing · Colour wheel · Effect speed · Dimmer

Safety-relevant functions

Fixture reset · Built-in effect programmes

DMX modes

4 Ch	4 ch
5 Ch	5 ch
7 Ch	7 ch
13 Ch	13 ch
17 Ch	17 ch

4 Ch

4 channels

Ch	Function	Default	DMX values
1	Color Macro1	0	
2	White Count	0	0–0 No Functions 1–23 2500k 24–47 3000k 48–71 3500k 72–95 4000k 96–119 4500k 120–143 5000k 144–167 6000k 168–191 7000k 192–215 8000k 216–225 9000k 226–255 10000k
3	Zoom	0	
4	Fixture Global Reset	0	0–200 No Functions 201–220 Reset 221–255 Reset Zoom

5 Ch

5 channels

Ch	Function	Default	DMX values
1	H SBHue	0	
2	H SBSaturation	0	
3	H SBBrightness	0	
4	Zoom	0	
5	Fixture Global Reset	0	0–200 No Functions 201–220 Reset 221–255 Reset Zoom

7 Ch

7 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Red	0	
3	Green	0	
4	Blue	0	
5	White	0	
6	Zoom	0	
7	Fixture Global Reset	0	0–200 No Functions 201–220 Reset 221–255 Reset Zoom

13 Ch

13 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Shutter1Strobe	0	0–9 Led On 10–189 Slow Fast 190–199 Led On 200–249 Random Slow Fast 250–255 Led On
3	Red	0	

13 Ch (continued)

Ch	Function	Default	DMX values
4	Green	0	
5	Blue	0	
6	White	0	
7	Zoom	0	
8	Color Macro1	0	
9	White Count	0	0–0 No Functions 1–23 2500k 24–47 3000k 48–71 3500k 72–95 4000k 96–119 4500k 120–143 5000k 144–167 6000k 168–191 7000k 192–215 8000k 216–225 9000k 226–255 10000k
10	Dimmer Curve	0	0–54 No Functions 55–79 Curve 1 80–119 Curve 2 120–159 Curve 3 160–255 Curve 4
11	L EDFrequency	0	0–9 No Functions 10–54 600 Hz 55–104 1200 Hz 105–154 2400 Hz 155–204 4800 Hz 205–255 15000 Hz
12	Fan Mode	0	0–15 No Functions 16–95 Auto 96–175 Silent 176–255 FULL
13	Fixture Global Reset	0	0–200 No Functions 201–220 Reset 221–255 Reset Zoom

17 Ch

17 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Dimmer Fine	0	Fine byte of Dimmer
3	Shutter1Strobe	0	0–9 Led On 10–189 Slow Fast 190–199 Led On 200–249 Random Slow Fast 250–255 Led On
4	Red	0	
5	Green	0	
6	Blue	0	
7	White	0	
8	Zoom	0	
9	Color Macro1	0	

17 Ch (continued)

Ch	Function	Default	DMX values
10	White Count	0	0–0 No Functions 1–23 2500k 24–47 3000k 48–71 3500k 72–95 4000k 96–119 4500k 120–143 5000k 144–167 6000k 168–191 7000k 192–215 8000k 216–225 9000k 226–255 10000k
11	Effect	0	0–0 No Functions 1–11 Auto Mode 1 12–23 Auto Mode 2 24–35 Auto Mode 3 36–47 Auto Mode 4 48–59 Auto Mode 5 60–71 Auto Mode 6 72–83 Auto Mode 7 84–95 Auto Mode 8 96–107 Auto Mode 9 108–119 Auto Mode 10 120–131 Auto Mode 11 132–143 Auto Mode 12 144–155 Auto Mode 13 156–167 Auto Mode 14 168–179 Auto Mode 15 180–191 Auto Mode 16 192–203 Auto Mode 17 204–215 Auto Mode 18 216–227 Auto Mode 19 228–239 Auto Mode 20 240–251 Auto Mode 21 252–255 Auto Mode 22
12	Effect Speed	0	
13	Dimmer Curve	0	0–54 No Functions 55–79 Curve 1 80–119 Curve 2 120–159 Curve 3 160–255 Curve 4
14	L EDFrequency	0	0–9 No Functions 10–54 600 Hz 55–104 1200 Hz 105–154 2400 Hz 155–204 4800 Hz 205–255 15000 Hz
15	Fan Mode	0	0–15 No Functions 16–95 Auto 96–175 Silent 176–255 FULL
16	Control1	0	
17	Fixture Global Reset	0	0–200 No Functions 201–220 Reset 221–255 Reset Zoom