SHEHDS

LED 230W Spot Moving Head Light



Manufacturer	**SHEHDS**
Type	**Moving head**
DMX modes	**1**
DMX footprint	**18 channels**
Beam angle	**11-25°**
Pan range	**540°**
Tilt range	**220°**
Size (W × H × D)	**203 × 325 × 220 mm**
GDTF fixture type	**C7C7EE0A-96CA-48EA-8EC0-A7…**

Controls

Focus · Prism · Prism rotation · Zoom · Colour wheel · Strobe · Dimmer · Movement speed · Gobos · Gobo rotation

Safety-relevant functions

Fixture reset · Strobe

DMX modes

Default 18 ch

Default

18 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Pan Fine	0	Fine byte of Pan
3	Tilt	128	
4	Tilt Fine	0	Fine byte of Tilt
5	Position MSpeed	0	
6	Dimmer	0	0–254 Closed 255–255 Open
7	Shutter / Strobe	255	0–4 Closed Shutter 5–250 Slow to Fast 251–255 Open Shutter
8	Color Wheel	0	0–4 Open White (wheel slot 1) 5–13 White/Red 14–22 Red (wheel slot 2) 23–31 Red/Yellow 32–40 Yellow (wheel slot 3) 41–49 Yellow/Green 50–58 Green (wheel slot 4) 59–67 Green/Blue 68–76 Blue (wheel slot 5) 77–85 Blue/Lemon Yellow 86–94 Lemon Yellow (wheel slot 6) 95–103 Lemon Yellow/Sky Blue 104–112 Sky Blue (wheel slot 7) 113–121 Sky Blue/Pink 122–130 Pink (wheel slot 8) 131–139 White (wheel slot 1) 140–199 CW Slow to Fast 200–255 CCW Slow to Fast
9	Gobo	0	0–7 Open Gobo (wheel slot 1) 8–17 Gobo 1 (wheel slot 2) 18–27 Gobo 2 (wheel slot 3) 28–37 Gobo 3 (wheel slot 4) 38–47 Gobo 4 (wheel slot 5) 48–57 Gobo 5 (wheel slot 6) 58–67 Gobo 6 (wheel slot 7) 68–77 Gobo 7 (wheel slot 8) 78–87 Gobo 1 Shake (wheel slot 2) 88–97 Gobo 2 Shake (wheel slot 3) 98–107 Gobo 3 Shake (wheel slot 4) 108–117 Gobo 4 Shake (wheel slot 5) 118–127 Gobo 5 Shake (wheel slot 6) 128–137 Gobo 6 Shake (wheel slot 7) 138–147 Gobo 7 Shake (wheel slot 8) 148–202 CW Slow to Fast 203–255 CCW Slow to Fast

Default (continued)

Ch	Function	Default	DMX values
10	Gobo 2	0	0–7 Open Gobo (wheel slot 1) 8–17 Gobo 1 (wheel slot 2) 18–27 Gobo 2 (wheel slot 3) 28–37 Gobo 3 (wheel slot 4) 38–47 Gobo 4 (wheel slot 5) 48–57 Gobo 5 (wheel slot 6) 58–67 Gobo 6 (wheel slot 7) 68–77 Gobo 7 (wheel slot 8) 78–87 Gobo 1 Shake (wheel slot 2) 88–97 Gobo 2 Shake (wheel slot 3) 98–107 Gobo 3 Shake (wheel slot 4) 108–117 Gobo 4 Shake (wheel slot 5) 118–127 Gobo 5 Shake (wheel slot 6) 128–137 Gobo 6 Shake (wheel slot 7) 138–147 Gobo 7 Shake (wheel slot 8) 148–203 CW Slow to Fast 204–255 CCW Slow to Fast
11	Gobo Rotation	0	0–130 CW Slow to Fast 131–255 CCW Slow to Fast
12	Zoom	0	
13	Focus	0	
14	Prism	0	0–7 Open Prism 8–130 5 Face Prism 131–255 Bar Prism
15	Prism Rotation	0	0–133 CW Slow to Fast 134–255 CCW Slow to Fast
16	Color Macro1	0	0–7 No Function 8–255 Color Macro
17	Position Effect	0	0–7 No Function 8–255 Position Effect
18	Fixture Global Reset	0	0–249 No Function 250–255 Global Reset