SHEHDS

SHEHDS LED 180W Beam Move Head Light



Manufacturer	**SHEHDS**
Type	**Moving head**
DMX modes	**1**
DMX footprint	**15 channels**
Beam angle	**2.5°**
Pan range	**450°**
Tilt range	**210°**
Size (W × H × D)	**210 × 305 × 200 mm**
GDTF fixture type	**838A8692-4B20-429A-811C-5D…**

Controls

Focus · Frost · Prism · Colour wheel · Strobe · Dimmer · Movement speed · Gobos

Safety-relevant functions

Fixture reset · Strobe

DMX modes

15 CH — 15 ch

15 CH

15 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Pan Fine	0	Fine byte of Pan
3	Tilt	128	
4	Tilt Fine	0	Fine byte of Tilt
5	Position MSpeed	0	
6	Dimmer	0	0–0 Closed 1–255 Dimmer
7	Shutter / Strobe	0	0–0 No Strobe 1–255 Strobe Slow - Fast
8	Color Wheel	0	0–1 White (wheel slot 1) 2–7 Red (wheel slot 2) 8–13 Yellow (wheel slot 3) 14–19 Indigo (wheel slot 4) 20–25 Forest Green (wheel slot 5) 26–31 Orange (wheel slot 6) 32–37 Magenta (wheel slot 7) 38–43 Steel Blue (wheel slot 8) 44–49 Purple (wheel slot 9) 50–55 Lime (wheel slot 10) 56–61 Amber (wheel slot 11) 62–67 White + Red (wheel slot 12) 68–73 Red + Yellow (wheel slot 13) 74–79 Yellow + Indigo (wheel slot 14) 80–85 Indigo + Forest Green (wheel slot 15) 86–91 Forest Green + Orange (wheel slot 16) 92–97 Orange + Magenta (wheel slot 17) 98–103 Magenta + Steel Blue (wheel slot 18) 104–109 Steel Blue + Purple (wheel slot 19) 110–115 Purple + Lime (wheel slot 20) 116–121 Lime + Amber (wheel slot 21) 122–127 Amber + White (wheel slot 22) 128–189 Rotate Clockwise (wheel slot 23) 190–193 Slow (wheel slot 24) 194–255 Rotate Counter Clockwise (wheel slot 25)
9	Gobo	0	0–15 White (wheel slot 1) 16–23 Gobo1 (wheel slot 2) 24–31 Gobo2 (wheel slot 3) 32–39 Gobo3 (wheel slot 4) 40–47 Gobo4 (wheel slot 5) 48–55 Gobo5 (wheel slot 6) 56–63 Gobo6 (wheel slot 7) 64–71 Gobo7 (wheel slot 8) 72–79 Gobo8 (wheel slot 9) 80–87 Gobo9 (wheel slot 10) 88–95 Gobo10 (wheel slot 11) 96–103 Gobo11 (wheel slot 12) 104–111 Gobo12 (wheel slot 13) 112–119 Gobo13 (wheel slot 14) 120–127 Gobo14 (wheel slot 15) 128–191 Clockwise Rotation 192–255 Counterclockwise Rotation
10	Prism	0	0–7 Prism Off 8–127 Prism Open 128–255 Prism Rotation
11	Focus	0	
12	Frost1	0	0–7 Off 8–127 Frost 128–255 Frost Rainbow

15 CH (continued)

Ch	Function	Default	DMX values
13	Color Macro1	0	0–49 Macro Off 50–149 Auto Mode 150–255 Sound Mode
14	Color Macro1Rate	0	
15	Beam Reset	0	0–240 No Function 241–255 Reset After 5s