Showtec

Airstrike



Manufacturer	**Showtec**
Type	**Profile spot**
DMX modes	**1**
DMX footprint	**10 channels**
Beam angle	**20°**
GDTF fixture type	**1F842CE3-D901-4AA1-BBFC-DE…**

Controls

Colour wheel · Strobe · Dimmer · Gobos

Safety-relevant functions

Lamp on and off · Fixture reset · Strobe

DMX modes

Mode 1 — 10 ch

Mode 1

10 channels

Ch	Function	Default	DMX values
1	Shutter / Strobe	25	0–10 Closed 11–39 Open 1 40–240 Strobe 241–255 Open 2
2	Dimmer	0	
3	Color Wheel	0	0–15 Open/White (wheel slot 1) 16–31 Red (wheel slot 2) 32–47 Green (wheel slot 3) 48–63 Blue (wheel slot 4) 64–79 Amber (wheel slot 5) 80–95 Yellow (wheel slot 6) 96–111 Magenta (wheel slot 7) 112–127 Pink (wheel slot 8) 128–191 Cunterclockwise rot - fast/slow 192–255 Clockwise rot - slow/fast
4	Gobo	0	0–4 Open/Hole (wheel slot 1) 5–9 Gobo 1 (wheel slot 2) 10–14 Gobo 2 (wheel slot 3) 15–19 Gobo 3 (wheel slot 4) 20–24 Gobo 4 (wheel slot 5) 25–29 Gobo 5 (wheel slot 6) 30–34 Gobo 6 (wheel slot 7) 35–39 Gobo 7 (wheel slot 8) 40–44 Gobo 8 (wheel slot 9) 45–49 Gobo 9 (wheel slot 10) 50–54 Gobo 10 (wheel slot 11) 55–59 Gobo 11 (wheel slot 12) 60–64 Gobo 12 (wheel slot 13) 65–69 Gobo 13 (wheel slot 14) 70–74 Gobo 14 (wheel slot 15) 75–75 Gobo 5 Shake fx (wheel slot 6) 76–81 Gobo 1 (wheel slot 2) 82–87 Gobo 2 (wheel slot 3) 88–93 Gobo 3 (wheel slot 4) 94–99 Gobo 4 (wheel slot 5) 100–105 Gobo 5 (wheel slot 6) 106–111 Gobo 6 (wheel slot 7) 112–117 Gobo 7 (wheel slot 8) 118–123 Gobo 8 (wheel slot 9) 124–129 Gobo 9 (wheel slot 10) 130–135 Gobo 10 (wheel slot 11) 136–141 Gobo 11 (wheel slot 12) 142–147 Gobo 12 (wheel slot 13) 148–153 Gobo 13 (wheel slot 14) 154–158 Gobo 14 (wheel slot 15) 159–207 Cunterclockwise rot - fast/slow 208–255 Clockwise rot - slow/fast
5	Beam Shaper Pos Rotate	32	0–63 Indexing 64–67 Stop 68–127 Roller Shake slow-fast 128–132 Stop 133–191 Clokwise roller rotation slow-fast 192–196 Stop 197–255 Cunterclokwise roller rotation slow-fast
6	Blade1A	64	0–127 Gradual mirror angle adjustament 128–159 Mirror shake 1 slow-fast 160–191 Mirror shake 2 slow-fast 192–223 Mirror shake 3 slow-fast 224–255 Mirror shake 4 slow-fast

Mode 1 (continued)

Ch	Function	Default	DMX values
7	Blade2A	64	0–127 Gradual mirror angle adjustament 128–159 Mirror shake 1 slow-fast 160–191 Mirror shake 2 slow-fast 192–223 Mirror shake 3 slow-fast 224–255 Mirror shake 4 slow-fast
8	Blade3A	64	0–127 Gradual mirror angle adjustament 128–159 Mirror shake 1 slow-fast 160–191 Mirror shake 2 slow-fast 192–223 Mirror shake 3 slow-fast 224–255 Mirror shake 4 slow-fast
9	Blade4A	64	0–127 Gradual mirror angle adjustament 128–159 Mirror shake 1 slow-fast 160–191 Mirror shake 2 slow-fast 192–223 Mirror shake 3 slow-fast 224–255 Mirror shake 4 slow-fast
10	Control1	0	0–50 No function 51–100 Energy saving 101–150 Lamp Off 151–200 Lamp On 201–225 Auto run 226–230 Reset 231–255 Sound-controlled