
Spotlight

PC HY LED 700 8C (Mark-II)



Manufacturer	**Spotlight**
Type	**PAR**
DMX modes	**6**
DMX footprint	**4, 7, 11, 18, 28, 29 channels**
Beam angle	**25°**
Size (W × H × D)	**386 × 448 × 50 mm**
GDTF fixture type	**ACBA11D5-50A6-4833-BEDF-4…**

Controls

Extra LED colours · RGB colour mixing · Colour temperature · Colour wheel · Dimmer

Safety-relevant functions

Service functions

DMX modes

EASY	4 ch
HSIC	7 ch
RGBACL+WW+CW	11 ch
RGBACL+WW+CW 16bit	18 ch
STUDIO	28 ch
THEATRE	29 ch

EASY

4 channels

Ch	Function	Default	DMX values
1	Dimmer	0	

EASY (continued)

Ch	Function	Default	DMX values
2	Color Wheel	0	0–0 NONE (wheel slot 1) 1–1 R0384 (wheel slot 2) 2–2 R0383 (wheel slot 3) 3–3 R0385 (wheel slot 4) 4–4 R0085 (wheel slot 5) 5–5 R0079 (wheel slot 6) 6–6 R0080 (wheel slot 7) 7–7 R2006 (wheel slot 8) 8–8 R3220 (wheel slot 9) 9–9 R2007 (wheel slot 10) 10–10 R0084 (wheel slot 11) 11–11 R0078 (wheel slot 12) 12–12 R0081 (wheel slot 13) 13–13 R0068 (wheel slot 14) 14–14 R0368 (wheel slot 15) 15–15 R0069 (wheel slot 16) 16–16 R0065 (wheel slot 17) 17–17 R0067 (wheel slot 18) 18–18 R0367 (wheel slot 19) 19–19 R0064 (wheel slot 20) 20–20 R0375 (wheel slot 21) 21–21 R0370 (wheel slot 22) 22–22 R0366 (wheel slot 23) 23–23 R0369 (wheel slot 24) 24–24 R0072 (wheel slot 25) 25–25 R0062 (wheel slot 26) 26–26 R0063 (wheel slot 27) 27–27 R0060 (wheel slot 28) 28–28 R3206 (wheel slot 29) 29–29 R0372 (wheel slot 30) 30–30 R0373 (wheel slot 31) 31–31 R3208 (wheel slot 32) 32–32 R4315 (wheel slot 33) 33–33 R3216 (wheel slot 34) 34–34 R0053 (wheel slot 35) 35–35 R3204 (wheel slot 36) 36–36 R0360 (wheel slot 37) 37–37 R4215 (wheel slot 38) 38–38 R3203 (wheel slot 39) 39–39 R0362 (wheel slot 40) 40–40 R0371 (wheel slot 41) 41–41 R0364 (wheel slot 42) 42–42 R3202 (wheel slot 43) 43–43 R3218 (wheel slot 44) 44–44 R0365 (wheel slot 45) 45–45 R0061 (wheel slot 46) 46–46 R4330 (wheel slot 47) 47–47 R0363 (wheel slot 48) 48–48 R0066 (wheel slot 49) 49–49 R0070 (wheel slot 50) 50–50 R4360 (wheel slot 51) 51–51 R4390 (wheel slot 52) 52–52 R0073 (wheel slot 53) 53–53 R2005 (wheel slot 54) 54–54 R0374 (wheel slot 55) 55–55 R0093 (wheel slot 56) 56–56 R0392 (wheel slot 57) 57–57 R0095 (wheel slot 58) 58–58 R0395 (wheel slot 59) 59–59 R0076 (wheel slot 60) 60–60 R0077 (wheel slot 61) 61–61 R0075 (wheel slot 62) 62–62 R0376 (wheel slot 63) 63–63 R0071 (wheel slot 64)

EASY (continued)

Ch	Function	Default	DMX values
3	Color Wheel 2	0	0–0 NONE (wheel slot 1) 1–1 071 (wheel slot 2) 2–2 713 (wheel slot 3) 3–3 120 (wheel slot 4) 4–4 363 (wheel slot 5) 5–5 085 (wheel slot 6) 6–6 119 (wheel slot 7) 7–7 716 (wheel slot 8) 8–8 195 (wheel slot 9) 9–9 715 (wheel slot 10) 10–10 723 (wheel slot 11) 11–11 721 (wheel slot 12) 12–12 722 (wheel slot 13) 13–13 079 (wheel slot 14) 14–14 714 (wheel slot 15) 15–15 132 (wheel slot 16) 16–16 068 (wheel slot 17) 17–17 075 (wheel slot 18) 18–18 197 (wheel slot 19) 19–19 712 (wheel slot 20) 20–20 525 (wheel slot 21) 21–21 200 (wheel slot 22) 22–22 719 (wheel slot 23) 23–23 500 (wheel slot 24) 24–24 366 (wheel slot 25) 25–25 283 (wheel slot 26) 26–26 174 (wheel slot 27) 27–27 201 (wheel slot 28) 28–28 281 (wheel slot 29) 29–29 501 (wheel slot 30) 30–30 708 (wheel slot 31) 31–31 502 (wheel slot 32) 32–32 503 (wheel slot 33) 33–33 218 (wheel slot 34) 34–34 278 (wheel slot 35) 35–35 203 (wheel slot 36) 36–36 202 (wheel slot 37) 37–37 061 (wheel slot 38) 38–38 063 (wheel slot 39) 39–39 725 (wheel slot 40) 40–40 117 (wheel slot 41) 41–41 140 (wheel slot 42) 42–42 353 (wheel slot 43) 43–43 144 (wheel slot 44) 44–44 724 (wheel slot 45) 45–45 118 (wheel slot 46) 46–46 172 (wheel slot 47) 47–47 183 (wheel slot 48) 48–48 141 (wheel slot 49) 49–49 161 (wheel slot 50) 50–50 196 (wheel slot 51) 51–51 165 (wheel slot 52) 52–52 352 (wheel slot 53) 53–53 143 (wheel slot 54) 54–54 727 (wheel slot 55) 55–55 729 (wheel slot 56) 56–56 116 (wheel slot 57) 57–57 354 (wheel slot 58) 58–58 115 (wheel slot 59) 59–59 323 (wheel slot 60) 60–60 322 (wheel slot 61) 61–61 131 (wheel slot 62) 62–62 219 (wheel slot 63) 63–63 241 (wheel slot 64)

EASY (continued)

Ch	Function	Default	DMX values
4	C TC	128	0–4 None 5–11 1500K 12–18 1600K 19–25 1700K 26–32 1800K 33–39 1900K 40–46 2000K 47–53 2100K 54–60 2200K 61–67 2300K 68–74 2400K 75–81 2500K 82–88 2600K 89–95 2700K 96–102 2800K 103–109 2900K 110–116 3000K 117–123 3100K 124–130 3200K 131–137 3300K 138–144 3400K 145–151 3500K 152–158 4000K 159–165 5000K 166–172 5600K 173–179 6000K 180–186 6500K 187–193 8000K 194–200 10000K 201–207 12000K 208–214 14000K 215–221 15000K 222–228 16000K 229–235 17000K 236–242 18000K 243–249 19000K 250–255 20000K

HSIC

7 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	H SBHue	0	
3	H SBHue Fine	0	Fine byte of H SBHue
4	H SBSaturation	0	
5	C TC	129	
6	Strobe Frequency	0	0–200 Strobe 201–230 Store 1 231–255 Store 2

HSIC (continued)

Ch	Function	Default	DMX values
7	Control1	0	0–5 Inactive 6–11 Off 12–17 50ms 18–23 100ms 24–29 240ms 30–35 400ms 36–41 600ms 42–47 800ms 48–53 1000ms 54–59 1200ms 60–65 1600ms 66–71 2000ms 72–77 Linear 78–81 Quadratic 82–83 S Curve 84–85 Halo 86–87 Gamma 2:6 88–89 Gamma 2:8 90–95 600Hz 96–101 900Hz 102–107 1200Hz 108–113 2100Hz 114–119 4200Hz 120–125 6000Hz 126–131 10200Hz 132–137 15600Hz 138–143 19800Hz 144–149 ON 150–155 OFF 156–161 Auto 162–167 Standard 168–173 Silent 174–179 Standard 180–185 Rotated 186–191 Off 192–197 On 198–203 LED Calibration 204–209 Default Settings 210–255 FREE

RGBACL+WW+CW

11 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Red	0	
3	Green	0	
4	Blue	0	
5	Color Add RY	0	
6	Color Add C	0	
7	Color Add GY	0	
8	Color Add WW	255	
9	Color Add CW	255	
10	Strobe Frequency	0	0–200 Strobe 201–230 Store 1 231–255 Store 2

RGBACL+WW+CW (continued)

Ch	Function	Default	DMX values
11	Control1	0	0–5 Inactive 6–11 Off 12–17 50ms 18–23 100ms 24–29 240ms 30–35 400ms 36–41 600ms 42–47 800ms 48–53 1000ms 54–59 1200ms 60–65 1600ms 66–71 2000ms 72–77 Linear 78–81 Quadratic 82–83 S Curve 84–85 Halo 86–87 Gamma 2:6 88–89 Gamma 2:8 90–95 600Hz 96–101 900Hz 102–107 1200Hz 108–113 2100Hz 114–119 4200Hz 120–125 6000Hz 126–131 10200Hz 132–137 15600Hz 138–143 19800Hz 144–149 ON 150–155 OFF 156–161 Auto 162–167 Standard 168–173 Silent 174–179 Standard 180–185 Rotated 186–191 Off 192–197 On 198–203 LED Calibration 204–209 Default Settings 210–255 FREE

RGBACL+WW+CW 16bit

18 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Dimmer Fine	0	Fine byte of Dimmer
3	Red	0	
4	Red Fine	0	Fine byte of Red
5	Green	0	
6	Green Fine	0	Fine byte of Green
7	Blue	0	
8	Blue Fine	0	Fine byte of Blue
9	Color Add RY	0	
10	Color Add RY Fine	0	Fine byte of Color Add RY
11	Color Add C	0	
12	Color Add C Fine	0	Fine byte of Color Add C
13	Color Add GY	0	

RGBACL+WW+CW 16bit (continued)

Ch	Function	Default	DMX values
14	Color Add GY Fine	0	Fine byte of Color Add GY
15	Color Add WW	255	
16	Color Add WW Fine	255	Fine byte of Color Add WW
17	Color Add CW	255	
18	Color Add CW Fine	255	Fine byte of Color Add CW

STUDIO

28 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Dimmer Fine	0	Fine byte of Dimmer
3	Red	0	
4	Red Fine	0	Fine byte of Red
5	Green	0	
6	Green Fine	0	Fine byte of Green
7	Blue	0	
8	Blue Fine	0	Fine byte of Blue
9	Color Add RY	0	
10	Color Add RY Fine	0	Fine byte of Color Add RY
11	Color Add C	0	
12	Color Add C Fine	0	Fine byte of Color Add C
13	Color Add GY	0	
14	Color Add GY Fine	0	Fine byte of Color Add GY
15	Color Add WW	255	
16	Color Add WW Fine	255	Fine byte of Color Add WW
17	Color Add CW	255	
18	Color Add CW Fine	255	Fine byte of Color Add CW

STUDIO (continued)

Ch	Function	Default	DMX values
19	Color Wheel	0	0–0 NONE (wheel slot 1) 1–1 R0384 (wheel slot 2) 2–2 R0383 (wheel slot 3) 3–3 R0385 (wheel slot 4) 4–4 R0085 (wheel slot 5) 5–5 R0079 (wheel slot 6) 6–6 R0080 (wheel slot 7) 7–7 R2006 (wheel slot 8) 8–8 R3220 (wheel slot 9) 9–9 R2007 (wheel slot 10) 10–10 R0084 (wheel slot 11) 11–11 R0078 (wheel slot 12) 12–12 R0081 (wheel slot 13) 13–13 R0068 (wheel slot 14) 14–14 R0368 (wheel slot 15) 15–15 R0069 (wheel slot 16) 16–16 R0065 (wheel slot 17) 17–17 R0067 (wheel slot 18) 18–18 R0367 (wheel slot 19) 19–19 R0064 (wheel slot 20) 20–20 R0375 (wheel slot 21) 21–21 R0370 (wheel slot 22) 22–22 R0366 (wheel slot 23) 23–23 R0369 (wheel slot 24) 24–24 R0072 (wheel slot 25) 25–25 R0062 (wheel slot 26) 26–26 R0063 (wheel slot 27) 27–27 R0060 (wheel slot 28) 28–28 R3206 (wheel slot 29) 29–29 R0372 (wheel slot 30) 30–30 R0373 (wheel slot 31) 31–31 R3208 (wheel slot 32) 32–32 R4315 (wheel slot 33) 33–33 R3216 (wheel slot 34) 34–34 R0053 (wheel slot 35) 35–35 R3204 (wheel slot 36) 36–36 R0360 (wheel slot 37) 37–37 R4215 (wheel slot 38) 38–38 R3203 (wheel slot 39) 39–39 R0362 (wheel slot 40) 40–40 R0371 (wheel slot 41) 41–41 R0364 (wheel slot 42) 42–42 R3202 (wheel slot 43) 43–43 R3218 (wheel slot 44) 44–44 R0365 (wheel slot 45) 45–45 R0061 (wheel slot 46) 46–46 R4330 (wheel slot 47) 47–47 R0363 (wheel slot 48) 48–48 R0066 (wheel slot 49) 49–49 R0070 (wheel slot 50) 50–50 R4360 (wheel slot 51) 51–51 R4390 (wheel slot 52) 52–52 R0073 (wheel slot 53) 53–53 R2005 (wheel slot 54) 54–54 R0374 (wheel slot 55) 55–55 R0093 (wheel slot 56) 56–56 R0392 (wheel slot 57) 57–57 R0095 (wheel slot 58) 58–58 R0395 (wheel slot 59) 59–59 R0076 (wheel slot 60) 60–60 R0077 (wheel slot 61) 61–61 R0075 (wheel slot 62) 62–62 R0376 (wheel slot 63) 63–63 R0071 (wheel slot 64)

STUDIO (continued)

Ch	Function	Default	DMX values
20	Color Wheel 2	0	0–0 NONE (wheel slot 1) 1–1 071 (wheel slot 2) 2–2 713 (wheel slot 3) 3–3 120 (wheel slot 4) 4–4 363 (wheel slot 5) 5–5 085 (wheel slot 6) 6–6 119 (wheel slot 7) 7–7 716 (wheel slot 8) 8–8 195 (wheel slot 9) 9–9 715 (wheel slot 10) 10–10 723 (wheel slot 11) 11–11 721 (wheel slot 12) 12–12 722 (wheel slot 13) 13–13 079 (wheel slot 14) 14–14 714 (wheel slot 15) 15–15 132 (wheel slot 16) 16–16 068 (wheel slot 17) 17–17 075 (wheel slot 18) 18–18 197 (wheel slot 19) 19–19 712 (wheel slot 20) 20–20 525 (wheel slot 21) 21–21 200 (wheel slot 22) 22–22 719 (wheel slot 23) 23–23 500 (wheel slot 24) 24–24 366 (wheel slot 25) 25–25 283 (wheel slot 26) 26–26 174 (wheel slot 27) 27–27 201 (wheel slot 28) 28–28 281 (wheel slot 29) 29–29 501 (wheel slot 30) 30–30 708 (wheel slot 31) 31–31 502 (wheel slot 32) 32–32 503 (wheel slot 33) 33–33 218 (wheel slot 34) 34–34 278 (wheel slot 35) 35–35 203 (wheel slot 36) 36–36 202 (wheel slot 37) 37–37 061 (wheel slot 38) 38–38 063 (wheel slot 39) 39–39 725 (wheel slot 40) 40–40 117 (wheel slot 41) 41–41 140 (wheel slot 42) 42–42 353 (wheel slot 43) 43–43 144 (wheel slot 44) 44–44 724 (wheel slot 45) 45–45 118 (wheel slot 46) 46–46 172 (wheel slot 47) 47–47 183 (wheel slot 48) 48–48 141 (wheel slot 49) 49–49 161 (wheel slot 50) 50–50 196 (wheel slot 51) 51–51 165 (wheel slot 52) 52–52 352 (wheel slot 53) 53–53 143 (wheel slot 54) 54–54 727 (wheel slot 55) 55–55 729 (wheel slot 56) 56–56 116 (wheel slot 57) 57–57 354 (wheel slot 58) 58–58 115 (wheel slot 59) 59–59 323 (wheel slot 60) 60–60 322 (wheel slot 61) 61–61 131 (wheel slot 62) 62–62 219 (wheel slot 63) 63–63 241 (wheel slot 64)

STUDIO (continued)

Ch	Function	Default	DMX values
21	C TC	129	
22	Tint	128	0–15 OFF 16–126 Minus Green 127–144 Zero Point 145–255 Plus Green
23	Intensity MSpeed	50	0–45 None 46–55 0ms 56–65 50ms 66–75 100ms 76–85 150ms 86–95 200ms 96–105 240ms 106–115 300ms 116–125 350ms 126–135 400ms 136–145 450ms 146–155 500ms 156–165 550ms 166–175 600ms 176–185 800ms 186–195 900ms 196–205 1000ms 206–215 1200ms 216–225 1400ms 226–235 1600ms 236–245 1800ms 246–255 2000ms
24	Fans	0	
25	Strobe Frequency	0	0–200 Strobe 201–230 Store 1 231–255 Store 2

STUDIO (continued)

Ch	Function	Default	DMX values
26	Control1	0	0–5 Inactive 6–11 Off 12–17 50ms 18–23 100ms 24–29 240ms 30–35 400ms 36–41 600ms 42–47 800ms 48–53 1000ms 54–59 1200ms 60–65 1600ms 66–71 2000ms 72–77 Linear 78–81 Quadratic 82–83 S Curve 84–85 Halo 86–87 Gamma 2:6 88–89 Gamma 2:8 90–95 600Hz 96–101 900Hz 102–107 1200Hz 108–113 2100Hz 114–119 4200Hz 120–125 6000Hz 126–131 10200Hz 132–137 15600Hz 138–143 19800Hz 144–149 ON 150–155 OFF 156–161 Auto 162–167 Standard 168–173 Silent 174–179 Standard 180–185 Rotated 186–191 Off 192–197 On 198–203 LED Calibration 204–209 Default Settings 210–255 FREE
27	No Feature	0	
28	No Feature	0	

THEATRE

29 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Dimmer Fine	0	Fine byte of Dimmer
3	Red	0	
4	Red Fine	0	Fine byte of Red
5	Green	0	
6	Green Fine	0	Fine byte of Green
7	Blue	0	
8	Blue Fine	0	Fine byte of Blue
9	Color Add RY	0	
10	Color Add RY Fine	0	Fine byte of Color Add RY
11	Color Add C	0	

THEATRE (continued)

Ch	Function	Default	DMX values
12	Color Add C Fine	0	Fine byte of Color Add C
13	Color Add GY	0	
14	Color Add GY Fine	0	Fine byte of Color Add GY
15	Color Add WW	255	
16	Color Add WW Fine	255	Fine byte of Color Add WW
17	Color Add CW	255	
18	Color Add CW Fine	255	Fine byte of Color Add CW

THEATRE (continued)

Ch	Function	Default	DMX values
19	Color Wheel	0	0–0 NONE (wheel slot 1) 1–1 R0384 (wheel slot 2) 2–2 R0383 (wheel slot 3) 3–3 R0385 (wheel slot 4) 4–4 R0085 (wheel slot 5) 5–5 R0079 (wheel slot 6) 6–6 R0080 (wheel slot 7) 7–7 R2006 (wheel slot 8) 8–8 R3220 (wheel slot 9) 9–9 R2007 (wheel slot 10) 10–10 R0084 (wheel slot 11) 11–11 R0078 (wheel slot 12) 12–12 R0081 (wheel slot 13) 13–13 R0068 (wheel slot 14) 14–14 R0368 (wheel slot 15) 15–15 R0069 (wheel slot 16) 16–16 R0065 (wheel slot 17) 17–17 R0067 (wheel slot 18) 18–18 R0367 (wheel slot 19) 19–19 R0064 (wheel slot 20) 20–20 R0375 (wheel slot 21) 21–21 R0370 (wheel slot 22) 22–22 R0366 (wheel slot 23) 23–23 R0369 (wheel slot 24) 24–24 R0072 (wheel slot 25) 25–25 R0062 (wheel slot 26) 26–26 R0063 (wheel slot 27) 27–27 R0060 (wheel slot 28) 28–28 R3206 (wheel slot 29) 29–29 R0372 (wheel slot 30) 30–30 R0373 (wheel slot 31) 31–31 R3208 (wheel slot 32) 32–32 R4315 (wheel slot 33) 33–33 R3216 (wheel slot 34) 34–34 R0053 (wheel slot 35) 35–35 R3204 (wheel slot 36) 36–36 R0360 (wheel slot 37) 37–37 R4215 (wheel slot 38) 38–38 R3203 (wheel slot 39) 39–39 R0362 (wheel slot 40) 40–40 R0371 (wheel slot 41) 41–41 R0364 (wheel slot 42) 42–42 R3202 (wheel slot 43) 43–43 R3218 (wheel slot 44) 44–44 R0365 (wheel slot 45) 45–45 R0061 (wheel slot 46) 46–46 R4330 (wheel slot 47) 47–47 R0363 (wheel slot 48) 48–48 R0066 (wheel slot 49) 49–49 R0070 (wheel slot 50) 50–50 R4360 (wheel slot 51) 51–51 R4390 (wheel slot 52) 52–52 R0073 (wheel slot 53) 53–53 R2005 (wheel slot 54) 54–54 R0374 (wheel slot 55) 55–55 R0093 (wheel slot 56) 56–56 R0392 (wheel slot 57) 57–57 R0095 (wheel slot 58) 58–58 R0395 (wheel slot 59) 59–59 R0076 (wheel slot 60) 60–60 R0077 (wheel slot 61) 61–61 R0075 (wheel slot 62) 62–62 R0376 (wheel slot 63) 63–63 R0071 (wheel slot 64)

THEATRE (continued)

Ch	Function	Default	DMX values
20	Color Wheel 2	0	0–0 NONE (wheel slot 1) 1–1 071 (wheel slot 2) 2–2 713 (wheel slot 3) 3–3 120 (wheel slot 4) 4–4 363 (wheel slot 5) 5–5 085 (wheel slot 6) 6–6 119 (wheel slot 7) 7–7 716 (wheel slot 8) 8–8 195 (wheel slot 9) 9–9 715 (wheel slot 10) 10–10 723 (wheel slot 11) 11–11 721 (wheel slot 12) 12–12 722 (wheel slot 13) 13–13 079 (wheel slot 14) 14–14 714 (wheel slot 15) 15–15 132 (wheel slot 16) 16–16 068 (wheel slot 17) 17–17 075 (wheel slot 18) 18–18 197 (wheel slot 19) 19–19 712 (wheel slot 20) 20–20 525 (wheel slot 21) 21–21 200 (wheel slot 22) 22–22 719 (wheel slot 23) 23–23 500 (wheel slot 24) 24–24 366 (wheel slot 25) 25–25 283 (wheel slot 26) 26–26 174 (wheel slot 27) 27–27 201 (wheel slot 28) 28–28 281 (wheel slot 29) 29–29 501 (wheel slot 30) 30–30 708 (wheel slot 31) 31–31 502 (wheel slot 32) 32–32 503 (wheel slot 33) 33–33 218 (wheel slot 34) 34–34 278 (wheel slot 35) 35–35 203 (wheel slot 36) 36–36 202 (wheel slot 37) 37–37 061 (wheel slot 38) 38–38 063 (wheel slot 39) 39–39 725 (wheel slot 40) 40–40 117 (wheel slot 41) 41–41 140 (wheel slot 42) 42–42 353 (wheel slot 43) 43–43 144 (wheel slot 44) 44–44 724 (wheel slot 45) 45–45 118 (wheel slot 46) 46–46 172 (wheel slot 47) 47–47 183 (wheel slot 48) 48–48 141 (wheel slot 49) 49–49 161 (wheel slot 50) 50–50 196 (wheel slot 51) 51–51 165 (wheel slot 52) 52–52 352 (wheel slot 53) 53–53 143 (wheel slot 54) 54–54 727 (wheel slot 55) 55–55 729 (wheel slot 56) 56–56 116 (wheel slot 57) 57–57 354 (wheel slot 58) 58–58 115 (wheel slot 59) 59–59 323 (wheel slot 60) 60–60 322 (wheel slot 61) 61–61 131 (wheel slot 62) 62–62 219 (wheel slot 63) 63–63 241 (wheel slot 64)

THEATRE (continued)

Ch	Function	Default	DMX values
21	H SBSaturation	0	
22	C TC	129	
23	Tint	128	0–15 OFF 16–126 Minus Green 127–144 Zero Point 145–255 Plus Green
24	Intensity MSpeed	50	0–45 None 46–55 0ms 56–65 50ms 66–75 100ms 76–85 150ms 86–95 200ms 96–105 240ms 106–115 300ms 116–125 350ms 126–135 400ms 136–145 450ms 146–155 500ms 156–165 550ms 166–175 600ms 176–185 800ms 186–195 900ms 196–205 1000ms 206–215 1200ms 216–225 1400ms 226–235 1600ms 236–245 1800ms 246–255 2000ms
25	Fans	0	
26	Strobe Frequency	0	0–200 Strobe 201–230 Store 1 231–255 Store 2

THEATRE (continued)

Ch	Function	Default	DMX values
27	Control1	0	0–5 Inactive 6–11 Off 12–17 50ms 18–23 100ms 24–29 240ms 30–35 400ms 36–41 600ms 42–47 800ms 48–53 1000ms 54–59 1200ms 60–65 1600ms 66–71 2000ms 72–77 Linear 78–81 Quadratic 82–83 S Curve 84–85 Halo 86–87 Gamma 2:6 88–89 Gamma 2:8 90–95 600Hz 96–101 900Hz 102–107 1200Hz 108–113 2100Hz 114–119 4200Hz 120–125 6000Hz 126–131 10200Hz 132–137 15600Hz 138–143 19800Hz 144–149 ON 150–155 OFF 156–161 Auto 162–167 Standard 168–173 Silent 174–179 Standard 180–185 Rotated 186–191 Off 192–197 On 198–203 LED Calibration 204–209 Default Settings 210–255 FREE
28	No Feature	0	
29	No Feature	0	