Stage4

X-STROBE 3X



Manufacturer	**Stage4**
Type	**Strobe**
DMX modes	**3**
DMX footprint	**3, 4, 14 channels**
Beam angle	**25°**
Size (W × H × D)	**440 × 195 × 45 mm**
GDTF fixture type	**4DB9A317-F494-4A57-AFA1-A1…**

Controls

RGB colour mixing · Colour wheel · Effect speed · Dimmer

Safety-relevant functions

Built-in effect programmes

DMX modes

3ch	3 ch
5ch	4 ch
14ch	14 ch

3ch

3 channels

Ch	Function	Default	DMX values
1	Strobe Mode Strobe	0	
2	Strobe Duration	0	
3	Strobe Rate	0	

5ch

4 channels

Ch	Function	Default	DMX values
1	Strobe Mode Strobe	0	
2	Strobe Duration	0	
3	Strobe Rate	0	
4	Shutter1Strobe	0	0–5 No Func 6–41 Min 42–42 Max 43–84 Min 85–85 Max 86–127 Min 128–128 Max 129–170 Min 171–171 Max 172–213 Min 214–214 Max 215–254 Min 255–255 Max

14ch

14 channels

Ch	Function	Default	DMX values
1	Strobe Mode Strobe	0	
2	Strobe Duration	0	
3	Strobe Rate	0	
4	Shutter1Strobe	0	0–5 No Func 6–41 Min 42–42 Max 43–84 Min 85–85 Max 86–127 Min 128–128 Max 129–170 Min 171–171 Max 172–213 Min 214–214 Max 215–254 Min 255–255 Max
5	L EDFrequency	0	0–50 No Func 51–101 4000Hz 102–152 8000Hz 153–203 15KHz 204–255 20KHz
6	Effect	0	
7	Effect Speed	0	
8	Intensity MSpeed	0	0–50 No Func 51–101 Fast Dim 102–255 Smooth Dim

14ch (continued)

Ch	Function	Default	DMX values
9	Shutter1Strobe	0	0–19 Close 20–49 Open 50–199 Min 200–200 Max 201–210 Open 211–254 Min 255–255 Max
10	Dimmer	0	0–254 Closed 255–255 Open
11	Red	0	
12	Green	0	
13	Blue	0	
14	Color Macro1	0	0–189 Open 190–190 Color 36 191–242 Min 243–243 Max 244–254 Fast 255–255 Slow