stagetronix

HYPNOS PIXEL STROBE BAR



Manufacturer	**stagetronix**
Type	**Strobe**
DMX modes	**1**
DMX footprint	**19 channels**
Beam angle	**16°**
Heads / cells	**2**
Size (W × H × D)	**900 × 70 × 135 mm**
GDTF fixture type	**ABF956D7-89BF-4207-B1B6-E7…**

Controls

Extra LED colours · Colour wheel · Effect speed · Strobe · Dimmer · Pixel control

Safety-relevant functions

Fixture reset · Built-in effect programmes

DMX modes

1 Advanced — 19 ch

1 Advanced

19 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–5 No Function 6–255 Min > Max
2	Shutter / Strobe	0	0–9 Open - Shutter Open 10–254 Slow 255–255 High
3	Shutter / Strobe 2	0	0–19 No Function 20–254 W Strobe · Slow 255–255 W Strobe · Fast
4	Shutter / Strobe 3	0	0–254 Slow 255–255 High
5	Red	255	
6	Green	255	
7	Blue	255	
8	White	255	
9	Color Add RY	0	
10	Effect	0	0–10 No Function 11–25 Effect 1 26–40 Effect 2 41–55 Effect 3 56–70 Effect 4 71–85 Effect 5 86–100 Effect 6 101–115 Effect 7 116–130 Effect 8 131–145 Effect 9 146–160 Effect 10 161–255 Effect 11
11	Effect Speed	0	0–127 Forward Flow F>S 128–255 Backward Flow S>F
12	Effect 2	0	0–10 No Function 11–25 Effect 1 26–40 Effect 2 41–55 Effect 3 56–70 Effect 4 71–85 Effect 5 86–100 Effect 6 101–115 Effect 7 116–130 Effect 8 131–145 Effect 9 146–160 Effect 10 161–255 Effect 11
13	Effect Speed 2	0	0–127 Forward Flow F>S 128–255 Backward Flow S>F
14	Color Control	0	0–63 Up and Down 64–127 Up Part 128–255 Down Part

1 Advanced (continued)

Ch	Function	Default	DMX values
15	Effect 3	0	0–10 No Function 11–25 Effect 1 26–40 Effect 2 41–55 Effect 3 56–70 Effect 4 71–85 Effect 5 86–100 Effect 6 101–115 Effect 7 116–130 Effect 8 131–145 Effect 9 146–160 Effect 10 161–255 Effect 11
16	Effect Speed 3	0	0–127 Forward Flow F>S 128–255 Backward Flow S>F
17	Dimmer	0	
18	Color Wheel	0	
19	Fixture Global Reset	0	0–127 No Function 128–255 Reset