V-Show

S718 Elf



Manufacturer	**V-Show**
Type	**Moving head**
DMX modes	**1**
DMX footprint	**17 channels**
Beam angle	**8-48°**
Pan range	**540°**
Tilt range	**270°**
Size (W × H × D)	**180 × 240 × 160 mm**
GDTF fixture type	**825F900F-0A6E-4BEA-8707-DE…**

Controls

Focus · Frost · Prism · Prism rotation · Zoom · Colour wheel · Strobe · Dimmer · Pan and tilt · Movement speed · Gobos · Gobo rotation

Safety-relevant functions

Fixture reset

DMX modes

Mode 1 - Standard 16 bit — 17 ch

Mode 1 - Standard 16 bit

17 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Pan Fine	0	Fine byte of Pan
3	Tilt	128	
4	Tilt Fine	0	Fine byte of Tilt
5	Position MSpeed	0	0–0 Standard mode 1–254 max 255–255 min
6	Dimmer	0	0–254 Closed 255–255 Open
7	Shutter / Strobe	32	0–31 Closed 32–63 Open 64–94 Strobe · Slow to fast 1/12 0.3–19.4 Hz 95–95 Strobe · Slow to fast 12/12 20 Hz 96–127 open 128–140 StrobePulseOpen · Slow to fast 1/7 0.1–0.42 Hz 141–143 StrobePulseOpen · Slow to fast 7/7 0.447–0.5 Hz 144–155 StrobePulseClose · Fast to slow 1/7 0.5–0.207 Hz 156–159 StrobePulseClose · Fast to slow 7/7 0.18–0.1 Hz 160–191 open 192–223 Random strobe from slow to fast 224–255 open
8	Color Wheel	0	0–15 Open/white - continual (wheel slot 1) 16–31 Red (wheel slot 2) 32–47 Green (wheel slot 4) 48–63 Blue (wheel slot 3) 64–79 Yellow (wheel slot 5) 80–95 Orange (wheel slot 6) 96–111 Magenta (wheel slot 7) 112–127 Zyan (wheel slot 8) 128–191 Fast to slow Reverse 192–255 Slow to fast Forward
9	Gobo	0	0–7 Open/hole (wheel slot 1) 8–15 Gobo 1 (wheel slot 2) 16–23 Gobo 2 (wheel slot 3) 24–31 Gobo 3 (wheel slot 4) 32–39 Gobo 4 (wheel slot 5) 40–47 Gobo 5 (wheel slot 6) 48–55 Gobo 6 (wheel slot 7) 56–63 Gobo 7 (wheel slot 8) 64–71 Open (wheel slot 1) 72–79 Gobo 1 - Shaking Index (wheel slot 2) 80–87 Gobo 2 - Shaking Index (wheel slot 3) 88–95 Gobo 3 - Shaking Index (wheel slot 4) 96–103 Gobo 4 - Shaking Index (wheel slot 5) 104–111 Gobo 5 - Shaking Index (wheel slot 6) 112–119 Gobo 6 - Shaking Index (wheel slot 7) 120–127 Gobo 7 - Shaking Index (wheel slot 8) 128–191 Forward Fast to Slow 192–255 Reverse Slow to Fast

Mode 1 - Standard 16 bit (continued)

Ch	Function	Default	DMX values
10	Gobo 2	0	0–9 Open/hole (wheel slot 1) 10–19 Gobo 1 (wheel slot 2) 20–29 Gobo 2 (wheel slot 3) 30–39 Gobo 3 (wheel slot 4) 40–49 Gobo 4 (wheel slot 5) 50–59 Gobo 5 (wheel slot 6) 60–69 Gobo 6 (wheel slot 7) 70–79 Gobo 1 - Shaking Index (wheel slot 2) 80–89 Gobo 2 - Shaking Index (wheel slot 3) 90–99 Gobo 3 - Shaking Index (wheel slot 4) 100–109 Gobo 4 - Shaking Index (wheel slot 5) 110–119 Gobo 5 - Shaking Index (wheel slot 6) 120–129 Gobo 6 - Shaking Index (wheel slot 7) 130–192 Forward Fast to Slow 193–255 Reverse Slow to Fast
11	Gobo Rotation 2	0	0–127 Angle Adjustment 128–191 Forward Rotation 192–255 Revers Rotation
12	Frost1	0	0–127 Open 128–255 100% Frost (Snap)
13	Prism	0	0–127 Open position (hole) (wheel slot 1) 128–255 Prism In (snap) (wheel slot 2)
14	Prism Rotation	128	0–127 Agle Adjustment 128–191 Forwarde 192–255 Reverse
15	Focus	128	
16	Zoom	0	
17	Position Reset	0	0–127 No Reset 128–255 Reset All Motors