V-Show

T911 Pioneer



Manufacturer	**V-Show**
Type	**Moving head**
DMX modes	**1**
DMX footprint	**18 channels**
Beam angle	**2°**
Pan range	**540°**
Tilt range	**270°**
Size (W × H × D)	**226 × 404 × 226 mm**
GDTF fixture type	**E812D213-DA4B-4A5F-917F-86…**

Controls

Focus · Frost · Prism · Prism rotation · Colour wheel · Strobe · Dimmer · Pan and tilt · Movement speed · Gobos

Safety-relevant functions

Lamp on and off · Fixture reset · Strobe

DMX modes

18CH — 18 ch

18CH

18 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Pan Fine	0	Fine byte of Pan
3	Tilt	128	
4	Tilt Fine	0	Fine byte of Tilt
5	Position MSpeed	0	
6	Dimmer	0	
7	Shutter / Strobe	160	0–32 Closed 33–63 Open 2 64–95 Strobe 96–127 Open 128–159 Pulse Close 160–191 Open 192–223 Strobe Random 224–255 Open 1
8	Color Wheel	0	0–8 White (wheel slot 1) 9–17 Red (wheel slot 2) 18–25 Yellow (wheel slot 3) 26–34 Blue (wheel slot 4) 35–42 Light Green (wheel slot 5) 43–51 Rose Red (wheel slot 6) 52–59 Dark Green (wheel slot 7) 60–68 Pink (wheel slot 8) 69–73 Cyan (wheel slot 9) 74–81 Purple (wheel slot 10) 82–85 Orange Red (wheel slot 11) 86–93 Dark Yellow (wheel slot 12) 94–110 CTO (wheel slot 13) 111–119 CTB (wheel slot 14) 120–127 Orange (wheel slot 15) 128–255 Color1WheelSpin 2

18CH (continued)

Ch	Function	Default	DMX values
9	Gobo	0	0–3 White (wheel slot 1) 4–6 Gobo 1 (wheel slot 2) 7–9 Gobo 2 (wheel slot 3) 10–12 Gobo 3 (wheel slot 4) 13–15 Gobo 4 (wheel slot 5) 16–18 Gobo 5 (wheel slot 6) 19–21 Gobo 6 (wheel slot 7) 22–24 Gobo 7 (wheel slot 8) 25–27 Gobo 8 (wheel slot 9) 28–30 Gobo 9 (wheel slot 10) 31–33 Gobo 10 (wheel slot 11) 34–36 Gobo 11 (wheel slot 12) 37–39 Gobo 12 (wheel slot 13) 40–42 Gobo 13 (wheel slot 14) 43–45 Gobo 14 (wheel slot 15) 46–48 Gobo 15 (wheel slot 16) 49–54 Gobo 16 (wheel slot 17) 55–62 Gobo 1 Shake (wheel slot 2) 63–70 Gobo 2 Shake (wheel slot 3) 71–78 Gobo 3 Shake (wheel slot 4) 79–86 Gobo 4 Shake (wheel slot 5) 87–94 Gobo 5 Shake (wheel slot 6) 95–102 Gobo 6 Shake (wheel slot 7) 103–110 Gobo 7 Shake (wheel slot 8) 111–118 Gobo 8 Shake (wheel slot 9) 119–126 Gobo 9 Shake (wheel slot 10) 127–134 Gobo 10 Shake (wheel slot 11) 135–142 Gobo 11 Shake (wheel slot 12) 143–150 Gobo 12 Shake (wheel slot 13) 151–159 Gobo 13 Shake (wheel slot 14) 160–166 Gobo 14 Shake (wheel slot 15) 167–174 Gobo 15 Shake (wheel slot 16) 175–190 Gobo 16 Shake (wheel slot 17) 191–201 Open (wheel slot 18) 202–227 Gobo Scroll (wheel slot 19) 228–229 Scroll Stop 230–255 Reverse Scroll
10	Frost1	0	0–19 White 20–137 Frost 138–255 Colorfull
11	Prism	0	0–127 Open (wheel slot 1) 128–255 Prism 1 (wheel slot 2)
12	Prism Rotation	0	0–127 Prism Index 128–190 >> 191–192 Stop 193–255 <<
13	Prism	0	0–127 Open 128–255 Prism 2
14	Focus	127	
15	No Feature	0	
16	No Feature	0	
17	Control1	0	0–25 Empty Channel Set 26–76 FX Reset 77–127 X/Y Reset 128–255 Reset ALL
18	Lamp Control	0	0–25 No function 26–100 Lamp ON 101–255 Lamp OFF