ACME

ACME CHAMPAGNE (AM1 CW)



Manufacturer	**ACME**
Type	**Moving head**
DMX modes	**3**
DMX footprint	**7, 9, 10 channels**
Beam angle	**10-40°**
Pan range	**540°**
Tilt range	**200°**
Size (W × H × D)	**192 × 271 × 192 mm**
GDTF fixture type	**58AFF61C-6380-4A68-BEB2-FC…**

Controls

Zoom · Strobe · Dimmer · Pan and tilt

Safety-relevant functions

Fixture reset · Strobe

DMX modes

Mode 1 7 DMX	7 ch
Mode 2 9 DMX	9 ch
Mode 3 10 DMX	10 ch

Mode 1 7 DMX

7 channels

Ch	Function	Default	DMX values
1	Pan	127	
2	Tilt	128	
3	P TSpeed	0	
4	Zoom	128	
5	Dimmer	0	
6	Dimmer Fine	0	Fine byte of Dimmer
7	Function	0	0–69 No Feature 1 70–79 Black out Pan Tilt Move Enable 80–89 Black out Pan Tilt Move Disable 90–139 No Feature 2 140–149 PT Reset 150–169 No Feature 2 170–179 Zoom Reset 180–199 No Feature 4 200–209 All Reset 218–255 No Feature 5

Mode 2 9 DMX

9 channels

Ch	Function	Default	DMX values
1	Pan	127	
2	Pan Fine	255	Fine byte of Pan
3	Tilt	128	
4	Tilt Fine	0	Fine byte of Tilt
5	P TSpeed	0	
6	Zoom	128	
7	Dimmer	0	
8	Dimmer Fine	0	Fine byte of Dimmer
9	Function	0	0–69 No Feature 1 70–79 Black out Pan Tilt Move Enable 80–89 Black out Pan Tilt Move Disable 90–139 No Feature 2 140–149 PT Reset 150–169 No Feature 2 170–179 Zoom Reset 180–199 No Feature 4 200–209 All Reset 218–255 No Feature 5

Mode 3 10 DMX

10 channels

Ch	Function	Default	DMX values
1	Pan	127	
2	Pan Fine	255	Fine byte of Pan
3	Tilt	128	
4	Tilt Fine	0	Fine byte of Tilt
5	P TSpeed	0	
6	Zoom	128	
7	Dimmer	0	
8	Dimmer Fine	0	Fine byte of Dimmer

Mode 3 10 DMX (continued)

Ch	Function	Default	DMX values
9	Shutter / Strobe	32	0–31 Closed 32–63 Open 64–94 min Strobe 95–95 max Strobe 96–127 Open 2 128–158 max Pulse Open 159–159 min Pulse Open 160–191 Open 3 192–223 Strobe Ran 224–255 Open 4
10	Function	0	0–69 No Feature 1 70–79 Black out Pan Tilt Move Enable 80–89 Black out Pan Tilt Move Disable 90–139 No Feature 2 140–149 PT Reset 150–169 No Feature 2 170–179 Zoom Reset 180–199 No Feature 4 200–209 All Reset 218–255 No Feature 5