ACME

ACME (FACE 600)



Manufacturer	**ACME**
Type	**Profile spot**
DMX modes	**2**
DMX footprint	**23, 28 channels**
Beam angle	**10-30°**
Pan range	**540°**
Tilt range	**270°**
Size (W × H × D)	**240 × 485 × 220 mm**
GDTF fixture type	**50C66EF5-A4FB-407E-AC6A-64…**

Controls

Focus · Frost · Iris · Zoom · CMY colour mixing · Colour temperature · Strobe · Dimmer · Pan and tilt

Safety-relevant functions

Fixture reset · Strobe

DMX modes

Mode 2 23 DMX	23 ch
Mode 1 28 DMX	28 ch

Mode 2 23 DMX

23 channels

Ch	Function	Default	DMX values
1	Pan	127	
2	Tilt	127	
3	P TSpeed	0	
4	Cyan	0	
5	Magenta	0	
6	Yellow	0	
7	C TO	0	
8	Iris	0	
9	Frost1	0	
10	Zoom	127	
11	Focus	127	
12	Shutter / Strobe	8	0–7 Closed 8–15 Open 16–130 min Strobe 131–131 max Strobe 132–139 Open 2 140–180 min Pulse Open 181–181 max Pulse Open 182–189 Open 3 190–230 min Pulse Close 231–231 max Pulse Close 232–239 Open 4 240–247 Strobe Ran 248–255 Open 5
13	Dimmer	0	
14	Shaper Rot	127	
15	Blade1B	0	
16	Blade1A	0	
17	Blade3A	0	
18	Blade3B	0	
19	Blade2A	0	
20	Blade2B	0	
21	Blade4A	0	
22	Blade4B	0	

Mode 2 23 DMX (continued)

Ch	Function	Default	DMX values
23	Function	0	0–9 No Feature 1 10–19 Blade Mode 1 20–29 Blade Mode 2 30–39 Dim Square Law 40–49 Dim Inv Square Law 50–59 Dim Curve Line 60–69 Dim Curve S 70–79 Standard 80–89 Quiet 90–99 Compatible 100–109 Frequency Setting 110–119 Frequency Disable 120–121 900HZ 122–123 1000HZ 124–125 1100HZ 126–127 1200HZ 128–129 1300HZ 130–131 1400HZ 132–133 1500HZ 134–135 2500HZ 136–137 4000HZ 138–139 5000HZ 140–141 6000HZ 142–143 10K 144–145 15K 146–147 20K 148–149 25K 150–179 NoFeature 2 180–189 Dimmer Fast 190–199 Dim Smooth 200–209 All Reset 210–219 Eff Reset 220–229 PT Reset 230–239 NoFeature 3 240–245 CCI On 246–251 CCI Off 252–255 NoFeature 4

Mode 1 28 DMX

28 channels

Ch	Function	Default	DMX values
1	Pan	127	
2	Pan Fine	255	Fine byte of Pan
3	Tilt	127	
4	Tilt Fine	255	Fine byte of Tilt
5	P TSpeed	0	
6	Cyan	0	
7	Magenta	0	
8	Yellow	0	
9	C TO	0	
10	Iris	0	
11	Frost1	0	
12	Zoom	127	
13	Zoom Fine	255	Fine byte of Zoom
14	Focus	127	
15	Focus Fine	255	Fine byte of Focus

Mode 1 28 DMX (continued)

Ch	Function	Default	DMX values
16	Shutter / Strobe	8	0–7 Closed 8–15 Open 16–130 min Strobe 131–131 max Strobe 132–139 Open 2 140–180 min Pulse Open 181–181 max Pulse Open 182–189 Open 3 190–230 min Pulse Close 231–231 max Pulse Close 232–239 Open 4 240–247 Strobe Ran 248–255 Open 5
17	Dimmer	0	
18	Dimmer Fine	0	Fine byte of Dimmer
19	Shaper Rot	127	
20	Blade1B	0	
21	Blade1A	0	
22	Blade3A	0	
23	Blade3B	0	
24	Blade2A	0	
25	Blade2B	0	
26	Blade4A	0	
27	Blade4B	0	

Mode 1 28 DMX (continued)

Ch	Function	Default	DMX values
28	Function	0	0–9 No Feature 1 10–19 Blade Mode 1 20–29 Blade Mode 2 30–39 Dim Square Law 40–49 Dim Inv Square Law 50–59 Dim Curve Line 60–69 Dim Curve S 70–79 Standard 80–89 Quiet 90–99 Compatible 100–109 Frequency Setting 110–119 Frequency Disable 120–121 900HZ 122–123 1000HZ 124–125 1100HZ 126–127 1200HZ 128–129 1300HZ 130–131 1400HZ 132–133 1500HZ 134–135 2500HZ 136–137 4000HZ 138–139 5000HZ 140–141 6000HZ 142–143 10K 144–145 15K 146–147 20K 148–149 25K 150–179 NoFeature 2 180–189 Dimmer Fast 190–199 Dim Smooth 200–209 All Reset 210–219 Eff Reset 220–229 PT Reset 230–239 NoFeature 3 240–245 CCI On 246–251 CCI Off 252–255 NoFeature 4