ACME

ACME FLANDINA 18 (BAR 18)



Manufacturer	**ACME**
Type	**PAR**
DMX modes	**5**
DMX footprint	**4, 8, 10, 11, 16 channels**
Beam angle	**25°**
Heads / cells	**3**
Size (W × H × D)	**1000 × 35 × 60 mm**
GDTF fixture type	**4F38A67E-2FF0-456E-B267-52C…**

Controls

Extra LED colours · RGB colour mixing · Colour temperature · Colour wheel · Strobe · Dimmer · Pixel control

Safety-relevant functions

Strobe

DMX modes

Mode 5 4 DMX	4 ch
Mode 4 8 DMX	8 ch
Mode 3 10 DMX	10 ch
Mode 2 11 DMX	11 ch
Mode 1 16 DMX	16 ch

Mode 5 4 DMX

4 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	White	0	

Mode 4 8 DMX

8 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Red Fine	255	Fine byte of Red
3	Green	255	
4	Green Fine	255	Fine byte of Green
5	Blue	255	
6	Blue Fine	255	Fine byte of Blue
7	White	0	
8	White Fine	0	Fine byte of White

Mode 3 10 DMX

10 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	White	0	
5	C TO	0	

Mode 3 10 DMX (continued)

Ch	Function	Default	DMX values
6	Color Wheel	0	0–13 Open 14–14 Color 1 15–19 Color 2 20–24 Color 3 25–29 Color 4 30–34 Color 5 35–39 Color 6 40–44 Color 7 45–49 Color 8 50–54 Color 9 55–59 Color 10 60–64 Color 11 65–69 Color 12 70–74 Color 13 75–79 Color 14 80–84 Color 15 85–89 Color 16 90–94 Color 17 95–99 Color 18 100–104 Color 19 105–109 Color 20 110–114 Color 21 115–119 Color 22 120–124 Color 23 125–129 Color 24 130–134 Color 25 135–139 Color 26 140–144 Color 27 145–149 Color 28 150–154 Color 29 155–159 Color 30 160–164 Color 31 165–169 Color 32 170–174 Color 33 175–179 Open 2 180–189 >>> 190–200 >> 201–201 > 202–207 Stop1 208–217 < 218–228 << 229–229 <<< 230–234 Open 3 235–239 Fast 240–244 Medium 245–249 Slow 250–255 Open 4
7	Shutter / Strobe	12	0–7 OFF 8–15 Open 16–130 min Strobe 131–131 max Strobe 132–139 Open 2 140–180 min Pulse Open 181–181 max Pulse Open 182–189 Open 3 190–230 min Pulse Close 231–231 max Pulse Close 232–239 Open 4 240–246 min Rnd Strobe 247–247 max Rnd Strobe 248–255 Open 5
8	Dimmer	0	

Mode 3 10 DMX (continued)

Ch	Function	Default	DMX values
9	Dimmer Fine	0	Fine byte of Dimmer
10	Control1	0	0–29 Null 30–39 Dim Line 40–49 Square Law 50–59 Inv SQ Law 60–69 S Curve 70–179 Null 2 180–189 Dim Fast 190–199 Dim Smooth 200–255 Null 3

Mode 2 11 DMX

11 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Red Fine	255	Fine byte of Red
3	Green	255	
4	Green Fine	255	Fine byte of Green
5	Blue	255	
6	Blue Fine	255	Fine byte of Blue
7	White	0	
8	White Fine	0	Fine byte of White
9	Shutter / Strobe	12	0–7 OFF 8–15 Open 16–130 min Strobe 131–131 max Strobe 132–139 Open 2 140–180 min Pulse Open 181–181 max Pulse Open 182–189 Open 3 190–230 min Pulse Close 231–231 max Pulse Close 232–239 Open 4 240–246 min Rnd Strobe 247–247 max Rnd Strobe 248–255 Open 5
10	Dimmer	0	
11	Dimmer Fine	0	Fine byte of Dimmer

Mode 1 16 DMX

16 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	White	0	
5	Red	255	
6	Green	255	
7	Blue	255	
8	White	0	
9	Red	255	
10	Green	255	

Mode 1 16 DMX (continued)

Ch	Function	Default	DMX values
11	Blue	255	
12	White	0	
13	Shutter / Strobe	12	0–7 OFF 8–15 Open 16–130 min Strobe 131–131 max Strobe 132–139 Open 2 140–180 min Pulse Open 181–181 max Pulse Open 182–189 Open 3 190–230 min Pulse Close 231–231 max Pulse Close 232–239 Open 4 240–246 min Rnd Strobe 247–247 max Rnd Strobe 248–255 Open 5
14	Dimmer	0	
15	Dimmer Fine	0	Fine byte of Dimmer
16	Control1	0	0–29 Null 30–39 Dim Line 40–49 Square Law 50–59 Inv SQ Law 60–69 S Curve 70–179 Null 2 180–189 Dim Fast 190–199 Dim Smooth 200–255 Null 3