ACME

ACME GINAMP (STROBE 2)CN



Manufacturer	**ACME**
Type	**Strobe**
DMX modes	**6**
DMX footprint	**3, 6, 13, 18, 36, 131 channels**
Beam angle	**25°**
Heads / cells	**8**
Size (W × H × D)	**410 × 55 × 210 mm**
GDTF fixture type	**46BBB187-FD94-4719-BA01-6F…**

Controls

Extra LED colours · RGB colour mixing · Colour wheel · Strobe · Dimmer · Pixel control

DMX modes

Mode 5 126DMX	3 ch
Mode 1 6DMX	6 ch
Mode 2 13DMX	13 ch
Mode 3 18DMX	18 ch
Mode 4 36DMX	36 ch
Mode 6 131DMX	131 ch

Mode 5 126DMX

3 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	

Mode 1 6DMX

6 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	White	255	
5	Dimmer	0	
6	Dimmer Fine	0	Fine byte of Dimmer

Mode 2 13DMX

13 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	White	255	
5	Color Wheel	0	0–9 Open (wheel slot 1) 10–17 Color 1 (wheel slot 2) 18–24 Color 2 (wheel slot 3) 25–32 Color 3 (wheel slot 4) 33–39 Color 4 (wheel slot 5) 40–47 Color 5 (wheel slot 6) 48–54 Color 6 (wheel slot 7) 55–61 Color 7 (wheel slot 8) 62–69 Color 8 (wheel slot 9) 70–76 Color 9 (wheel slot 10) 77–84 Color 10 (wheel slot 11) 85–91 Color 11 (wheel slot 12) 92–99 Color 12 (wheel slot 13) 100–106 Color 13 (wheel slot 14) 107–113 Color 14 (wheel slot 15) 114–121 Color 15 (wheel slot 16) 122–128 Color 16 (wheel slot 17) 129–136 Color 17 (wheel slot 18) 137–143 Color 18 (wheel slot 19) 144–151 Color 19 (wheel slot 20) 152–158 Color 20 (wheel slot 21) 159–165 Color 21 (wheel slot 22) 166–173 Color 22 (wheel slot 23) 174–180 Color 23 (wheel slot 24) 181–188 Color 24 (wheel slot 25) 189–195 Color 25 (wheel slot 26) 196–203 Color 26 (wheel slot 27) 204–210 Color 27 (wheel slot 28) 211–217 Color 28 (wheel slot 29) 218–225 Color 29 (wheel slot 30) 226–232 Color 30 (wheel slot 31) 233–240 Color 31 (wheel slot 32) 241–247 Color 32 (wheel slot 33) 248–255 Color 33 (wheel slot 34)

Mode 2 13DMX (continued)

Ch	Function	Default	DMX values
6	Dimmer	0	
7	Dimmer Fine	0	Fine byte of Dimmer
8	Strobe Duration	255	
9	Shutter / Strobe	255	0–6 Null 7–255 Shutter1Strobe · Shutter Frequency 1–15 Hz
10	Shutter1Strobe Effect	0	0–5 open 6–49 Pulse Open min 50–50 Pulse Open max 51–99 Pulse Close min 100–100 Pulse Close max 101–149 Pulse min 150–150 Pulse max 151–199 Lighting min 200–200 Lighting max 201–254 Random min 255–255 Random max
11	Color Macro1	0	0–21 Open 22–30 Macro 1 31–39 Macro 2 40–48 Macro 3 49–57 Macro 4 58–66 Macro 5 67–75 Macro 6 76–84 Macro 7 85–93 Macro 8 94–102 Macro 9 103–111 Macro 10 112–120 Macro 11 121–129 Macro 12 130–138 Macro 13 139–147 Macro 14 148–156 Macro 15 157–165 Macro 16 166–174 Macro 17 175–183 Macro 18 184–192 Macro 19 193–201 Macro 20 202–210 Macro 21 211–219 Macro 22 220–228 Macro 23 229–237 Macro 24 238–246 Macro 25 247–255 Macro 26
12	Color Macro2	0	0–90 Open 91–105 Macro 1 106–120 Macro 2 121–135 Macro 3 136–150 Macro 4 151–165 Macro 5 166–180 Macro 6 181–195 Macro 7 196–210 Macro 8 211–225 Macro 9 226–240 Macro 10 241–255 Macro 11
13	Color Mix MSpeed	255	

Mode 3 18DMX

18 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	Color Wheel	0	0–9 Open (wheel slot 1) 10–17 Color 1 (wheel slot 2) 18–24 Color 2 (wheel slot 3) 25–32 Color 3 (wheel slot 4) 33–39 Color 4 (wheel slot 5) 40–47 Color 5 (wheel slot 6) 48–54 Color 6 (wheel slot 7) 55–61 Color 7 (wheel slot 8) 62–69 Color 8 (wheel slot 9) 70–76 Color 9 (wheel slot 10) 77–84 Color 10 (wheel slot 11) 85–91 Color 11 (wheel slot 12) 92–99 Color 12 (wheel slot 13) 100–106 Color 13 (wheel slot 14) 107–113 Color 14 (wheel slot 15) 114–121 Color 15 (wheel slot 16) 122–128 Color 16 (wheel slot 17) 129–136 Color 17 (wheel slot 18) 137–143 Color 18 (wheel slot 19) 144–151 Color 19 (wheel slot 20) 152–158 Color 20 (wheel slot 21) 159–165 Color 21 (wheel slot 22) 166–173 Color 22 (wheel slot 23) 174–180 Color 23 (wheel slot 24) 181–188 Color 24 (wheel slot 25) 189–195 Color 25 (wheel slot 26) 196–203 Color 26 (wheel slot 27) 204–210 Color 27 (wheel slot 28) 211–217 Color 28 (wheel slot 29) 218–225 Color 29 (wheel slot 30) 226–232 Color 30 (wheel slot 31) 233–240 Color 31 (wheel slot 32) 241–247 Color 32 (wheel slot 33) 248–255 Color 33 (wheel slot 34)
5	Dimmer	0	
6	Dimmer Fine	0	Fine byte of Dimmer
7	Strobe Duration	255	
8	Shutter / Strobe	255	0–6 RGB NULL 7–255 StrobeFrequency1 · RGB Shutter Frequency 1–15 Hz
9	Shutter1Strobe Effect	0	0–5 RGB open 6–49 RGB Pulse Open min 50–50 RGB Pulse Open max 51–99 RGB Pulse Close min 100–100 RGB Pulse Close max 101–149 RGB Pulse min 150–150 RGB Pulse max 151–199 RGB Lighting min 200–200 RGB Lighting max 201–254 RGB Random min 255–255 RGB Random max

Mode 3 18DMX (continued)

Ch	Function	Default	DMX values
10	Color Macro1	0	0–5 Open 6–15 Macro 1 16–25 Macro 2 26–35 Macro 3 36–45 Macro 4 46–55 Macro 5 56–65 Macro 6 66–75 Macro 7 76–85 Macro 8 86–95 Macro 9 96–105 Macro 10 106–115 Macro 11 116–125 Macro 12 126–135 Macro 13 136–145 Macro 14 146–155 Macro 15 156–165 Macro 16 166–175 Macro 17 176–185 Macro 18 186–195 Macro 19 196–205 Macro 20 206–215 Macro 21 216–225 Macro 22 226–235 Macro 23 236–245 Macro 24 246–255 Macro 25
11	Color Macro1Rate	255	0–127 ColorMacro1Rate CW 128–255 ColorMacro1Rate CCW
12	Dimmer	0	
13	Dimmer Fine	0	Fine byte of Dimmer
14	Strobe Duration	255	
15	Shutter / Strobe	255	0–6 W NULL 7–255 StrobeFrequency2 · W Shutter Frequency 1–15 Hz
16	Shutter2Strobe Effect	0	0–5 W open 6–49 W Pulse Open min 50–50 W Pulse Open max 51–99 W Pulse Close min 100–100 W Pulse Close max 101–149 W Pulse min 150–150 W Pulse max 151–199 W Lighting min 200–200 W Lighting max 201–254 W Random min 255–255 W Random max
17	Color Macro2	0	0–5 Open 6–40 Macro 1 41–75 Macro 2 76–110 Macro 3 111–145 Macro 4 146–180 Macro 5 181–215 Macro 6 216–250 Macro 7 251–255 Macro 8
18	Color Macro2Rate	255	1–127 CW 128–255 CCW

Mode 4 36DMX

36 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	Red	255	
5	Green	255	
6	Blue	255	
7	Red	255	
8	Green	255	
9	Blue	255	
10	Red	255	
11	Green	255	
12	Blue	255	
13	Red	255	
14	Green	255	
15	Blue	255	
16	Red	255	
17	Green	255	
18	Blue	255	
19	Red	255	
20	Green	255	
21	Blue	255	
22	Red	255	
23	Green	255	
24	Blue	255	
25	Dimmer	0	
26	Dimmer Fine	0	Fine byte of Dimmer
27	Strobe Duration	255	
28	Shutter / Strobe	255	0–6 RGB NULL 7–255 StrobeFrequency1 · RGB Shutter Frequency 1–15 Hz
29	Shutter1Strobe Effect	0	0–5 RGB open 6–49 RGB Pulse Open min 50–50 RGB Pulse Open max 51–99 RGB PulseClose min 100–100 RGB PulseClose max 101–149 RGB Pulse min 150–150 RGB Pulse max 151–199 RGB Lighting min 200–200 RGB Lighting max 201–254 RGB Random min 255–255 RGB Random max
30	White	255	
31	White	255	
32	Dimmer	0	
33	Dimmer Fine	0	Fine byte of Dimmer
34	Strobe Duration	255	
35	Shutter / Strobe	255	0–6 W NULL 7–255 StrobeFrequency2 · W Shutter Frequency 1–15 Hz

Mode 4 36DMX (continued)

Ch	Function	Default	DMX values
36	Shutter1Strobe Effect	0	0–5 W open 6–49 W Pulse Open min 50–50 W Pulse Open max 51–99 W Pulse Close min 100–100 W Pulse Close max 101–149 W Pulse min 150–150 W Pulse max 151–199 W Lighting min 200–200 W Lighting max 201–254 W Random min 255–255 W Random max

Mode 6 131DMX

131 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	Reserved 4	0	
5	Reserved 5	0	
6	Reserved 6	0	
7	Reserved 7	0	
8	Reserved 8	0	
9	Reserved 9	0	
10	Reserved 10	0	
11	Reserved 11	0	
12	Reserved 12	0	
13	Reserved 13	0	
14	Reserved 14	0	
15	Reserved 15	0	
16	Reserved 16	0	
17	Reserved 17	0	
18	Reserved 18	0	
19	Reserved 19	0	
20	Reserved 20	0	
21	Reserved 21	0	
22	Reserved 22	0	
23	Reserved 23	0	
24	Reserved 24	0	
25	Reserved 25	0	
26	Reserved 26	0	
27	Reserved 27	0	
28	Reserved 28	0	
29	Reserved 29	0	
30	Reserved 30	0	
31	Reserved 31	0	
32	Reserved 32	0	
33	Reserved 33	0	

Mode 6 131DMX (continued)

Ch	Function	Default	DMX values
34	Reserved 34	0	
35	Reserved 35	0	
36	Reserved 36	0	
37	Reserved 37	0	
38	Reserved 38	0	
39	Reserved 39	0	
40	Reserved 40	0	
41	Reserved 41	0	
42	Reserved 42	0	
43	Reserved 43	0	
44	Reserved 44	0	
45	Reserved 45	0	
46	Reserved 46	0	
47	Reserved 47	0	
48	Reserved 48	0	
49	Reserved 49	0	
50	Reserved 50	0	
51	Reserved 51	0	
52	Reserved 52	0	
53	Reserved 53	0	
54	Reserved 54	0	
55	Reserved 55	0	
56	Reserved 56	0	
57	Reserved 57	0	
58	Reserved 58	0	
59	Reserved 59	0	
60	Reserved 60	0	
61	Reserved 61	0	
62	Reserved 62	0	
63	Reserved 63	0	
64	Reserved 64	0	
65	Reserved 65	0	
66	Reserved 66	0	
67	Reserved 67	0	
68	Reserved 68	0	
69	Reserved 69	0	
70	Reserved 70	0	
71	Reserved 71	0	
72	Reserved 72	0	
73	Reserved 73	0	
74	Reserved 74	0	
75	Reserved 75	0	
76	Reserved 76	0	
77	Reserved 77	0	
78	Reserved 78	0	

Mode 6 131DMX (continued)

Ch	Function	Default	DMX values
79	Reserved 79	0	
80	Reserved 80	0	
81	Reserved 81	0	
82	Reserved 82	0	
83	Reserved 83	0	
84	Reserved 84	0	
85	Reserved 85	0	
86	Reserved 86	0	
87	Reserved 87	0	
88	Reserved 88	0	
89	Reserved 89	0	
90	Reserved 90	0	
91	Reserved 91	0	
92	Reserved 92	0	
93	Reserved 93	0	
94	Reserved 94	0	
95	Reserved 95	0	
96	Reserved 96	0	
97	Reserved 97	0	
98	Reserved 98	0	
99	Reserved 99	0	
100	Reserved 100	0	
101	Reserved 101	0	
102	Reserved 102	0	
103	Reserved 103	0	
104	Reserved 104	0	
105	Reserved 105	0	
106	Reserved 106	0	
107	Reserved 107	0	
108	Reserved 108	0	
109	Reserved 109	0	
110	Reserved 110	0	
111	Reserved 111	0	
112	Reserved 112	0	
113	Reserved 113	0	
114	Reserved 114	0	
115	Reserved 115	0	
116	Reserved 116	0	
117	Reserved 117	0	
118	Reserved 118	0	
119	Reserved 119	0	
120	Reserved 120	0	
121	Reserved 121	0	
122	Reserved 122	0	
123	Reserved 123	0	

Mode 6 131DMX (continued)

Ch	Function	Default	DMX values
124	Reserved 124	0	
125	Reserved 125	0	
126	Reserved 126	0	
127	Dimmer	0	
128	Dimmer Fine	0	Fine byte of Dimmer
129	Strobe Duration	255	
130	Strobe Frequency	255	
131	Shutter1Strobe Effect	0	