ADJ

Encore LB15IP



Manufacturer	**ADJ**
Type	**Effect light**
DMX modes	**10**
DMX footprint	**4, 7, 8, 13, 16, 63, 69, 72 channels**
Beam angle	**13°**
Size (W × H × D)	**730 × 100 × 150 mm**
GDTF fixture type	**D91273EB-DC07-4B93-A73E-24…**

Controls

Extra LED colours · RGB colour mixing · Colour temperature · Colour wheel · Effect speed · Strobe · Dimmer · Pixel control

Safety-relevant functions

Strobe · Built-in effect programmes

DMX modes

4CH	4 ch
60CH	4 ch
7CH	7 ch
120CH	8 ch
8CH	8 ch
13CH	13 ch
16CH	16 ch
63CH	63 ch
69CH	69 ch
72CH	72 ch

4CH

4 channels

Ch	Function	Default	DMX values
1	Red	0	0–254 Red Min 255–255 Red Max
2	Green	0	0–254 Green Min 255–255 Green Max
3	Blue	0	0–254 Blue Min 255–255 Blue Max
4	Color Add GY	0	0–254 Lime Min 255–255 Lime Max

60CH

4 channels

Ch	Function	Default	DMX values
1	Red	255	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
2	Green	255	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
3	Blue	255	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
4	Color Add GY	255	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %

7CH

7 channels

Ch	Function	Default	DMX values
1	Red	0	0–254 Red Min 255–255 Red Max
2	Green	0	0–254 Green Min 255–255 Green Max
3	Blue	0	0–254 Blue Min 255–255 Blue Max
4	Color Add GY	0	0–254 Lime Min 255–255 Lime Max
5	Shutter / Strobe	50	0–31 Shutter Closed 32–63 No Function (Shutter Open) 64–95 Strobe Effect Slow to Fast 96–127 No Function (Shutter Open) 128–159 Pulse-Effect in Sequences 160–191 No Function (Shutter Open) 192–223 Random Strobe Effect Slow to Fast 224–255 No Function (Shutter Open)

7CH (continued)

Ch	Function	Default	DMX values
6	Dimmer	0	0–62 0 percent 63–126 25 percent 127–190 50 percent 191–254 75 percent 255–255 100 percent
7	Dimmer Fine	0	Fine byte of Dimmer

120CH

8 channels

Ch	Function	Default	DMX values
1	Red	255	0–63 0 % 64–127 25 % 128–190 50 % 191–254 75 % 255–255 100 %
2	Red Fine	255	Fine byte of Red
3	Green	255	0–63 0 % 64–127 25 % 128–190 50 % 191–254 75 % 255–255 100 %
4	Green Fine	255	Fine byte of Green
5	Blue	255	0–63 0 % 64–127 25 % 128–190 50 % 191–254 75 % 255–255 100 %
6	Blue Fine	255	Fine byte of Blue
7	Color Add GY	255	0–63 0 % 64–127 25 % 128–190 50 % 191–254 75 % 255–255 100 %
8	Color Add GY Fine	255	Fine byte of Color Add GY

8CH

8 channels

Ch	Function	Default	DMX values
1	Red	0	0–254 Red Min 255–255 Red Max
2	Red Fine	0	Fine byte of Red
3	Green	0	0–254 Green Min 255–255 Green Max
4	Green Fine	0	Fine byte of Green
5	Blue	0	0–254 Blue Min 255–255 Blue Max
6	Blue Fine	0	Fine byte of Blue
7	Color Add GY	0	0–254 Lime Min 255–255 Lime Max
8	Color Add GY Fine	0	Fine byte of Color Add GY

13CH

13 channels

Ch	Function	Default	DMX values
1	Red	255	0–254 Red Min 255–255 Red Max
2	Green	255	0–254 Green Min 255–255 Green Max
3	Blue	255	0–254 Blue Min 255–255 Blue Max
4	Color Add GY	255	0–254 Lime Min 255–255 Lime Max

13CH (continued)

Ch	Function	Default	DMX values
5	Color Wheel	0	0–0 Off (wheel slot 1) 1–4 Color Macro 1 (wheel slot 2) 5–8 Color Macro 2 (wheel slot 3) 9–12 Color Macro 3 (wheel slot 4) 13–16 Color Macro 4 (wheel slot 5) 17–20 Color Macro 5 (wheel slot 6) 21–24 Color Macro 6 (wheel slot 7) 25–28 Color Macro 7 (wheel slot 8) 29–32 Color Macro 8 (wheel slot 9) 33–36 Color Macro 9 (wheel slot 10) 37–40 Color Macro 10 (wheel slot 11) 41–44 Color Macro 11 (wheel slot 12) 45–48 Color Macro 12 (wheel slot 13) 49–52 Color Macro 13 (wheel slot 14) 53–56 Color Macro 14 (wheel slot 15) 57–60 Color Macro 15 (wheel slot 16) 61–64 Color Macro 16 (wheel slot 17) 65–68 Color Macro 17 (wheel slot 18) 69–72 Color Macro 18 (wheel slot 19) 73–76 Color Macro 19 (wheel slot 20) 77–80 Color Macro 20 (wheel slot 21) 81–84 Color Macro 21 (wheel slot 22) 85–88 Color Macro 22 (wheel slot 23) 89–92 Color Macro 23 (wheel slot 24) 93–96 Color Macro 24 (wheel slot 25) 97–100 Color Macro 25 (wheel slot 26) 101–104 Color Macro 26 (wheel slot 27) 105–108 Color Macro 27 (wheel slot 28) 109–112 Color Macro 28 (wheel slot 29) 113–116 Color Macro 29 (wheel slot 30) 117–120 Color Macro 30 (wheel slot 31) 121–127 Color Macro 31 (wheel slot 32) 128–128 Color Macro 32 (wheel slot 33) 129–132 Color Macro 33 (wheel slot 34) 133–136 Color Macro 34 (wheel slot 35) 137–140 Color Macro 35 (wheel slot 36) 141–144 Color Macro 36 (wheel slot 37) 145–148 Color Macro 37 (wheel slot 38) 149–152 Color Macro 38 (wheel slot 39) 153–156 Color Macro 39 (wheel slot 40) 157–160 Color Macro 40 (wheel slot 41) 161–164 Color Macro 41 (wheel slot 42) 165–168 Color Macro 42 (wheel slot 43) 169–172 Color Macro 43 (wheel slot 44) 173–176 Color Macro 44 (wheel slot 45) 177–180 Color Macro 45 (wheel slot 46) 181–184 Color Macro 46 (wheel slot 47) 185–188 Color Macro 47 (wheel slot 48) 189–192 Color Macro 48 (wheel slot 49) 193–196 Color Macro 49 (wheel slot 50) 197–200 Color Macro 50 (wheel slot 51) 201–208 Color Macro 51 (wheel slot 52) 209–209 Color Macro 52 (wheel slot 53) 210–212 Color Macro 53 (wheel slot 54) 213–216 Color Macro 54 (wheel slot 55) 217–220 Color Macro 55 (wheel slot 56) 221–224 Color Macro 56 (wheel slot 57) 225–228 Color Macro 57 (wheel slot 58) 229–232 Color Macro 58 (wheel slot 59) 233–236 Color Macro 59 (wheel slot 60) 237–240 Color Macro 60 (wheel slot 61) 241–244 Color Macro 61 (wheel slot 62) 245–248 Color Macro 62 (wheel slot 63) 249–252 Color Macro 63 (wheel slot 64)

13CH (continued)

Ch	Function	Default	DMX values
6	C TO	0	
7	Color Wheel 2	0	0–0 Off (wheel slot 1) 1–42 2700K (wheel slot 13) 43–85 3200K (wheel slot 18) 86–128 4000K (wheel slot 26) 129–171 5600K (wheel slot 42) 172–214 6500K (wheel slot 51) 215–255 7000K (wheel slot 56)
8	Shutter / Strobe	50	0–31 Shutter Closed 32–63 No Function (Shutter Open) 64–95 Strobe Effect Slow to Fast 96–127 No Function (Shutter Open) 128–159 Pulse-Effect in Sequences 160–191 No Function (Shutter Open) 192–223 Random Strobe Effect Slow to Fast 224–255 No Function (Shutter Open)
9	Dimmer	0	0–62 0 percent 63–126 25 percent 127–190 50 percent 191–254 75 percent 255–255 100 percent
10	Dimmer Fine	0	Fine byte of Dimmer
11	Dimmer Mode	0	0–20 Default to unit setting 21–40 Standard 41–60 Stage 61–80 TV 81–100 Architectural 101–120 Theatre 121–140 Stage 2 141–141 0/1s Delay 142–142 0/2s Delay 143–143 0/3s Delay 144–144 0/4s Delay 145–145 0/5s Delay 146–146 0/6s Delay 147–147 0/7s Delay 148–148 0/8s Delay 149–149 0/9s Delay 150–150 1s Delay 151–151 1/5s Delay 152–152 2s Delay 153–153 3s Delay 154–154 4s Delay 155–155 5s Delay 156–156 6s Delay 157–157 7s Delay 158–158 8s Delay 159–159 9s Delay 160–160 10s Delay 161–255 Default
12	Dimmer Curve	0	0–20 Square 21–40 Linear 41–60 Inverted Square 61–80 S Curve 81–255 No function

13CH (continued)

Ch	Function	Default	DMX values
13	L EDFrequency	0	0–15 Default to unit setting 16–30 900 Hz 31–45 1000 Hz 46–60 1100 Hz 61–75 1200 Hz 76–90 1300 Hz 91–105 1400 Hz 106–120 1500 Hz 121–135 2500 Hz 136–150 4000 Hz 151–165 5000 Hz 166–180 10000 Hz 181–195 15000 Hz 196–210 20000 Hz 211–225 25000 Hz 226–255 No Function

16CH

16 channels

Ch	Function	Default	DMX values
1	Red	255	0–254 Red Min 255–255 Red Max
2	Green	255	0–254 Green Min 255–255 Green Max
3	Blue	255	0–254 Blue Min 255–255 Blue Max
4	Color Add GY	255	0–254 Lime Min 255–255 Lime Max

16CH (continued)

Ch	Function	Default	DMX values
5	Color Wheel	0	0–0 Off (wheel slot 1) 1–4 Color Macro 1 (wheel slot 2) 5–8 Color Macro 2 (wheel slot 3) 9–12 Color Macro 3 (wheel slot 4) 13–16 Color Macro 4 (wheel slot 5) 17–20 Color Macro 5 (wheel slot 6) 21–24 Color Macro 6 (wheel slot 7) 25–28 Color Macro 7 (wheel slot 8) 29–32 Color Macro 8 (wheel slot 9) 33–36 Color Macro 9 (wheel slot 10) 37–40 Color Macro 10 (wheel slot 11) 41–44 Color Macro 11 (wheel slot 12) 45–48 Color Macro 12 (wheel slot 13) 49–52 Color Macro 13 (wheel slot 14) 53–56 Color Macro 14 (wheel slot 15) 57–60 Color Macro 15 (wheel slot 16) 61–64 Color Macro 16 (wheel slot 17) 65–68 Color Macro 17 (wheel slot 18) 69–72 Color Macro 18 (wheel slot 19) 73–76 Color Macro 19 (wheel slot 20) 77–80 Color Macro 20 (wheel slot 21) 81–84 Color Macro 21 (wheel slot 22) 85–88 Color Macro 22 (wheel slot 23) 89–92 Color Macro 23 (wheel slot 24) 93–96 Color Macro 24 (wheel slot 25) 97–100 Color Macro 25 (wheel slot 26) 101–104 Color Macro 26 (wheel slot 27) 105–108 Color Macro 27 (wheel slot 28) 109–112 Color Macro 28 (wheel slot 29) 113–116 Color Macro 29 (wheel slot 30) 117–120 Color Macro 30 (wheel slot 31) 121–127 Color Macro 31 (wheel slot 32) 128–128 Color Macro 32 (wheel slot 33) 129–132 Color Macro 33 (wheel slot 34) 133–136 Color Macro 34 (wheel slot 35) 137–140 Color Macro 35 (wheel slot 36) 141–144 Color Macro 36 (wheel slot 37) 145–148 Color Macro 37 (wheel slot 38) 149–152 Color Macro 38 (wheel slot 39) 153–156 Color Macro 39 (wheel slot 40) 157–160 Color Macro 40 (wheel slot 41) 161–164 Color Macro 41 (wheel slot 42) 165–168 Color Macro 42 (wheel slot 43) 169–172 Color Macro 43 (wheel slot 44) 173–176 Color Macro 44 (wheel slot 45) 177–180 Color Macro 45 (wheel slot 46) 181–184 Color Macro 46 (wheel slot 47) 185–188 Color Macro 47 (wheel slot 48) 189–192 Color Macro 48 (wheel slot 49) 193–196 Color Macro 49 (wheel slot 50) 197–200 Color Macro 50 (wheel slot 51) 201–208 Color Macro 51 (wheel slot 52) 209–209 Color Macro 52 (wheel slot 53) 210–212 Color Macro 53 (wheel slot 54) 213–216 Color Macro 54 (wheel slot 55) 217–220 Color Macro 55 (wheel slot 56) 221–224 Color Macro 56 (wheel slot 57) 225–228 Color Macro 57 (wheel slot 58) 229–232 Color Macro 58 (wheel slot 59) 233–236 Color Macro 59 (wheel slot 60) 237–240 Color Macro 60 (wheel slot 61) 241–244 Color Macro 61 (wheel slot 62) 245–248 Color Macro 62 (wheel slot 63) 249–252 Color Macro 63 (wheel slot 64)

16CH (continued)

Ch	Function	Default	DMX values
6	C TO	0	
7	Color Wheel 2	0	0–0 Off (wheel slot 1) 1–42 2700K (wheel slot 13) 43–85 3200K (wheel slot 18) 86–128 4000K (wheel slot 26) 129–171 5600K (wheel slot 42) 172–214 6500K (wheel slot 51) 215–255 7000K (wheel slot 56)
8	Shutter / Strobe	50	0–31 Shutter Closed 32–63 No Function (Shutter Open) 64–95 Strobe Effect Slow to Fast 96–127 No Function (Shutter Open) 128–159 Pulse-Effect in Sequences 160–191 No Function (Shutter Open) 192–223 Random Strobe Effect Slow to Fast 224–255 No Function (Shutter Open)
9	Dimmer	0	0–62 0 percent 63–126 25 percent 127–190 50 percent 191–254 75 percent 255–255 100 percent
10	Dimmer Fine	0	Fine byte of Dimmer
11	Effect	0	0–10 No Function 11–26 Program 1 27–43 Program 2 44–60 Program 3 61–76 Program 4 77–93 Program 5 94–110 Program 6 111–126 Program 7 127–143 Program 8 144–160 Program 9 161–176 Program 10 177–193 Program 11 194–210 Program 12 211–226 Program 13 227–241 Program 14 242–255 Program 15
12	Effect Speed	0	
13	Effects1Fade	0	

16CH (continued)

Ch	Function	Default	DMX values
14	Dimmer Mode	0	0–20 Default to unit setting 21–40 Standard 41–60 Stage 61–80 TV 81–100 Architectural 101–120 Theatre 121–140 Stage 2 141–141 0/1s Delay 142–142 0/2s Delay 143–143 0/3s Delay 144–144 0/4s Delay 145–145 0/5s Delay 146–146 0/6s Delay 147–147 0/7s Delay 148–148 0/8s Delay 149–149 0/9s Delay 150–150 1s Delay 151–151 1/5s Delay 152–152 2s Delay 153–153 3s Delay 154–154 4s Delay 155–155 5s Delay 156–156 6s Delay 157–157 7s Delay 158–158 8s Delay 159–159 9s Delay 160–160 10s Delay 161–255 Default
15	Dimmer Curve	0	0–20 Square 21–40 Linear 41–60 Inverted Square 61–80 S Curve 81–255 No function
16	L EDFrequency	0	0–15 Default to unit setting 16–30 900 Hz 31–45 1000 Hz 46–60 1100 Hz 61–75 1200 Hz 76–90 1300 Hz 91–105 1400 Hz 106–120 1500 Hz 121–135 2500 Hz 136–150 4000 Hz 151–165 5000 Hz 166–180 10000 Hz 181–195 15000 Hz 196–210 20000 Hz 211–225 25000 Hz 226–255 No Function

63CH

63 channels

Ch	Function	Default	DMX values
1	Red	255	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %

63CH (continued)

Ch	Function	Default	DMX values
2	Green	255	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
3	Blue	255	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
4	Color Add GY	255	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
5	Reserved 5	0	
6	Reserved 6	0	
7	Reserved 7	0	
8	Reserved 8	0	
9	Reserved 9	0	
10	Reserved 10	0	
11	Reserved 11	0	
12	Reserved 12	0	
13	Reserved 13	0	
14	Reserved 14	0	
15	Reserved 15	0	
16	Reserved 16	0	
17	Reserved 17	0	
18	Reserved 18	0	
19	Reserved 19	0	
20	Reserved 20	0	
21	Reserved 21	0	
22	Reserved 22	0	
23	Reserved 23	0	
24	Reserved 24	0	
25	Reserved 25	0	
26	Reserved 26	0	
27	Reserved 27	0	
28	Reserved 28	0	
29	Reserved 29	0	
30	Reserved 30	0	
31	Reserved 31	0	
32	Reserved 32	0	
33	Reserved 33	0	
34	Reserved 34	0	
35	Reserved 35	0	
36	Reserved 36	0	
37	Reserved 37	0	
38	Reserved 38	0	

63CH (continued)

Ch	Function	Default	DMX values
39	Reserved 39	0	
40	Reserved 40	0	
41	Reserved 41	0	
42	Reserved 42	0	
43	Reserved 43	0	
44	Reserved 44	0	
45	Reserved 45	0	
46	Reserved 46	0	
47	Reserved 47	0	
48	Reserved 48	0	
49	Reserved 49	0	
50	Reserved 50	0	
51	Reserved 51	0	
52	Reserved 52	0	
53	Reserved 53	0	
54	Reserved 54	0	
55	Reserved 55	0	
56	Reserved 56	0	
57	Reserved 57	0	
58	Reserved 58	0	
59	Reserved 59	0	
60	Reserved 60	0	
61	Shutter / Strobe	50	0–31 Shutter Closed 32–63 No Function (Shutter Open) 64–95 Strobe Effect Slow to Fast 96–127 No Function (Shutter Open) 128–159 Pulse-Effect in Sequences 160–191 No Function (Shutter Open) 192–223 Random Strobe Effect Slow to Fast 224–255 No Function (Shutter Open)
62	Dimmer	0	0–62 0 percent 63–126 25 percent 127–190 50 percent 191–254 75 percent 255–255 100 percent
63	Dimmer Fine	0	Fine byte of Dimmer

69CH

69 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	Color Add GY	255	
5	Reserved 5	0	
6	Reserved 6	0	
7	Reserved 7	0	
8	Reserved 8	0	
9	Reserved 9	0	

69CH (continued)

Ch	Function	Default	DMX values
10	Reserved 10	0	
11	Reserved 11	0	
12	Reserved 12	0	
13	Reserved 13	0	
14	Reserved 14	0	
15	Reserved 15	0	
16	Reserved 16	0	
17	Reserved 17	0	
18	Reserved 18	0	
19	Reserved 19	0	
20	Reserved 20	0	
21	Reserved 21	0	
22	Reserved 22	0	
23	Reserved 23	0	
24	Reserved 24	0	
25	Reserved 25	0	
26	Reserved 26	0	
27	Reserved 27	0	
28	Reserved 28	0	
29	Reserved 29	0	
30	Reserved 30	0	
31	Reserved 31	0	
32	Reserved 32	0	
33	Reserved 33	0	
34	Reserved 34	0	
35	Reserved 35	0	
36	Reserved 36	0	
37	Reserved 37	0	
38	Reserved 38	0	
39	Reserved 39	0	
40	Reserved 40	0	
41	Reserved 41	0	
42	Reserved 42	0	
43	Reserved 43	0	
44	Reserved 44	0	
45	Reserved 45	0	
46	Reserved 46	0	
47	Reserved 47	0	
48	Reserved 48	0	
49	Reserved 49	0	
50	Reserved 50	0	
51	Reserved 51	0	
52	Reserved 52	0	
53	Reserved 53	0	
54	Reserved 54	0	

69CH (continued)

Ch	Function	Default	DMX values
55	Reserved 55	0	
56	Reserved 56	0	
57	Reserved 57	0	
58	Reserved 58	0	
59	Reserved 59	0	
60	Reserved 60	0	

69CH (continued)

Ch	Function	Default	DMX values
61	Color Wheel	0	0–0 Off (wheel slot 1) 1–4 Color Macro 1 (wheel slot 2) 5–8 Color Macro 2 (wheel slot 3) 9–12 Color Macro 3 (wheel slot 4) 13–16 Color Macro 4 (wheel slot 5) 17–20 Color Macro 5 (wheel slot 6) 21–24 Color Macro 6 (wheel slot 7) 25–28 Color Macro 7 (wheel slot 8) 29–32 Color Macro 8 (wheel slot 9) 33–36 Color Macro 9 (wheel slot 10) 37–40 Color Macro 10 (wheel slot 11) 41–44 Color Macro 11 (wheel slot 12) 45–48 Color Macro 12 (wheel slot 13) 49–52 Color Macro 13 (wheel slot 14) 53–56 Color Macro 14 (wheel slot 15) 57–60 Color Macro 15 (wheel slot 16) 61–64 Color Macro 16 (wheel slot 17) 65–68 Color Macro 17 (wheel slot 18) 69–72 Color Macro 18 (wheel slot 19) 73–76 Color Macro 19 (wheel slot 20) 77–80 Color Macro 20 (wheel slot 21) 81–84 Color Macro 21 (wheel slot 22) 85–88 Color Macro 22 (wheel slot 23) 89–92 Color Macro 23 (wheel slot 24) 93–96 Color Macro 24 (wheel slot 25) 97–100 Color Macro 25 (wheel slot 26) 101–104 Color Macro 26 (wheel slot 27) 105–108 Color Macro 27 (wheel slot 28) 109–112 Color Macro 28 (wheel slot 29) 113–116 Color Macro 29 (wheel slot 30) 117–120 Color Macro 30 (wheel slot 31) 121–127 Color Macro 31 (wheel slot 32) 128–128 Color Macro 32 (wheel slot 33) 129–132 Color Macro 33 (wheel slot 34) 133–136 Color Macro 34 (wheel slot 35) 137–140 Color Macro 35 (wheel slot 36) 141–144 Color Macro 36 (wheel slot 37) 145–148 Color Macro 37 (wheel slot 38) 149–152 Color Macro 38 (wheel slot 39) 153–156 Color Macro 39 (wheel slot 40) 157–160 Color Macro 40 (wheel slot 41) 161–164 Color Macro 41 (wheel slot 42) 165–168 Color Macro 42 (wheel slot 43) 169–172 Color Macro 43 (wheel slot 44) 173–176 Color Macro 44 (wheel slot 45) 177–180 Color Macro 45 (wheel slot 46) 181–184 Color Macro 46 (wheel slot 47) 185–188 Color Macro 47 (wheel slot 48) 189–192 Color Macro 48 (wheel slot 49) 193–196 Color Macro 49 (wheel slot 50) 197–200 Color Macro 50 (wheel slot 51) 201–208 Color Macro 51 (wheel slot 52) 209–209 Color Macro 52 (wheel slot 53) 210–212 Color Macro 53 (wheel slot 54) 213–216 Color Macro 54 (wheel slot 55) 217–220 Color Macro 55 (wheel slot 56) 221–224 Color Macro 56 (wheel slot 57) 225–228 Color Macro 57 (wheel slot 58) 229–232 Color Macro 58 (wheel slot 59) 233–236 Color Macro 59 (wheel slot 60) 237–240 Color Macro 60 (wheel slot 61) 241–244 Color Macro 61 (wheel slot 62) 245–248 Color Macro 62 (wheel slot 63) 249–252 Color Macro 63 (wheel slot 64)

69CH (continued)

Ch	Function	Default	DMX values
62	C TO	0	
63	Color Wheel 2	0	0–0 Off (wheel slot 1) 1–42 2700K (wheel slot 13) 43–85 3200K (wheel slot 18) 86–128 4000K (wheel slot 26) 129–171 5600K (wheel slot 42) 172–214 6500K (wheel slot 51) 215–255 7000K (wheel slot 56)
64	Shutter / Strobe	50	0–31 Shutter Closed 32–63 No Function (Shutter Open) 64–95 Strobe Effect Slow to Fast 96–127 No Function (Shutter Open) 128–159 Pulse-Effect in Sequences 160–191 No Function (Shutter Open) 192–223 Random Strobe Effect Slow to Fast 224–255 No Function (Shutter Open)
65	Dimmer	0	
66	Dimmer Fine	0	Fine byte of Dimmer
67	Dimmer Mode	0	
68	Dimmer Curve	0	
69	L EDFrequency	0	

72CH

72 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	Color Add GY	255	
5	Reserved 5	0	
6	Reserved 6	0	
7	Reserved 7	0	
8	Reserved 8	0	
9	Reserved 9	0	
10	Reserved 10	0	
11	Reserved 11	0	
12	Reserved 12	0	
13	Reserved 13	0	
14	Reserved 14	0	
15	Reserved 15	0	
16	Reserved 16	0	
17	Reserved 17	0	
18	Reserved 18	0	
19	Reserved 19	0	
20	Reserved 20	0	
21	Reserved 21	0	
22	Reserved 22	0	
23	Reserved 23	0	
24	Reserved 24	0	

72CH (continued)

Ch	Function	Default	DMX values
25	Reserved 25	0	
26	Reserved 26	0	
27	Reserved 27	0	
28	Reserved 28	0	
29	Reserved 29	0	
30	Reserved 30	0	
31	Reserved 31	0	
32	Reserved 32	0	
33	Reserved 33	0	
34	Reserved 34	0	
35	Reserved 35	0	
36	Reserved 36	0	
37	Reserved 37	0	
38	Reserved 38	0	
39	Reserved 39	0	
40	Reserved 40	0	
41	Reserved 41	0	
42	Reserved 42	0	
43	Reserved 43	0	
44	Reserved 44	0	
45	Reserved 45	0	
46	Reserved 46	0	
47	Reserved 47	0	
48	Reserved 48	0	
49	Reserved 49	0	
50	Reserved 50	0	
51	Reserved 51	0	
52	Reserved 52	0	
53	Reserved 53	0	
54	Reserved 54	0	
55	Reserved 55	0	
56	Reserved 56	0	
57	Reserved 57	0	
58	Reserved 58	0	
59	Reserved 59	0	
60	Reserved 60	0	

72CH (continued)

Ch	Function	Default	DMX values
61	Color Wheel	0	0–0 Off (wheel slot 1) 1–4 Color Macro 1 (wheel slot 2) 5–8 Color Macro 2 (wheel slot 3) 9–12 Color Macro 3 (wheel slot 4) 13–16 Color Macro 4 (wheel slot 5) 17–20 Color Macro 5 (wheel slot 6) 21–24 Color Macro 6 (wheel slot 7) 25–28 Color Macro 7 (wheel slot 8) 29–32 Color Macro 8 (wheel slot 9) 33–36 Color Macro 9 (wheel slot 10) 37–40 Color Macro 10 (wheel slot 11) 41–44 Color Macro 11 (wheel slot 12) 45–48 Color Macro 12 (wheel slot 13) 49–52 Color Macro 13 (wheel slot 14) 53–56 Color Macro 14 (wheel slot 15) 57–60 Color Macro 15 (wheel slot 16) 61–64 Color Macro 16 (wheel slot 17) 65–68 Color Macro 17 (wheel slot 18) 69–72 Color Macro 18 (wheel slot 19) 73–76 Color Macro 19 (wheel slot 20) 77–80 Color Macro 20 (wheel slot 21) 81–84 Color Macro 21 (wheel slot 22) 85–88 Color Macro 22 (wheel slot 23) 89–92 Color Macro 23 (wheel slot 24) 93–96 Color Macro 24 (wheel slot 25) 97–100 Color Macro 25 (wheel slot 26) 101–104 Color Macro 26 (wheel slot 27) 105–108 Color Macro 27 (wheel slot 28) 109–112 Color Macro 28 (wheel slot 29) 113–116 Color Macro 29 (wheel slot 30) 117–120 Color Macro 30 (wheel slot 31) 121–127 Color Macro 31 (wheel slot 32) 128–128 Color Macro 32 (wheel slot 33) 129–132 Color Macro 33 (wheel slot 34) 133–136 Color Macro 34 (wheel slot 35) 137–140 Color Macro 35 (wheel slot 36) 141–144 Color Macro 36 (wheel slot 37) 145–148 Color Macro 37 (wheel slot 38) 149–152 Color Macro 38 (wheel slot 39) 153–156 Color Macro 39 (wheel slot 40) 157–160 Color Macro 40 (wheel slot 41) 161–164 Color Macro 41 (wheel slot 42) 165–168 Color Macro 42 (wheel slot 43) 169–172 Color Macro 43 (wheel slot 44) 173–176 Color Macro 44 (wheel slot 45) 177–180 Color Macro 45 (wheel slot 46) 181–184 Color Macro 46 (wheel slot 47) 185–188 Color Macro 47 (wheel slot 48) 189–192 Color Macro 48 (wheel slot 49) 193–196 Color Macro 49 (wheel slot 50) 197–200 Color Macro 50 (wheel slot 51) 201–208 Color Macro 51 (wheel slot 52) 209–209 Color Macro 52 (wheel slot 53) 210–212 Color Macro 53 (wheel slot 54) 213–216 Color Macro 54 (wheel slot 55) 217–220 Color Macro 55 (wheel slot 56) 221–224 Color Macro 56 (wheel slot 57) 225–228 Color Macro 57 (wheel slot 58) 229–232 Color Macro 58 (wheel slot 59) 233–236 Color Macro 59 (wheel slot 60) 237–240 Color Macro 60 (wheel slot 61) 241–244 Color Macro 61 (wheel slot 62) 245–248 Color Macro 62 (wheel slot 63) 249–252 Color Macro 63 (wheel slot 64)

72CH (continued)

Ch	Function	Default	DMX values
62	C TO	0	
63	Color Wheel 2	0	0–0 Off (wheel slot 1) 1–42 2700K (wheel slot 13) 43–85 3200K (wheel slot 18) 86–128 4000K (wheel slot 26) 129–171 5600K (wheel slot 42) 172–214 6500K (wheel slot 51) 215–255 7000K (wheel slot 56)
64	Shutter / Strobe	50	0–31 Shutter Closed 32–63 No Function (Shutter Open) 64–95 Strobe Effect Slow to Fast 96–127 No Function (Shutter Open) 128–159 Pulse-Effect in Sequences 160–191 No Function (Shutter Open) 192–223 Random Strobe Effect Slow to Fast 224–255 No Function (Shutter Open)
65	Dimmer	0	
66	Dimmer Fine	0	Fine byte of Dimmer
67	Effect	0	0–10 No Function 11–26 Program 1 27–43 Program 2 44–60 Program 3 61–76 Program 4 77–93 Program 5 94–110 Program 6 111–126 Program 7 127–143 Program 8 144–160 Program 9 161–176 Program 10 177–193 Program 11 194–210 Program 12 211–226 Program 13 227–241 Program 14 242–255 Program 15
68	Effect Speed	0	
69	Effects1Fade	0	
70	Dimmer Mode	0	
71	Dimmer Curve	0	
72	L EDFrequency	0	